


# COOLING SYSTEM


<b>INDEX .....</b>	E- 2
<b>OUTLINE .....</b>	E- 4
SPECIFICATIONS .....	E- 4
<b>TROUBLESHOOTING GUIDE .....</b>	E- 4
<b>ON-VEHICLE INSPECTION .....</b>	E- 5
PREPARATION .....	E- 5
ENGINE COOLANT .....	E- 5
REPLACEMENT .....	E- 6
AIR BLEEDING AND REFILLING SYSTEM...	E- 6
RADIATOR CAP .....	E- 7
COOLING FAN .....	E- 7
<b>ON-VEHICLE MAINTENANCE.....</b>	E- 8
RADIATOR .....	E- 8
WATER PUMP .....	E- 9
THERMOSTAT .....	E-11

2BU0EX-001




## INDEX

B2200 (F2 ENGINE)



9MU0EX-002

1. Radiator  
Removal, Inspection, and Installation ..... page E- 7
2. Cooling fan  
Removal and Installation ..... page E- 7  
Inspection ..... page E- 6
3. Water pump  
Removal, Inspection, and Installation ..... page E- 8
4. Thermostat  
Removal ..... page E-10  
Inspection ..... page E-11  
Installation ..... page E-11
5. Coolant reservoir

**B2600I (G6 ENGINE)**

2. MU0EX-003
1. Radiator  
Removal, Inspection, and Installation ..... page E- 7
  2. Cooling fan  
Removal and Installation ..... page E- 7  
Inspection ..... page E- 6
  3. Water pump  
Removal, Inspection, and Installation ..... pages E- 8, 9
  4. Thermostat  
Removal ..... page E-10  
Inspection ..... page E-11  
Installation ..... page E-11
  5. Coolant reservoir

# OUTLINE, TROUBLESHOOTING GUIDE

## OUTLINE

### SPECIFICATIONS

Item		Engine model	F2	G6
Cooling system			Water-cooled, forced circulation	
Coolant capacity	liters (US qt, Imp qt)	With heater	7.5 (7.9, 6.6)	7.5 (7.9, 6.6)
		Without heater	6.9 (7.3, 6.1)	6.9 (7.3, 6.1)
Water pump	Type	Centrifugal		
	Water seal	Unified mechanical seal		
Thermostat	Type		Wax	Wax, two-stage
	Opening temperature °C (°F)	86.5—89.5 (188—193)	Main: 86.5—89.5 (188—193) Sub : 83.5—86.5 (182—188)	
	Full-open temperature °C (°F)	100 (212)	100 (212)	
	Full-open lift mm (in)	8.5 (0.33) min.	Main: 8.0 (0.31) min. Sub : 1.5 (0.06) min.	
Radiator	Type	Corrugated fin		
	Cap valve opening pressure kPa (kg/cm², psi)	74—103 (0.75—1.05, 11—15)		
Cooling fan	Type	Thermo-modulated		
	Switching temperature OFF → ON °C (°F)	M/T	55—65 (131—149)..... linear	68—92 (154—198)..... linear
		A/T	65—75 (149—167)..... linear	—
	Number of blades	M/T	7	8
		A/T	8	—
	Outer diameter of blade mm (in)	M/T	380 (15.0)	410 (16.1)
		A/T	410 (16.1)	—

1BU0EX-001

## TROUBLESHOOTING GUIDE

Problem	Possible Cause	Remedy	Page
Overheating	Insufficient coolant Coolant leakage Radiator fins clogged Radiator cap malfunction Cooling fan malfunction Thermostat malfunction Water passage clogged Water pump malfunction	Add Repair Clean Replace Replace Replace Clean Replace	E— 5 — E— 7 E— 6 E— 6 E—10 E— 5 E— 8
Corrosion	Impurities in coolant	Replace	E— 5

9MU0EX-005


## ON-VEHICLE INSPECTION

PREPARATION  
SST

49 9200 145

Radiator cap  
tester adapter set


49 9200 146

Adapter A  
(Part of  
49 9200 145)

49 9200 147

Adapter B  
(Part of  
49 9200 145)

9MU0EX-006



## ENGINE COOLANT

## Coolant Level (Engine cold)


1. Check that the coolant level is near the radiator inlet port.
2. Check that the coolant level in the coolant reservoir is between the FULL and LOW marks.  
Add coolant if necessary.

**Warning**


- a) Never remove the radiator cap while the engine is hot.
- b) Wrap a thick cloth around the cap when removing it.

## Coolant Quality

1. Check that there is no build up of rust or scales around the radiator cap or radiator filler neck.
2. Check that coolant is free of oil.
3. Replace the coolant if necessary.



9MU0EX-008



9MU0EX-009


## Coolant Leakage

1. Connect a tester and SST to the radiator inlet port.
2. Apply 103 kPa (1.05 kg/cm<sup>2</sup>, 15 psi) pressure to the system.
3. Check that the pressure is held.  
If not, check for coolant leakage.

**Warning**

**When removing either the radiator cap or the tester, loosen it slowly until the pressure in the radiator is released, and then remove it.**

## **REPLACEMENT, AIR BLEEDING AND REFILLING SYSTEM**



21E0EX-00B

## **Coolant Protection**

## **Caution**

- Caution:**

  - a) Do not use alcohol- or methanol-based coolant.
  - b) Use only soft (demineralized) water in the coolant mixture.

1. Measure the coolant temperature and specific gravity with a thermometer and a hydrometer.
  2. Determine the coolant protection by referring to the graph shown.  
If the coolant protection is not proper, add water or coolant.

#### **Antifreeze solution mixture percentage**

Coolant protection	Volume percentage		Gravity at 20°C (68°F)
	Water	Coolant	
Above -16°C (3°F)	65	35	1.054
Above -26°C (-15°F)	55	45	1.066
Above -40°C (-40°F)	45	55	1.078

05U0EX-010

051UDFX-010

## **REPLACEMENT**

## Warning


- Warning**

  - a) Never open the radiator cap while the engine is hot.
  - b) Wrap a thick cloth around the cap when loosening.
  - c) When removing the radiator cap, loosen it slowly to the first stop until the pressure in the radiator is released, and then remove it.
  - d) Use caution when draining hot coolant.

## **Caution**

- a) Do not use alcohol- or methanol-based coolant.
  - b) Use only soft (demineralized) water in the coolant mixture.
  - c) Before loosening the radiator drain plug, verify that the radiator drain hose faces straight down.

1. Remove the radiator cap and loosen the drain plug.
  2. Drain the coolant into a suitable container.
  3. Fill with the proper amount and mixture of ethylene glycol-based coolant.



2BLJ0EX-004

#### **AIR BLEEDING AND REFILLING SYSTEM**

**AIR BLEEDING AND REFILLING COOLANT**  
When the coolant is drained, bleed the cooling system after refilling it.

1. Slowly pour the coolant into the radiator up to the coolant filler port.


Filling pace: 2 l (2.1 US qt, 1.8 Imp qt)/min. max.

2. Fill the coolant reservoir up to the FULL level.
  3. Install the radiator cap securely and start the engine.

2RU10EX-005

## RADIATOR CAP, COOLING FAN

E



2BU0EX-006

- Run the engine at idle speed until it reaches normal operating temperature.


### Caution

If the temperature increase beyond normal, there is excessive air in the system.  
Stop the engine, allow the engine to cool, and repeat Steps 1—3.

- Run the engine above idle several times as specified.

**Speed: 2,200—2,800 rpm × 5 sec.**

- Stop the engine and wait till the system is cooled down. Remove the radiator cap and check the coolant level. If the coolant level has dropped, repeat the operation from Step 1.




49 9200 147

### RADIATOR CAP

#### Radiator Cap Valve


- Remove foreign material (such as water residue) from between the radiator cap valve and the valve seat.
- Attach the radiator cap to a tester with the SST. Apply pressure gradually to **74—103 kPa (0.75—1.05 kg/cm<sup>2</sup>, 11—15 psi)**.
- Wait about 10 seconds; then check that the pressure has not decreased.



9MU0EX-013

#### Negative Pressure Valve

- Pull the negative-pressure valve to open it. Check that it closes completely when released.
- Check for damage on the contact surfaces and for cracked or deformed seal packing.
- Replace the radiator cap if necessary.



9MU0EX-014

### COOLING FAN

#### Inspection

- Inspect the following items. Replace if necessary.
  - Fluid leakage from the fan-drive clutch
  - Deformation of the bimetal
  - Excessive play of the cooling fan bearing
  - Grease leakage from the cooling fan bearing
- When the engine is warm, turn the cooling fan by hand and check that resistance is felt. Replace the fan-drive clutch if necessary.

## ON-VEHICLE MAINTENANCE

## RADIATOR

## Removal, Inspection and Installation

1. Drain the engine coolant.
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal.


## Caution

After radiator cowling installation, rotate the cooling fan by hand and verify that the fan blade does not touch the radiator cowling.

If the fan touches the cowling, adjust the radiator cowling mounting position.

## Note

Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.



1. Upper and lower radiator hoses
2. Coolant reservoir hose
3. ATF hose (A/T)

4. Cooling fan and radiator cowling
5. Radiator

**WATER PUMP****Removal, Inspection, and Installation**

1. Disconnect the negative battery cable.
2. Turn the crankshaft so that the No.1 cylinder is at TDC of compression. (F2 Engine)
3. Drain the engine coolant.
4. Remove in the order shown in the figure.
5. Inspect all parts and repair or replace as necessary.
6. Install in the reverse order of removal.


**Caution**

**After radiator cowling installation, rotate the cooling fan by hand and verify that the fan blade does not touch the radiator cowling.**

**If the fan touches the cowling, adjust the radiator cowling mounting position.**

**Note**

**Do not disassemble the water pump. If a problem is found, replace the pump as a unit.**

**F2 ENGINE**


N·m (m·kg, ft·lb)

1BU0EX-003

1. Timing belt (Refer to Section B1.)
2. Timing belt idler pulley
3. Water pump  
Inspect for body cracks and damaged gasket surface
4. Gasket

## ON-VEHICLE MAINTENANCE (WATER PUMP)

### G6 ENGINE



9MU0EX-019

1. Drive belt Adjustment ..... Section B2
2. Cooling fan and radiator cowling
3. Water pump pulley

4. Water pump  
Inspect body cracks and damaged gasket surface
5. Gasket



#### Steps After Installation

1. Add engine coolant to the specified levels.
2. Connect the negative battery cable.
3. Start the engine and do the following:
  - (1) Check for leakage of engine coolant.
  - (2) Perform engine adjustments if necessary.
  - (3) Recheck the coolant levels.

9MU0EX-020

**THERMOSTAT****Removal**

1. Drain the engine coolant.
2. Remove in the order shown in the figure.

**F2 ENGINE****G6 ENGINE**

1. Upper radiator hose
2. Thermostat cover


3. Thermostat  
Inspection ..... page E-12

N·m (m·kg, ft·lb)

2BU0EX-007


## ON-VEHICLE MAINTENANCE (THERMOSTAT)

F2 ENGINE



9BU0EX-005

G6 ENGINE



9BU0EX-006

### Inspection

Check the thermostat and replace if necessary.

1. Visually check that the valve is airtight.
2. Place the thermostat in water with a thermometer.  
Increase the water temperature, and check the following.

Item	Engine	F2	G6
Initial opening temperature °C (°F)		86.5—89.5 (188—193)	Main: 86.5—89.5 (188—193) Sub : 83.5—86.5 (182—188)
Full-open temperature °C (°F)		100 (212)	100 (212)
Full-open lift mm (in)		8.5 (0.33) min.	Main: 8.0 (0.31) min. Sub : 1.5 (0.06) min.

### Installation

Install in the reverse order of removal.

#### Note

Position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.

9MU0EX-024

### Steps After Installation

1. Add engine coolant to the specified levels.
2. Connect the negative battery cable.
3. Start the engine and do the following:
  - (1) Check for leakage of engine coolant.
  - (2) Perform engine adjustments if necessary.
  - (3) Recheck the coolant levels.

9MU0EX-025

# FUEL AND EMISSION CONTROL SYSTEMS (CARBURETOR)

<b>INDEX .....</b>	<b>F1- 2</b>
<b>OUTLINE .....</b>	<b>F1- 6</b>
SYSTEM DIAGRAM .....	F1- 6
COMPONENT DESCRIPTIONS .....	F1- 7
VACUUM HOSE ROUTING DIAGRAM .....	F1- 10
SPECIFICATIONS .....	F1- 12
<b>TROUBLESHOOTING GUIDE .....</b>	<b>F1- 13</b>
HOW TO USE THIS SECTION .....	F1- 13
DIAGNOSTIC INDEX .....	F1- 15
SYMPTOM TROUBLESHOOTING .....	F1- 16
<b>FEEDBACK SYSTEM .....</b>	<b>F1- 52</b>
PREPARATION .....	F1- 52
SYSTEM INSPECTION .....	F1- 53
AIR/FUEL (A/F) SOLENOID VALVE .....	F1- 54
OXYGEN SENSOR .....	F1- 55
IDLE, CLUTCH, NEUTRAL, AND AIR-CONDITIONER SIGNALS .....	F1- 56
<b>AIR INJECTION SYSTEM .....</b>	<b>F1- 58</b>
SYSTEM INSPECTION .....	F1- 59
No.1 AIR CONTROL VALVE .....	F1- 59
No.2 AIR CONTROL VALVE .....	F1- 60
REED VALVE .....	F1- 60
ACV SOLENOID VALVE .....	F1- 60
<b>EXHAUST GAS RECIRCULATION (EGR) SYSTEM .....</b>	<b>F1- 61</b>
SYSTEM INSPECTION .....	F1- 62
EGR CONTROL VALVE .....	F1- 62
EGR POSITION SENSOR .....	F1- 63
DUTY SOLENOID VALVE .....	F1- 63
<b>DECELERATION CONTROL SYSTEM .....</b>	<b>F1- 65</b>
SYSTEM INSPECTION .....	F1- 66
SLOW FUEL CUT SOLENOID VALVE .....	F1- 67
COASTING RICHER SOLENOID VALVE .....	F1- 67
VACUUM SOLENOID VALVE .....	F1- 67
MIXTURE CONTROL VALVE .....	F1- 68
DASHPOT (FOR M/T) .....	F1- 68
<b>EVAPORATIVE EMISSION CONTROL (EEC) SYSTEM .....</b>	<b>F1- 69</b>
SYSTEM INSPECTION .....	F1- 70
No.1 PURGE CONTROL VALVE .....	F1- 70
No.2 PURGE CONTROL VALVE .....	F1- 71
No.3 PURGE CONTROL VALVE .....	F1- 71
WATER THERMOVALVE .....	F1- 71
CHECK-AND-CUT VALVE .....	F1- 71
AIR VENT SOLENOID VALVE .....	F1- 72
PURGE SOLENOID VALVE .....	F1- 72
<b>CATALYTIC CONVERTER .....</b>	<b>F1- 74</b>
INSPECTION .....	F1- 74
<b>PTC HEATER SYSTEM .....</b>	<b>F1- 75</b>
PTC HEATER .....	F1- 75
PTC HEATER RELAY .....	F1- 75
<b>ALTITUDE COMPENSATION SYSTEM .....</b>	<b>F1- 76</b>
HIGH-ALTITUDE COMPENSATOR .....	F1- 76
<b>AIR INTAKE TEMPERATURE CONTROL SYSTEM .....</b>	<b>F1- 77</b>
CONTROL VALVE .....	F1- 77
<b>HOT-IDLE COMPENSATION SYSTEM .....</b>	<b>F1- 78</b>
IDLE COMPENSATOR .....	F1- 78
<b>ACCELERATOR CABLE .....</b>	<b>F1- 78</b>
<b>POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM .....</b>	<b>F1- 79</b>
PCV VALVE .....	F1- 79
<b>VACUUM CONTROL VALVE (VCV) SYSTEM .....</b>	<b>F1- 80</b>
VACUUM CONTROL VALVE .....	F1- 80
<b>AIR CLEANER .....</b>	<b>F1- 80</b>
AIR CLEANER ELEMENT .....	F1- 80
<b>FUEL SYSTEM .....</b>	<b>F1- 81</b>
FUEL PUMP (ELECTRICAL TYPE) .....	F1- 82
FUEL PUMP (MECHANICAL TYPE) .....	F1- 83
FUEL PUMP CONTROL UNIT .....	F1- 83
FUEL FILTER .....	F1- 83
FUEL TANK .....	F1- 84
FUEL CHECK VALVE .....	F1- 84
FUEL CUT VALVE .....	F1- 84
CARBURETOR .....	F1- 85
<b>CONTROL SYSTEM .....</b>	<b>F1- 95</b>
PREPARATION .....	F1- 95
TROUBLESHOOTING WITH SELF-DIAGNOSIS CHECKER .....	F1- 97
WATER TEMPERATURE SWITCH .....	F1- 105
IDLE SWITCH .....	F1- 105
CLUTCH SWITCH .....	F1- 105
NEUTRAL SWITCH .....	F1- 105
INHIBITOR SWITCH .....	F1- 106
ATMOSPHERIC PRESSURE SENSOR .....	F1- 106
WATER THERMOSENSOR .....	F1- 106
VACUUM SENSOR .....	F1- 107
INTAKE AIR THERMOSENSOR .....	F1- 107
EGR POSITION SENSOR .....	F1- 107
OXYGEN SENSOR .....	F1- 107
ENGINE CONTROL UNIT .....	F1- 108
<b>IDLE ADJUSTMENT .....</b>	<b>F1- 112</b>
IDLE SPEED .....	F1- 112
IDLE MIXTURE .....	F1- 112
<b>IDLE-UP SYSTEM .....</b>	<b>F1- 114</b>
IDLE-UP FOR A/T OR A/C .....	F1- 114
IDLE UP FOR A/T WITH A/C (DUAL SERVO DIAPHRAGM) .....	F1- 115
IDLE-UP SOLENOID VALVE .....	F1- 116
<b>MALFUNCTION INDICATOR LIGHT (MIL) .....</b>	<b>F1- 117</b>