


AUTOMATIC TRANSMISSION (Electronically-Controlled)

INDEX	K2- 2	OIL PUMP	K2- 61
OUTLINE	K2- 3	REVERSE CLUTCH	K2- 65
SPECIFICATIONS	K2- 3	HIGH CLUTCH AND	
CROSS-SECTIONAL VIEW	K2- 4	FRONT SUN GEAR	K2- 71
POWER FLOW DIAGRAM	K2- 5	BAND SERVO	K2- 78
OPERATION OF COMPONENTS	K2- 5	FRONT INTERNAL GEAR, REAR	
FLUID PASSAGE LOCATION	K2- 6	INTERNAL GEAR, FORWARD CLUTCH	
TROUBLESHOOTING	K2- 8	HUB, OVERRUNNING CLUTCH HUB	K2- 82
GENERAL NOTES	K2- 8	FORWARD CLUTCH DRUM	
QUICK DIAGNOSIS CHART	K2- 9	(FORWARD CLUTCH; OVERRUNNING	
SELF-DIAGNOSTIC SYSTEM		CLUTCH, LOW ONE-WAY CLUTCH)	K2- 85
INSPECTION	K2- 13	LOW AND REVERSE BRAKE	K2- 93
SELF-DIAGNOSTIC FUNCTION	K2- 13	ADAPTER CASE AND	
EC-AT TESTER	K2- 13	PARKING MECHANISM	K2- 99
GENERAL NOTES	K2- 16	OIL SEAL	K2-102
RETRIEVAL PROCEDURES	K2- 16	CONTROL VALVE BODY	
INSPECTION PROCEDURES	K2- 17	(DISASSEMBLY AND INSPECTION) ..	K2-103
AFTER-REPAIR PROCEDURES	K2- 20	UPPER VALVE BODY	K2-108
ELECTRIC SIGNAL INSPECTION	K2- 21	LOWER VALVE BODY	K2-116
INSPECTION PROCEDURES	K2- 21	CONTROL VALVE BODY (ASSEMBLY)	K2-121
MECHANICAL SYSTEM TEST	K2- 23	ON-VEHICLE REMOVAL	K2-124
PREPARATION	K2- 23	ON-VEHICLE INSTALLATION	K2-126
STALL TEST	K2- 23	TRANSMISSION UNIT (ASSEMBLY)	K2-128
TIME LAG TEST	K2- 26	TRANSMISSION UNIT (INSTALLATION)	K2-140
LINE PRESSURE TEST	K2- 27	OIL COOLER	K2-143
ROAD TEST	K2- 29	DRIVE PLATE	K2-144
D RANGE TEST	K2- 29	SHIFT MECHANISM	K2-146
S RANGE TEST	K2- 32	SHIFT-LOCK SYSTEM COMPONENTS	K2-146
L RANGE TEST	K2- 33	TROUBLESHOOTING	K2-146
P RANGE TEST	K2- 33	P RANGE SWITCH	K2-148
ELECTRONIC SYSTEM COMPONENTS	K2- 35	SHIFT-LOCK ACTUATOR	K2-148
HOLD OFF SWITCH	K2- 35	SELECTOR LEVER	K2-149
INHIBITOR SWITCH	K2- 35	REMOVAL, INSPECTION AND	
ATF THERMOSENSOR	K2- 36	INSTALLATION	K2-152
SPEED SENSOR 1	K2- 37	HYDRAULIC CIRCUIT	K2-155
SOLENOID VALVES	K2- 38	P RANGE	K2-155
DROPPING RESISTOR	K2- 38	R RANGE	K2-156
ATF THERMOSWITCH	K2- 38	N RANGE	K2-157
EC-AT CONTROL UNIT	K2- 39	D RANGE; 1ST GEAR	K2-158
AUTOMATIC TRANSMISSION FLUID		D RANGE; 2ND GEAR	K2-159
(ATF)	K2- 42	D RANGE; 3RD GEAR	K2-160
INSPECTION	K2- 42	D RANGE; OD, LOCKUP OFF	K2-161
REPLACEMENT	K2- 43	D RANGE; OD, LOCKUP ON	K2-162
TRANSMISSION	K2- 44	S RANGE; 1ST GEAR	K2-163
TRANSMISSION UNIT (REMOVAL)	K2- 44	S RANGE; 2ND GEAR	K2-164
TRANSMISSION UNIT		S RANGE; 3RD GEAR	K2-165
(DISASSEMBLY)	K2- 47	L RANGE; 1ST GEAR	K2-166
TORQUE CONVERTER	K2- 58	L RANGE; 2ND GEAR	K2-167
ACCUMULATORS	K2- 59		

INDEX



1. Hold switch		
Inspection	page K2-	35
2. Inhibitor switch		
Inspection	page K2-	35
Adjustment	page K2-	36
3. ATF thermosensor		
Inspection	page K2-	36
4. Speed sensor 1		
Inspection	page K2-	37
5. Solenoids		
Inspection	page K2-	38
6. Dropping resistor		
Inspection	page K2-	38
7. ATF thermostwitch		
Inspection	page K2-	38
8. EC-AT control unit		
Inspection	page K2-	39
9. Automatic transmission		
Removal	page K2-	44
Disassembly	page K2-	47
Assembly	page K2-	128
Installation	page K2-	140
10. Oil cooler		
Removal, Inspection, and		
Installation	page K2-	143
11. P range switch		
Inspection	page K2-	148
12. Shift-lock actuator		
Inspection	page K2-	148
13. Selector lever		
Inspection	page K2-	149
Adjustment	page K2-	150
Removal, Inspection, and		
Installation	page K2-	152

2BU0K2-002

OUTLINE


SPECIFICATIONS

Item		Transmission	R4AX-EL
Torque converter stall torque ratio			2.000
Gear ratio	1st		2.786
	2nd		1.546
	3rd		1.000
	OD (4th)		0.694
	Reverse		2.273
Number of drive/ driven plates	Reverse clutch		2/2
	High clutch		4/7
	Forward clutch		6/6
	Overrunning clutch		3/5
	Low and reverse brake		6/6
Automatic transmission fluid (ATF)	Type		Dexron®II or M-III
	Capacity liters (US qt, Imp qt)	Total	8.6 (9.1, 7.6)
		Oil pan	4.0 (4.2, 3.5)


2BU0K2-003

CROSS-SECTIONAL VIEW

- LOW ONE-WAY CLUTCH
- FORWARD ONE-WAY CLUTCH
- LOW AND REVERSE BRAKE
- FORWARD CLUTCH
- OVERRUNNING CLUTCH
- FRONT PLANETARY GEAR UNIT
- REAR PLANETARY GEAR UNIT
- HIGH CLUTCH
- BRAKE BAND
- REVERSE CLUTCH
- OIL PUMP
- TORQUE CONVERTER
- LOCKUP CLUTCH



POWER FLOW DIAGRAM



9MU0K1-005


OPERATION OF COMPONENTS

Mode	Range	Gear	Reverse clutch	High clutch	Forward clutch	Overrunning clutch	Brake band			Forward one-way clutch	Low one-way clutch	Low and reverse brake	
							2nd applied	3rd released	OD applied				
ECONOMY/POWER	P	—											
	R	Reverse	○									○	
	N	—											
	D	1st				○	■				●	●	
		2nd				○	□	○			●		
		3rd			○	○	□	⊗*1	⊗		●		
		OD			○	⊗		⊗*2	⊗	○			
	S	1st				○	★				●	●	
		2nd				○	⊙	○			●		
		3rd			○	○	⊙	⊗*1	⊗		●		
L	1st				○	○	○			●		○	
	2nd				○	○	○			●			
HOLD	D	2nd			○	⊙	○			●			
		3rd		○	○	⊙	⊗*1	⊗		●			
	S	2nd			○	⊙	○			●			
		L	1st			○	○			●		○	


9MU0K1-006

- *1 : Hydraulic pressure is applied to both 2nd applied side and 3rd released side of band servo piston. However, because the area of the 3rd released side is larger than the 2nd applied side, the brake band does not operate.
- *2 : Hydraulic pressure is applied to OD applied side, plus condition *1 above. Brake band is applied.
- : Operates.
- ⊙ : Operates when throttle opening is less than 1/8. Engine braking effect available.
- ★ : Operates when throttle opening is less than 1/8. Engine braking effect not available.
- : Operates when the EC-AT control unit receive OD inhibit signal from the cruise control unit and throttle opening less than 1/8. Engine braking effect available.
- : Operates when the EC-AT control unit receive OD inhibit signal from the cruise control unit and throttle opening less than 1/8. Engine braking effect not available.
- ⊗ : Operates but does not transmit power.
- : Operates during acceleration and cruising.


FLUID PASSAGE LOCATION
Transmission Case



BAND SERVO OD APPLY SIDE PRESSURE
 BAND SERVO 2ND APPLY SIDE PRESSURE
 BAND SERVO 3RD RELEASE SIDE PRESSURE
 3-4/N-R ACCUMULATOR BACK SIDE PRESSURE (R RANGE LINE PRESSURE INSPECTION HOLE)
 FORWARD CLUTCH PRESSURE (S,D,L RANGE LINE PRESSURE INSPECTION HOLE)
 OIL COOLER INLET




FORWARD CLUTCH PRESSURE
 OIL PUMP SUCTION
 TORQUE CONVERTER PRESSURE (LOCKUP CONDITION)
 REVERSE CLUTCH PRESSURE
 TORQUE CONVERTER PRESSURE (NON-LOCKUP CONDITION)
 HIGH CLUTCH PRESSURE
 FRONT LUBRICATION
 OIL PUMP DISCHARGE
 OVERRUNNING CLUTCH PRESSURE
 OIL PUMP FEEDBACK PRESSURE




FORWARD CLUTCH PRESSURE
 OVERRUNNING CLUTCH PRESSURE
 LOW AND REVERSE BRAKE PRESSURE
 N-D ACCUMULATOR SHOULDER SIDE PRESSURE
 2-3 ACCUMULATOR SHOULDER SIDE PRESSURE
 N-D ACCUMULATOR BACK SIDE PRESSURE
 1-2 ACCUMULATOR BACK SIDE PRESSURE
 1-2 ACCUMULATOR DRAIN PORT
 3-4/N-R ACCUMULATOR BACK SIDE PRESSURE
 3-4/N-R ACCUMULATOR SHOULDER SIDE PRESSURE
 2-3 ACCUMULATOR BACK SIDE PRESSURE
 OIL PUMP SUCTION
 TORQUE CONVERTER PRESSURE (LOCKUP CONDITION)
 REVERSE CLUTCH PRESSURE
 TORQUE CONVERTER PRESSURE (NON-LOCKUP CONDITION)
 HIGH CLUTCH PRESSURE
 FRONT LUBRICATION
 OIL PUMP DISCHARGE
 BAND SERVO OD APPLY SIDE PRESSURE
 OIL PUMP FEEDBACK PRESSURE
 BAND SERVO 3RD RELEASE SIDE PRESSURE
 BAND SERVO 2ND APPLY SIDE PRESSURE

Oil Pump




9MU0K1-008

Input Shaft



9MU0K1-009

Output Shaft



9MU0K1-010
K2-7

K2


TROUBLESHOOTING

GENERAL NOTES

A problem with the EC-AT may be caused by the engine, the EC-AT powertrain, the hydraulic control system, or the electronic control system.

When troubleshooting, therefore, begin from these points, which can be inspected quickly and easily. The recommended troubleshooting sequence is described below.

9MU0K1-011




1BU0K2-079

Step 1: Self-diagnostic System Inspection

Check for malfunction code(s) memorized in the EC-AT control unit with the **EC-AT Tester**. (Refer to page K2-13.)

Note

Malfunction code(s) can also be checked for by the flashing sequence of the **HOLD** indicator lamp. (Refer to page K2-13.)




1BU0K2-080

Step 2: Electric Signal Inspection

Check the signals to/from the EC-AT control unit with the **EC-AT Tester**. (Refer to page K2-21.)

Note


Signals can also be checked by checking the EC-AT control unit terminal voltages with a voltmeter. (Refer to page K2-39.)



1BU0K2-081

Step 3: Mechanical System Test

Check the engine stall speed, time lag, and line pressure. (Refer to page K2-23.)



1BU0K2-082

Step 4: Road Test

Note

For correct testing, vehicle speed, throttle opening (throttle sensor voltage), and gear position should be checked with the **EC-AT Tester**.

Check the shift point, shift schedule, and shift shock. (Refer to page K2-29.)

If the 4 steps on page K2-8 are followed, the cause of the problem should be located. Another guide to faster location of the causes of problems, the QUICK DIAGNOSIS CHART, is on pages K2-9 to 12. In this chart, numbers are used to indicate the components that may be the cause of 51 possible problems. It is necessary to check only those components indicated by numbers during each step of the troubleshooting process to locate the cause of the problem quickly.

QUICK DIAGNOSIS CHART

The QUICK DIAGNOSIS CHART shows different problems and the relationship of components that might be the cause.

- Components indicated in the "Adjustment" column indicate the possibility that the problem may result from an incorrect adjustment.
Check the adjustment of each component, and readjust if necessary.
- Components indicated in the "Self-diagnosis" column are diagnosed by the EC-AT control unit self-diagnostic function.
The **EC-AT Tester** can be used for easy retrieval of these signals.
- Input and output signals of the EC-AT control unit for components indicated in the "EC-AT Tester" column can be easily checked with the **EC-AT Tester**.
- Components indicated in the "Mechanical System Test" column can be checked for malfunction by the results of the oil pressure test.
- Components indicated in the "Road Test" column can be checked for malfunction by the results of the road test.
- The numbers in the chart indicate the order of inspection for detecting malfunctions.
- Circled numbers indicate that the transmission must be removed from the vehicle.
- The checking, adjusting, repair, and replacement procedures for components are described in the page(s) shown in the "Reference page" column.

1BU0K2-083

Item	Inspection point and reference page	ON VEHICLE															OFF VEHICLE																						
		Preliminary		Electronic system										Hydraulic control system					Powertrain																				
		K2-42	K2-146	Section F2	Section G	K2-35	K2-35	Section T	Section F2	Section F2	Section F2	Section F2	K2-37	K2-36	Section G	K2-38	K2-38	K2-38	K2-38	K2-38	K2-27	K2-103	K2-59	K2-59	K2-59	K2-59	K2-61	K2-58	K2-65	K2-71	K2-85	K2-82	K2-85	K2-85	K2-93	K2-78	K2-99		
	ATF level and condition																																						
	Selector lever and control linkage	X																																					
	Idle speed and engine condition	X																																					
	Ignition switch and starter																																						
	Inhibitor switch																																						
	Hold switch																																						
	Cruise control switch																																						
	Atmospheric pressure sensor																																						
	Idle switch																																						
	Throttle sensor																																						
	Speed sensor 1																																						
	ATF thermosensor																																						
	Engine rpm sensor																																						
	Shift solenoid A																																						
	Shift solenoid B																																						
	Line pressure solenoid																																						
	Dropping resistor																																						
	Lockup solenoid																																						
	Overrunning clutch solenoid																																						
	Line pressure																																						
	Control valve body																																						
	N-D accumulator																																						
	1-2 accumulator																																						
	2-3 accumulator																																						
	3-4/N-R accumulator																																						
	Oil pump																																						
	Torque converter																																						
	Reverse clutch																																						
	High clutch																																						
	Forward clutch																																						
	Forward one-way clutch																																						
	Overrunning clutch																																						
	Low one-way clutch																																						
	Low and reverse brake																																						
	Brake band and band servo																																						
	Parking mechanism																																						
Adjustment		X	X							X	X																												
Self-diagnosis												X	X	X	X	X	X	X	X	X	X																		
EC-AT Tester																																							
Mechanical System Test																							X	X															
Road Test																																							

K2

Inspection point and reference page		ON VEHICLE														OFF VEHICLE																							
		Preliminary				Electronic system								Hydraulic control system				Powertrain																					
		K2-42	K2-146	Section F2	Section G	K2-35	Section T	Section F2	Section F2	Section F2	K2-37	K2-36	Section G	K2-38	K2-38	K2-38	K2-38	K2-38	K2-27	K2-103	K2-59	K2-59	K2-59	K2-59	K2-61	K2-58	K2-65	K2-71	K2-85	K2-82	K2-85	K2-85	K2-93	K2-78	K2-99				
ATF level and condition	Selector lever and control linkage	Idle speed and engine condition	Ignition switch and starter	Inhibitor switch	Hold switch	Cruise control switch	Atmospheric pressure sensor	Idle switch	Throttle sensor	Speed sensor 1	ATF thermostat	Engine rpm sensor	Shift solenoid A	Shift solenoid B	Line pressure solenoid	Dropping resistor	Lockup solenoid	Overrunning clutch solenoid	Line pressure	Control valve body	N-D accumulator	1-2 accumulator	2-3 accumulator	3-4/N-R accumulator	Oil pump	Torque converter	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrunning clutch	Low one-way clutch	Low and reverse brake	Brake band and band servo	Parking mechanism				
Engine starting	Engine does not start in N and/or P range	2	1	3																																			
	Engine starts in ranges other than N and P range	1		2																																			
Accelerating	Vehicle does not move in D range (moves in L, S, and R ranges)	1																																		②			
	Vehicle does not move in forward ranges (moves in R range) Extremely poor acceleration	1												3					2	4	5																		
	Vehicle does not move in R range (moves in forward ranges) Extremely poor acceleration	1												3					2	4																			
	Vehicle does not move in any range	1	2											4					3							5	9		6								8	7	10
	Slippage felt when accelerating	1	2						3					5					4	6	7					8	12	13	10		9						11		
	Vehicle moves in N range	1																							4			3		2		5							
	Excessive creep		1																																				
	No creep	1																		2	3						5	6		4									
	Low maximum speed and poor acceleration	1		2										3	4							5					10	11	6	7							9	8	
	No shift	Does not shift from 1st to 2nd	3	2	1						6		4									5																	7
Does not shift from 2nd to 3rd		3	2	1						6		4									5								7									8	
Does not shift from 3rd to OD		4	3	1	2					6	7	5																											8
Lockup does not occur				4				1	2	3	6	5						8	7	9							10												
Does not shift from OD to 3rd		1								2			4	5				3			6																	8	7
Does not shift from 3rd to 2nd, or from OD to 2nd		1								2			3	4							5									6									7
Does not shift from 2nd to 1st or from 3rd to 1st		1			3					2			4	5							6									8			7						9
Does not kickdown when accelerator is depressed in OD within kickdown range										1	2			3	4																								

Inspection point and reference page		ON VEHICLE																			OFF VEHICLE																			
		Preliminary		Electronic system										Hydraulic control system							Powertrain																			
		K2-42	K2-146	Section F2	Section G	K2-35	K2-35	Section T	Section F2	Section F2	Section F2	K2-37	K2-36	Section G	K2-38	K2-38	K2-38	K2-38	K2-27	K2-103	K2-59	K2-59	K2-59	K2-59	K2-61	K2-58	K2-65	K2-71	K2-85	K2-82	K2-85	K2-85	K2-93	K2-78	K2-99					
ATF level and condition	Selector lever and control linkage	Idle speed and engine condition	Ignition switch and starter	Inhibitor switch	Hold switch	Cruise control switch	Atmospheric pressure sensor	Idle switch	Throttle sensor	Speed sensor 1	ATF thermostat	Engine rpm sensor	Shift solenoid A	Shift solenoid B	Line pressure solenoid	Dropping resistor	Lockup solenoid	Overrunning clutch solenoid	Line pressure	Control valve body	N-D accumulator	1-2 accumulator	2-3 accumulator	3-4/N-R accumulator	Oil pump	Torque converter	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrunning clutch	Low one-way clutch	Low and reverse brake	Brake band and band servo	Parking mechanism					
Item	No shift	Excessive engine speed when accelerated in OD due to delayed kickdown								2	1			3	4																									
	Does not shift from 2nd to 1st in L range				1						2		3					5		4												6				7				
Shift shock	Excessive N to D range shift shock		1				5	2	4	7			8	6				3	9	10									11											
	Excessive 1st to 2nd shift shock						6	1	5					7				2	4	3																		8		
	Excessive 2nd to 3rd shift shock						6	1	5					7				2	4	3							8											9		
	Excessive 3rd to OD shift shock						5	1						6				2	4					3					8									7		
	Vehicle brakes when shifted from 1st to 2nd	1																										2	4									5	3	
	Vehicle brakes when shifted from 2nd to 3rd	1																																					2	
	Vehicle brakes when shifted from 3rd to OD	1																										4											3	2
	Shift shock felt when accelerator released and deceleration occurs							3	1							4			5	2	6																			
	Excessively large 2nd to 1st shift shock in L range																					1																	2	
Vehicle brakes when shifted to R range	1	2												4				3	5										6	8		9					7			
Shift point	Excessively high 1st to 2nd, 2nd to 3rd, and 3rd to OD shift points				3			1	2			4	5																											
	Excessively high OD to 3rd, 3rd to 2nd, and 2nd to 1st shift points							1	2																															
	Excessively high or low lockup point							1	2							3				4																				
	Shifts directly from 1st to 3rd	1																					2															3		
Slipping	Almost no shift shock or excessive slippage at 1st to 2nd shift	1							2											3	5	4																6		
	Almost no shift shock or excessive slippage at 2nd to 3rd shift	1							2											3	5		4					6										7		
	Almost no shift shock or excessive slippage at 3rd to OD shift	1							2											3	5			4				6										7		

Inspection point and reference page	ON VEHICLE														OFF VEHICLE																						
	Preliminary		Electronic system										Hydraulic control system				Powertrain																				
	K2-42	K2-146	Section F2	Section G	K2-35	K2-35	Section T	Section F2	Section F2	Section F2	K2-37	K2-36	Section G	K2-38	K2-38	K2-38	K2-38	K2-38	K2-38	K2-27	K2-103	K2-59	K2-59	K2-59	K2-59	K2-61	K2-58	K2-65	K2-71	K2-85	K2-82	K2-85	K2-85	K2-93	K2-78	K2-99	
ATF level and condition	Selecter lever and control linkage	Idle speed and engine condition	Ignition switch and starter	Inhibitor switch	Hold switch	Cruise control switch	Atmospheric pressure sensor	Idle switch	Throttle sensor	Speed sensor 1	ATF thermosensor	Engine rpm sensor	Shift solenoid A	Shift solenoid B	Line pressure solenoid	Dropping resistor	Lockup solenoid	Overrunning clutch solenoid	Line pressure	Control valve body	N-D accumulator	1-2 accumulator	2-3 accumulator	3-4/N-R accumulator	Oil pump	Torque converter	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrunning clutch	Low one-way clutch	Low and reverse brake	Brake band and band servo	Parking mechanism		
Slipping	Engine overruns or slips when shifting OD to 3rd	1							2					4					3	5								6	7								
	Engine overruns or slips when shifting OD to 2nd	1							2			5		4					3	6								6						7			
	Engine overruns or slips when shifting 3rd to 2nd	1							2					4			8	3	5				10					9	7						6		
	Engine overruns or slips when shifting OD to 3rd, or OD to 2nd	1							2					4					3	5								6	7			8					
	Lockup clutch (in torque converter) slips when locking	1							2					5	4		3	6								7											
Noise	Transmission noisy in P, and N ranges	1							3	4		5							2						6	7											
	Transmission noisy in D, S, L, and R ranges	1																								2											
Others	No engine braking in L range	2		1					3	4		5					7	6														8		9			
	Vehicle moves in P or parking gear not disengaged when P is disengaged	1																																	2		
	Transmission overheats	1	2						3					5			4	6							7	14	8	9	11	12	13	10					
	White smoke discharged from exhaust while running	1																									2	3	5		6		7	4			
	Abnormal odor from oil level gauge pipe	1																								3	2	4	6	7		8		9	6		
Engine stalls when shifting to D, S, L, or R ranges		1														2		3								4											

2BU0K2-004

SELF-DIAGNOSTIC SYSTEM INSPECTION





















SELF-DIAGNOSTIC FUNCTION

The self-diagnostic system, which is integrated in the EC-AT control unit, diagnoses malfunction of the main sensors (input) and solenoid valves (output) and the EC-AT control unit.


Malfunctions or intermittent malfunctions are stored in the EC-AT control unit to later be output as malfunction codes.

The **EC-AT Tester and Adapter** are used to retrieve these malfunction codes. Each malfunction is indicated by a code number and the buzzer as shown in the table below.

Malfunction Code Number

CODE NO.	LOCATION OF MALFUNCTION	BUZZER	BUZZER (HOLD INDICATOR LAMP FLASH CYCLE)
		49 G019 901 TESTER BODY	49 G019 901A TESTER BODY
01	ENGINE RPM SENSOR		
06	SPEED SENSOR 1		
07	SPEED SENSOR 2 (IN SPEEDOMETER)		
12	THROTTLE SENSOR		
56	ATF THERMOSENSOR		
60	SHIFT SOLENOID A		
61	SHIFT SOLENOID B		
62	OVERRUNNING CLUTCH SOLENOID		
63	LOCKUP SOLENOID		
64	LINE PRESSURE SOLENOID		

9MU0K1-018




1BU0K2-005

EC-AT TESTER


The previous **EC-AT Tester** can be used along with the **Adapter** (49 L019 901).


Components

EC-AT TESTER BODY (49 G019 901) AND ADAPTER UNIT (49 H019 902)




EC-AT TESTER BODY (49 G019 901A)







08U0K2-015




9MU0K1-021



9MU0K1-022



08U0K2-016



9MU0K1-024

Assembly of EC-AT Tester

For EC-AT tester body (49 G019 901) and adapter unit (49 H019 902)

1. Install the **adapter** (49 L019 901) to the assembled **EC-AT tester body** (49 G019 901) and **adapter unit** (49 H019 902).
2. Set the **panel** (49 L019 903) onto the EC-AT tester.

3. Affix the EC-AT tester assembly with the band.

4. Set the code selector switch to position A.

Note

Position B is used only for the 1987 626.

5. Select the select switch to the MPV position.

For EC-AT tester body (49 G019 901A)


1. Install the **adapter** (49 L019 901) to the **EC-AT tester body** (49 G019 901A).
2. Set the **panel** (49 L019 902) onto the EC-AT tester body.

3. Perform steps 3 to 5 above.


06 → 4 SEC PERIOD →
62 → 4 SEC PERIOD →
64 → 4 SEC PERIOD →
REPEATS ABOVE

9MU0K1-025


CHECK CONNECTOR NOT GROUNDED




9MU0K1-026



9MU0K1-027



2BU0K2-005



9MU0K1-029

GENERAL NOTES

1. If there is more than one malfunction, the code numbers will be displayed on the tester one by one in numerical order. In the case of malfunctions 62, 06, and 64, the code numbers are displayed in order of 06, 62, then 64. The display is shown.


2. The HOLD indicator flashes to indicate the same pattern as the buzzer of the **EC-AT Tester (49 G019 901A)** when the check connector (blue, 1-pin) is grounded. When the check connector is not grounded, the indicator flashes at a constant frequency malfunction recovers. However, the malfunction code is memorized in the EC-AT control unit.

3. The EC-AT control unit has a built-in fail-safe function for the throttle sensor, the speed sensors, and all the solenoids. If a malfunction occurs, the EC-AT control unit will control operation of the remaining components according to a preset fail-safe program. The vehicle may still be driven, although driving performance will be slightly affected.


4. The memory of malfunction codes is canceled when the negative battery terminal is disconnected for approximately 20 seconds.

RETRIEVAL PROCEDURES

1. Locate the check connector, and test connector.



OBU0K2-166



1BU0K2-006


2. Connect the 6-pin connector of the **EC-AT Tester** to the test connector (Blue: 6-pin).
3. Ground the ground connector of the **EC-AT Tester**.
4. Ground the check connector (Blue: 1-pin).
5. Turn the ignition switch ON.
6. Check that "88" flashes on the digital display and that the buzzer sounds for three seconds.
7. If "88" does not flash, check the test connector wiring.
8. If "88" flashes and the buzzer sounds continuously for more than **20 seconds**, check the wiring to 2N terminal of the EC-AT control unit for a short-circuit. If necessary, replace the EC-AT control unit and repeat steps 2 to 5.
9. Note the code numbers and check for the causes by referring to the INSPECTION PROCEDURES shown on pages K2-17 to 20. Repair as necessary.

Note

After repairs are made, recheck for code numbers by performing the "AFTER-REPAIR PROCEDURES". (Refer to page K2-20.)


INSPECTION PROCEDURES


No.01 Code Display (Engine RPM Sensor)




OBU0K2-018

No.06 Code Display (Speed Sensor 1)







No.07 Code Display (Speed Sensor 2)




No.12 Code Display (Throttle Sensor)




No.56 Code Display (ATF Thermosensor)







No.60, 61, or 62 Code Display (Shift Solenoid A, Shift Solenoid B, or Overrunning Clutch Solenoid)




No.63 Code Display (Lockup Solenoid)



No.64 Code Display (Line Pressure Solenoid)



1BU0K2-012



2BU0K2-006

DRIVE AT 50 km/h (31 mph)


↓

KICKDOWN

↓

STOP THE VEHICLE

79G07C-069




9MU0K1-484

AFTER-REPAIR PROCEDURES


1. Cancel the memory of malfunctions by disconnecting the negative battery terminal for approximately 20 seconds and reconnect it.
2. Remove the **EC-AT tester** if it is connected.

3. Drive the vehicle at 50 km/h (31 mph), then depress the accelerator pedal fully to activate kickdown. Stop the vehicle gradually.

4. Reconnect the **EC-AT Tester** to the test connector (Blue: 6-pin).
5. Ground the ground connector of the **EC-AT Tester**.
6. Ground the check connector (Blue: 1-pin).
7. Turn the ignition switch ON.
8. Check that no code numbers are displayed.



9MU0K1-041



1BU0K2-013

ELECTRIC SIGNAL INSPECTION

In this step, the input and output signals are checked with the **EC-AT Tester**.

The tester checks for proper operation of the various switches and sensors in the EC-AT system. It also checks the control unit for output of the various control signals.

INSPECTION PROCEDURES

1. Assemble the **EC-AT Tester**. (Refer to page K2-15.)
2. Disconnect the connectors from the EC-AT control unit.
3. Connect the **Adapter** between the control unit and the connectors.
4. Turn the ignition switch and main switch of the **EC-AT Tester** ON.
5. Check indication of the respective light or digital display in each condition, referring to the indication table below.

Indication Table of Light and Digital Display

Item	Indication	Condition	Possible cause	
Input (Light)				
INHIBITOR SW	P, N	ON	Other ranges	Inhibitor switch or wiring
		OFF	P or N range	
	D	ON	D range	
		OFF	Other ranges	
	S	ON	S range	
		OFF	Other ranges	
	L	ON	L range	
		OFF	Other ranges	
R	ON	R range		
	OFF	Other ranges		
MODE SW	Not used		—	
HOLD SW	ON	Hold switch depressed	Hold switch or wiring	
	OFF	Hold switch released		
*ATF THERMOSENSOR	ON	ATF temperature above 40°C (104°F)	ATF thermosensor or wiring	
	OFF	ATF temperature below 40°C (104°F)		
IDLE SW	ON	Throttle valve fully closed	Idle switch (in throttle sensor) or wiring	
	OFF	Throttle valve open		
ATMOSPHERIC PRESSURE SENSOR	ON	Atmospheric pressure below 679 mmHg (26.73 inHg) which is approximately at 1,500 m (4,921 ft)	Atmospheric pressure sensor (in engine control unit) or wiring	
	OFF	Atmospheric pressure above 679 mmHg (26.73 inHg)		

Note

*: Items should be checked with engine running or while driving.

ELECTRIC SIGNAL INSPECTION

Item	Indication	Condition	Possible cause	
*CRUISE CONTROL SW	ON	SET or RESUME switch ON or vehicle speed 8 km/h (5 mph) lower than preset speed (Driving vehicle, cruise control operation)	Cruise control unit, switch, or wiring	
	OFF	SET or RESUME switch OFF and vehicle speed kept at preset speed (driving vehicle, cruise control operation and not cruise control operation)		
Input (Digital display)				
THROTTLE SENSOR	EC-AT control unit terminal voltage	Constant	Throttle sensor or wiring	
*VEHICLE SPEED	Vehicle speed calculated from speed sensor 1 signal	Constant	Speed sensor 1 or wiring	
*ENGINE RPM	Not used		—	
Output (Light)				
*SOLENOID	SHIFT A	ON	1st and OD gear positions	Control unit, shift solenoid A, or wiring
		OFF	2nd and 3rd gear positions	
	SHIFT B	ON	1st and 2nd gear positions	Control unit, shift solenoid B, or wiring
		OFF	3rd and OD gear positions	
	OVER-RUNNING	ON	Other conditions	Control unit, overrunning clutch solenoid, or wiring
		OFF	When engine braking and 3-2 timing control	
	LOCKUP	Bright	Lockup	Control unit, lockup solenoid, or wiring
		Dim	Non-lockup	
	LINE PRESSURE	ON (Bright↔Dim)	While driving	Control unit, line pressure solenoid, or wiring
		OFF	Vehicle stopped	
HOLD INDICATOR	ON	Hold mode	Control unit, hold switch, or wiring	
	OFF	Other modes		
MODE INDICATOR	ON	Power mode	Control unit, mode switch, or wiring	
	OFF	Other modes		
*GEAR POSITION	1st	ON	1st gear position	—
		OFF	Other gear positions	
	2nd	ON	2nd gear position	
		OFF	Other gear positions	
	3rd	ON	3rd gear position	
		OFF	Other gear positions	
	OD	ON	OD gear position	
		OFF	Other gear positions	




1BU0K2-014

Note

* : Items should be checked with engine running or while driving.

MECHANICAL SYSTEM TEST

PREPARATION
SST

<p>49 0378 400A Gauge set, oil pressure</p> 	<p>49 H019 002 Adapter</p> 	<p>49 B019 901 Gauge, oil pressure</p> 
---	---	--







1BU0K2-015

STALL TEST

This test is performed to determine if there is slippage of the friction elements or malfunction of the hydraulic components.


Preparation

1. Check the engine coolant, engine oil, and ATF levels before testing.
2. Warm the engine thoroughly to raise the ATF temperature to operating level (60—70°C, 140—158°F).
3. Engage the parking brake and use wheel chocks at the front and rear of the wheels.

<p>ENGAGE PARKING BRAKE</p> 	<p>WARM UP ENGINE</p> 	<p>COOLANT LEVEL</p> 
 <p>WHEEL CHOCKS</p>		<p>ENGINE OIL LEVEL</p> 
		<p>ATF LEVEL</p> 

TEMPERATURE:
60—70°C (140—158°F)

Procedure



2BU0K2-007

1. Connect a tachometer to the engine.
2. Start the engine and check the idle speed in P range. (Refer to Section F2.)

Idle speed: 750—790 rpm

3. Shift the selector lever to R range.

Caution

Step 4 must be performed within 5 seconds to prevent possible transmission damage.

4. Firmly depress the foot brake with the left foot, and gently depress the accelerator pedal with the right foot.

Caution

Step 5 must be performed within 5 seconds to prevent possible transmission damage.

5. When the engine speed no longer increases, quickly read the engine speed and release the accelerator.

Caution

Idling for at least one minute is to cool the ATF and to prevent deterioration of the fluid.

6. Move the selector lever to N range and let the engine idle for at least one minute.

Caution

Be sure to allow sufficient cooling time between each stall test.

7. Perform the stall test for the following ranges in the same manner.
 (1) D range
 (2) S range
 (3) L range

Engine stall speed: 2,300—2,500 rpm

9MU0K1-047

Evaluation of Stall Test

Condition		Possible cause	
Above specification	In all ranges	Insufficient line pressure	Worn oil pump
			Oil leakage from oil pump, control valve, and/or transmission case
			Stuck pressure regulator valve
	In D and S ranges	Forward clutch slipping Forward one-way clutch slipping Low one-way clutch slipping	
	In R range	Low and reverse brake slipping Reverse clutch slipping Perform road test to determine whether problem is low and reverse brake or reverse clutch a) Engine brake applied in L range 1st ...Reverse clutch b) Engine brake not applied in L range 1st ...Low and reverse brake	
Within specification		All shift control elements within transmission are functioning normally	
Below specification		Engine out of tune	
		One-way clutch slipping within torque converter	

9MU0K1-048


TIME LAG TEST

If the selector lever is shifted while the engine is idling, there will be a certain time lapse, or time lag, before shock is felt. This step measures this time lag for checking conditions of the N-D, 1-2, and 3-4/N-R accumulators; forward, reverse, and one-way clutches; brake band; and low and reverse brake.

Preparation

Perform the preparation procedure shown in the STALL TEST. (Refer to page K2-23.)

Procedure



2BU0K2-006

1. Start the engine and check the idle speed on P range. (Refer to Section F2.)

Idle speed: 750—790 rpm

2. Shift from N range to D range.
3. Use a stop watch to measure the time it takes from shifting until shock is felt.

Caution

Idling for at least one minute is to cool the ATF and prevent deterioration of the fluid.

4. Shift the selector to N range and run the engine at idle speed for at least one minute.

Note

Make three measurements for each test and take the average value.

5. Perform the test for the following shifts in the same manner.
 - (1) N→D range
 - (2) N→D range (Hold mode)
 - (3) N→R range

Specified time lag: N→D range Less than 1.0 second
 N→R range Less than 1.2 second

Evaluation of Time Lag Test

Condition		Possible Cause
Above specification	N→D and N→D (Hold) shift	Insufficient line pressure Forward clutch slipping Forward one-way clutch slipping
	N→D shift	Insufficient line pressure Low one-way clutch slipping N-D accumulator not operating properly
	N→D (Hold) shift	Insufficient line pressure Brake band slipping 1-2 accumulator not operating properly
	N→R shift	Insufficient line pressure Reverse clutch slipping Low and reverse brake slipping 3-4/N-R accumulator not operating properly


9MU0K1-050

LINE PRESSURE TEST

This test measures line pressures for checking the hydraulic components and inspecting for oil leakage.

Preparation

1. Perform the preparation procedure shown in the STALL TEST. (Refer to page K2-23.)
2. Connect a tachometer to the engine.
3. Connect the **SST** to the line pressure inspection hole(s).

Procedure

2BU0K2-009

1. Start the engine and check the idle speed in P range. (Refer to Section F2.)

Idle speed: 750—790 rpm

2. Shift the selector lever to D range and read the line pressure at idle.

Caution

Step 3 must be performed within 5 seconds to prevent possible transmission damage.

3. Depress the brake pedal firmly with the left foot and gradually depress the accelerator pedal with the right foot.

Caution

Step 4 must be performed within 5 seconds to prevent possible transmission damage.

4. Read the line pressure as soon as the engine speed becomes constant, then release the accelerator pedal.

Caution

Idling for at least one minute is to cool the ATF and to prevent deterioration of the fluid.

5. Shift the selector lever to N range and run the engine at idle for at least one minute.
6. Read the line pressure at idle and at the engine stall speed for each range in the same manner.

Specified line pressure:

Range	Line pressure	
	Idle	Stall
D, S, L	432—471 (4.4—4.8, 63—68)	1,040—1,118 (10.6—11.4, 151—162)
R	598—638 (6.1—6.5, 87—92)	1,452—1,530 (14.8—15.6, 210—222)

0BU0K2-030

7. Install new plugs in the inspection ports.

Tightening torque: 4.9—9.8 N·m (50—100 cm·kg, 43—87 in·lb)

Evaluation of Line Pressure Test

Condition		Possible cause
When idling	Low pressure in every range	Worn oil pump Damaged control piston (in oil pump) Pressure regulator valve or plug sticking Damaged pressure regulator valve spring Fluid leaking between oil strainer and pressure regulator valve
	Low pressure in forward ranges	Fluid leaking from hydraulic circuit of forward clutch
	Low pressure in D and S ranges (Hold mode only)	Fluid leaking from hydraulic circuit of band servo 2nd apply side
	Low pressure in R range only	Fluid leaking from hydraulic circuit of reverse clutch
	Low pressure in R and L ranges only	Fluid leaking from hydraulic circuit of low and reverse brake
	Higher than specification	Throttle sensor out of adjustment Damaged fluid thermosensor Line pressure solenoid sticking Short circuit of line pressure solenoid circuit Pressure modifier valve sticking Pressure regulator valve or plug sticking
At stall speed	Low pressure	Throttle sensor out of adjustment Damaged control piston (in oil pump) Line pressure solenoid sticking Short circuit of line pressure solenoid circuit Pressure regulator valve or plug sticking Pressure modifier valve sticking Pilot valve sticking

9MU0K1-053

ROAD TEST

Caution

Perform the test at normal ATF operating temperature (60—70°C, 140—158°F).

This step is performed to inspect for problems in the various ranges. If these tests show any problems, refer to the electronic system component or mechanical sections to adjust or replace.

D RANGE TEST**Shift Point, Shift Pattern, and Shift Shock**

1. Shift the selector lever to D range.

Note

Throttle sensor voltage of the EC-AT Tester represents the throttle valve opening.

Driving mode (Economy or Power) is automatically changed corresponding to accelerator pedal depressing speed.

2. Accelerate the vehicle with half- and full-throttle opening.
3. Check that 1-2, 2-3, and 3-OD upshifts, downshifts, and lockup are obtained. The shift points must be as shown in the D range (Economy or Power) shift diagram.

Note

a) Vehicle speed of the EC-AT Tester and the speedometer and vehicle speed on a chassis roller may not meet the specified shift pattern because of incorrect tire size. Therefore, check the shift points with the VEHICLE SPEED of the EC-AT Tester.


b) There is no overdrive when the ATF temperature is below 10°C (50°F).

c) There is no overdrive when the cruise control is operating and there is an 8 km/h (13 mph) difference between the preset cruise speed and vehicle speed, or SET or RESUME switch is ON.


d) There is no overdrive when ATF temperature is below 40°C (104°F).

e) There is no lockup when the accelerator pedal is fully closed (Idle switch ON) while driving the vehicle below 120 km/h (74 mph).

4. Check the upshifts for shift shock or slippage in the same manner.
5. While driving in OD, shift the selector lever to S range and check that OD-3 downshift immediately occurs.

D range (Economy) shift diagram


D range (Power) shift diagram



0BU0K2-032

6. Select the Hold mode.
7. Accelerate the vehicle; check 2-3 up- and downshifts and lockup and that no 1st or OD is obtained. The 2-3 shift points are as shown in the D range (Hold) shift diagram.
8. Decelerate the vehicle and check that engine braking effect is felt in 3rd and 2nd gears when throttle opening less than 1/8.

D range (Hold) shift diagram



79G07C-094

Evaluation

Condition		Possible Cause
Shifting	Starts in 2nd or shifts directly from 1st to OD	Stuck shift solenoid A Stuck shift valve A
	Starts in OD	Stuck shift solenoid B Stuck shift valve B
	No shift	Stuck shift solenoid A and/or B Stuck shift valve A and/or B
	Incorrect shift points	Throttle sensor out of adjustment Speed sensor 1 not operating properly
Shift shock felt or slipping		Stuck line pressure solenoid Accumulators not operating properly Throttle sensor out of adjustment Speed sensor 1 not operating properly ATF thermosensor not operating properly Worn clutches, one-way clutches, and/or brakes
No engine braking		Stuck overrunning clutch solenoid Worn clutches, and/or brakes
No lockup shift		Stuck lockup solenoid Stuck lockup control valve

9MU0K1-056

Noise and Vibration

Drive the vehicle in OD (lockup), OD (no lockup), and 3rd (Hold) and check for abnormal noise or vibration.

Note

Abnormal noise and vibration can also be caused by the torque converter, propeller shaft, or differential. Therefore, check for the cause with extreme care.

Kickdown

Drive the vehicle in OD, 3rd, and 2nd gears and check that kickdown occurs for OD→3, OD→2, OD→1, 3→2, 3→1, 2→1, and that the shift points are as shown in the shift diagram. (Refer to pages K2-29, 30.)

1BU0K2-018

S RANGE TEST

Shift Pattern

1. Shift the selector lever to S range.
2. Accelerate the vehicle; check that 1-2 and 2-3 up- and downshifts, and lockup are obtained and that no OD is obtained.
3. Decelerate the vehicle and check that engine braking effect is felt in only 3rd and 2nd gear when throttle opening less than 1/8.


Note

- a) Inspections of shift shock and shift points are not necessary because these are the same as those of the D-range test.
- b) Shift points are the same as those of the D-range (Economy) shift diagram except 3↔OD.

1. While driving in S range (Economy mode) and 3rd gear, select the Hold mode and check that 3rd gear is held until the 3-2 downshift point is achieved as shown in the S range (Hold) shift diagram.
2. Accelerate the vehicle in S range (Hold mode) and check that 2nd gear is held.
3. Decelerate the vehicle and check that engine braking effect is felt when throttle opening less than 1/8.

S range (Hold) shift diagram

OBUOK2-034



79G07C-475

Noise and Vibration

Drive the vehicle in 2nd gear (Hold mode) and check for abnormal noise or vibration.

Note

Abnormal noise and vibration can also be caused by the torque converter, propeller shaft, or differential. Therefore, check for the cause with extreme care.

L RANGE TEST**Shift Pattern**


1. Shift the selector lever to L range.
2. Accelerate the vehicle and check that the 1-2 up- and downshifts are obtained and that no 3rd gear, over-drive, or lockup is obtained.

Note

a) Inspection of shift shock and shift points are not necessary because these are the same as those of the D-range test.

b) Shift points are the same as those of the D-range (Economy) shift diagram except 2↔3 and 3↔OD.

3. Decelerate the vehicle and check that engine braking effect is felt in 1st and 2nd gears.
4. While driving in D range (Hold mode) and 3rd gear, shift the selector lever to L range and check that 3rd gear is held until the 3-2 downshift point as shown in the L range (Hold) shift diagram is achieved, then that 2nd gear is held until 2-1 downshift point is achieved.
5. Accelerate the vehicle in L range (Hold mode) and check that 1st gear is held.
6. Decelerate the vehicle and check that engine braking effect is felt.

L range (Hold) shift diagram

0BU0K2-035

Noise and Vibration

Drive the vehicle in 1st gear (Hold mode) and check for abnormal noise or vibration.

Note

Abnormal noise and vibration can also be caused by the torque converter, propeller shaft or differential. Therefore, check for the cause with extreme care.

P RANGE TEST

1. Shift into P range on a gentle slope, release the brake, and check that the vehicle does not roll.
2. Shift into P range while driving the vehicle at **maximum of 4 km/h (2.5 mph)** on a level surface, and check that the vehicle stop.

9MU0K1-060

K2-33

Vehicle Speed at Shiftpoint Table

Mode	Range	Throttle condition (Throttle sensor voltage)	Shift	Vehicle speed km/h (mph)	
Normal (Power)	D	Fully opened (4.4 volt)	D ₁ →D ₂	47-51 (29-32)	
			D ₂ →D ₃	87-95 (54-59)	
			D ₃ →OD	129-139 (80-86)	
		Half throttle (1.6-2.2 volt)	D ₁ →D ₂	39-43 (24-27)	
			D ₂ →D ₃	66-72 (41-45)	
			Lockup ON (D ₃)	96-104 (60-64)	
	D ₃ →OD		111-119 (69-74)		
	Lockup ON (OD)		128-136 (79-84)		
	Lockup OFF (OD)		96-104 (60-64)		
	OD→D ₃		71-79 (44-49)		
	Lockup OFF (D ₃)	86-94 (53-58)			
	Normal (Economy)	D	Kickdown	D ₃ →D ₂	42-48 (26-30)
				OD→D ₃	124-134 (77-83)
				OD→D ₂	81-89 (50-55)
OD→D ₁				41-45 (25-28)	
D ₃ →D ₂				81-89 (50-55)	
D ₃ →D ₁				41-45 (25-28)	
Fully opened (4.4 volt)		Kickdown	D ₂ →D ₁	41-45 (25-28)	
			D ₁ →D ₂	47-51 (29-32)	
			D ₂ →D ₃	87-95 (54-59)	
			D ₃ →OD	129-139 (80-86)	
			D ₁ →D ₂	30-34 (19-21)	
			D ₂ →D ₃	52-58 (32-36)	
		Half throttle (1.6-2.2 volt)	D ₃ →OD	96-104 (60-64)	
			Lockup ON (OD)	96-104 (60-64)	
			Lockup OFF (OD)	81-89 (50-55)	
			OD→D ₃	43-51 (27-32)	
			D ₃ →D ₂	22-28 (14-17)	
			OD→D ₃	124-134 (77-83)	
Kickdown	OD→D ₂	81-89 (50-55)			
	OD→D ₁	41-45 (25-28)			
	D ₃ →D ₂	81-89 (50-55)			
	D ₃ →D ₁	41-45 (25-28)			
	D ₂ →D ₁	41-45 (25-28)			
	S ₁ →S ₂	47-51 (29-32)			
Normal	S	Fully opened (4.4 volt)	S ₂ →S ₃	87-95 (54-59)	
			S ₃ →S ₂	82-88 (51-55)	
			S ₂ →S ₁	41-45 (25-28)	
	Half throttle (1.6-2.2 volt)	S ₁ →S ₂	39-43 (24-27)		
		S ₂ →S ₃	66-72 (41-45)		
		S ₃ →S ₂	41-47 (25-29)		
Normal	L	Fully opened (4.4 volt)	L ₁ →L ₂	47-51 (29-32)	
			L ₂ →L ₁	41-45 (25-28)	
	Half throttle (1.6-2.2 volt)	L ₁ →L ₂	39-43 (24-27)		
HOLD	D	-	D ₂ →D ₃	18-22 (11-14)	
			D ₃ →D ₂	7-13 (4-8)	
	Fully closed (0.4 volt)	OD→D ₃	138-148 (86-92)		
		S ₃ →S ₂	88-96 (55-60)		
		L ₂ →L ₁	44-48 (27-30)		

ELECTRONIC SYSTEM COMPONENTS

HOLD OFF SWITCH

Inspection

Terminal voltage

1. Remove the selector lever knob.
2. Turn the ignition switch ON.
3. Check the voltage between terminal A and ground, and between terminal B and ground.

V_B: Battery voltage

Terminal	Terminal voltage
A and ground	0V
B and ground	V _B


4. If correct, check continuity between the terminals.
5. If not correct, check the wiring harness.

Continuity


1. Check continuity of the terminals.

Continuity	Switch
Yes	Released
No	Depressed


2. If not correct, replace the selector lever knob.
3. If not correct, replace the change knob as an assembly.




2BU0K2-010



9BU0KX-031



9MU0K1-066




9MU0K1-067

INHIBITOR SWITCH


Inspection

Operation


1. Check that the starter operates with the ignition switch at START position and the selector lever in P and N range only and that it does not operate in any other position.
2. Check that the back-up lights illuminate when shifted to the R range with the ignition switch in the ON position.
3. Check the inhibitor switch if it is not as specified.




0BU0K2-167




0BU0K2-038



2BU0K2-011



9MU0K1-071



9MU0K1-072

Continuity

1. Jack up the vehicle and support it with safety stands.
2. Disconnect the control linkage from the manual shaft.
3. Disconnect the inhibitor switch connector.
4. Check continuity of the terminals.

Position	Connector terminal								
	A	B	C	D	E	F	G	H	I
P	○—○		○—○						
R			○—○	○—○					
N	○—○		○—○		○—○				
D			○—○				○—○		
S			○—○					○—○	
L			○—○						○—○

○—○: Indicates continuity

5. If not correct, adjust the inhibitor switch.
6. If correct, check or adjust the selector lever.
(Refer to page K2-149.)

Adjustment

1. Move the manual shaft to N position.
2. Loosen the inhibitor switch mounting bolts.
3. Align the holes of the inhibitor switch and the manual shaft lever by inserting a an **approx. 4.0mm (0.157 in)** O.D. pin.
4. Tighten the mounting bolts.

Tightening torque:

2.5—3.9 N·m (25—40 cm·kg, 22—35 in·lb)

5. Recheck the continuity of the inhibitor switch.
6. If not correct, replace the inhibitor switch.

7. Connect the control linkage.


Tightening torque:

29—39 N·m (3.0—4.0 m·kg, 22—29 ft·lb)


ATF THERMOSENSOR

Inspection


1. Jack up the vehicle and support it with safety stands.
2. Loosen the oil pan mounting bolts, and drain the ATF into a suitable container.




1BU0K2-021




9MU0K1-074



1BU0K2-022



1BU0K2-023



9MU0K1-077

3. Remove the oil pan.
4. Remove the control valve body and solenoid connector. (Refer to page K2-124.)

5. Place the ATF thermosensor in water with a thermometer as shown and heat the water gradually.
6. Measure the resistance between the terminals. If necessary, replace the ATF thermosensor.

Water temperature	Resistance
20°C (68°F)	Approx. 2.5 kΩ
80°C (176°F)	Approx. 0.3 kΩ

7. Install the solenoid connector and control valve body. (Refer to page K2-126.)
8. Install the oil pan.

Tightening torque:

4.9—7.8 N·m (50—80 cm·kg, 43—69 in·lb)

9. Pour in ATF, and with the engine idling, check the ATF level and check for leaks. (Refer to page K2-42.)

SPEED SENSOR 1

Inspection

1. Jack up the vehicle and support it with safety stands.
2. Disconnect the connector.
3. Measure the resistance between the terminals.

Terminal	Resistance
A and B	504—616Ω
B and C	∞
A and C	∞

4. If not correct, replace the speed sensor 1.

Tightening torque:

4.9—6.9 N·m (50—70 cm·kg, 43—61 in·lb)

SOLENOID VALVES

Inspection

1. Jack up the vehicle and support it with safety stands.
2. Disconnect the connector.
3. Measure the resistance between the terminals.

Note

a) Terminal A: ATF thermoswitch

b) Terminal G, H: ATF thermosensor

Terminal	Connected to	Resistance
B	Shift solenoid A	20—40Ω
C	Shift solenoid B	20—40Ω
D	Overrunning clutch solenoid	20—40Ω
E	Line pressure solenoid	2.5—5Ω
F	Lockup solenoid	10—20Ω

4. If not correct, replace the solenoid or assembly.

Note

If shift solenoid A, shift solenoid B, overrunning clutch solenoid, or line pressure solenoid is not correct, replace as an assembly.

DROPPING RESISTOR

Inspection

1. Disconnect the dropping resistor connector.
2. Measure the resistance of the terminals.

Resistance: 10—14Ω


3. If not correct, replace the dropping resistor.

ATF THERMOSWITCH


Inspection

1. Drain the ATF. (Refer to ATF thermosensor inspection; page K2-36, Steps 1—3.)
2. Disconnect the connector, and remove the ATF thermoswitch.
3. Place the ATF thermoswitch in fluid with a thermometer shown and heat the fluid gradually.
4. Measure the continuity between terminal and bracket.


Fluid temperature	Continuity
Above 150°C (302°F)	Yes
Below 145°C (293°F)	No




9MU0K1-078




0BU0K2-042




9MU0K1-080



9MU0K1-081



1BU0K2-024




1BU0K2-025

5. If not correct, replace the ATF thermoswitch.
6. Install the ATF thermoswitch and connect the connector.

Tightening torque:

6.9—8.8 N·m (70—90 cm·kg, 61—78 In·lb)

7. Add ATF to the correct level. (Refer to ATF thermosensor inspection; page K2-36, Steps 8, 9.)



9MU0K1-082

EC-AT CONTROL UNIT

Inspection

1. Turn the ignition switch ON, and check the EC-AT control unit terminal voltage, referring to the Terminal Voltage Chart.
2. If not correct, check or replace the component(s), wiring, and/or EC-AT control unit.

Terminal Voltage Chart

2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1O	1M	1K	1I	1G	1E	1C	1A
2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1P	1N	1L	1J	1H	1F	1D	1B

9MU0K1-083

V_B: Battery voltage

Terminal	Connected to	Voltmeter		Voltage	Condition
		+ terminal	- terminal		
1A (Memory power)	Battery	1A	Ground	V _B	Constant
1B (Output)	Shift solenoid B	1B		V _B	Solenoid ON in following condition: • 1st and 2nd gear positions
				0V	Solenoid OFF in following condition: • 3rd and OD gear positions
1C	—	—	—	—	—
1D (Output)	Shift solenoid A	1D	Ground	V _B	Solenoid ON in following condition: • 1st and OD gear positions
				0V	Solenoid OFF in following condition: • 2nd and 3rd gear positions
1E (Input)	Inhibitor switch (R range)	1E	Ground	V _B	R range
				0V	Other ranges
1F (Output)	Line pressure solenoid	1F	Ground	1.7—4.5V	Accelerator pedal depressed (After ATF warm, engine stopped)
				Below 1.5V	Accelerator pedal fully released (After ATF warm, engine stopped)
1G (Input)	Engine rpm sensor*	1G	Ground	Above 1V (AC)	Engine running
				Below 0.5V (AC)	Engine stopped
1H (Output)	Dropping resistor	1H	Ground	V _B	Accelerator pedal fully released (After ATF warm, engine stopped)
				Below 1.5V	Accelerator pedal depressed (After ATF warm, engine stopped)
1I (Input)	Speed sensor 2	1I	Ground	Approx. 2—3V	While driving
				0V or 4.5—5.5V	Vehicle stopped
1J (Ground)	—	1J	Ground	0V	Constant
1K (Output)	Hold indicator	1K		V _B	Power or Economy mode
			0V	Hold mode	
1L (Ground)	—	1L	Ground	0V	Constant
1M (Output)	Lockup solenoid	1M		V _B	Solenoid ON, Lockup
			Below 1.5V	Solenoid OFF, Non-lockup	
1N (Battery power)	Battery	1N	Ground	V _B	Ignition switch ON
				0V	Ignition switch OFF
1O (Output)	Overrunning clutch solenoid	1O	Ground	V _B	Solenoid ON in following condition: • D range (Engine stopped)
				0V	Solenoid OFF in following condition: • Except D range (Engine stopped)
1P (Battery power)	Battery	1P	Ground	V _B	Ignition switch ON
				0V	Ignition switch OFF
2A (Input)	Throttle sensor	2A	2L	4.5—5.5V	Ignition switch ON
				0V	Ignition switch OFF
2B (Input)	Inhibitor switch (D range)	2B	Ground	V _B	D range
				0V	Other ranges
2C	—	—	—	—	—
2D (Input)	Inhibitor switch (N and P ranges)	2D	Ground	V _B	Except P or N ranges
				0V	P or N range
				Below 7V	P or N range and engine crank

* Checked with AC range

V_B: Battery voltage

Terminal	Connected to	Voltmeter		Voltage	Condition
		+ terminal	- terminal		
2E (Input)	Cruise control unit	2E	Ground	Above 6V	Normal conditions
				Below 1.5V	Set or Resume switch ON or vehicle speed 8 km/h (5 mph) lower than preset speed (Driving vehicle cruise control operation)
2F	—	—	—	—	—
2G	Engine control unit	2G	Ground	Above 6V	Normal condition
				Below 1.5V	Atmospheric pressure below 679 mmHg (26.73 inHg) which is approximately at 1,500 m (4,921 ft)
2H	—	—	—	—	—
2I (Input)	Hold switch	2I	Ground	Above 6V	Switch released
				0V	Switch depressed
2J (Input)	Speed sensor 1*	2J	Ground	Above 1V (AC)	Vehicle speed above 25 km/h (16 mph)
				Approx. 0V (AC)	Vehicle stopped
2K (Input)	EC-AT check connector	2K	Ground	Above 6V	Normal
				0V	Check connector grounded
2L (Ground)	Ground (For sensors)	2L	Ground	0V	Constant
2M (Input)	Idle switch	2M	Ground	V _B	Idle switch OFF (Throttle valve open)
				0V	Idle switch ON (Throttle valve fully closed)
2N (Output)	EC-AT Tester (Malfunction code)	2N	Ground	V _B	Normal (With EC-AT tester)
				0V	If malfunction present (With EC-AT tester)
				Code signal	EC-AT check connector grounded (With EC-AT tester)
2O	—	—	—	—	—
2P	—	—	—	—	—
2Q (Input)	Inhibitor switch (L range)	2Q	Ground	V _B	L range
				0V	Other ranges
2R (Input)	ATF thermosensor	2R	2L	Approx. 2.4—0.4V	While warming up ATF Note Approx. 1.8V: ATF temp. 10°C (50°F) Approx. 1.1V: ATF temp. 40°C (104°F)
2S (Input)	Inhibitor switch (S range)	2S	Ground	V _B	S range
				0V	Other ranges
2T (Input)	Throttle sensor	2T	2L	Approx. 0.5—4.3V	Throttle valve fully closed to fully open

* Checked with AC range

2BU0K2-012

AUTOMATIC TRANSMISSION FLUID (ATF)


INSPECTION

Level


Caution

Place the vehicle on a flat, level surface.


1. Apply the parking brake and position wheel chocks securely to prevent the vehicle from rolling.
2. Warm-up the engine until the ATF reaches **60—70°C (140—158°F)**.
3. While the engine is idling, shift the selector lever from P to L and back again.
4. Let the engine idle.
5. Shift the selector lever to P.



1BU0K1-027



79G07C-126



2BU0K2-013

6. Ensure that the ATF level is between the notches on the transmission level gauge. Add ATF to specification if necessary.


ATF type: Dexron® II or M-III

Condition

1. Check the ATF for discoloration.
2. Check the ATF for any unusual smell.

Note

- a) Determine whether or not the automatic transmission should be disassembled by observing the condition of the ATF carefully.
- b) If the ATF is muddy and varnished, it indicates burned drive plates.




79G07C-128


Fluid leaks

Check for fluid leaks of the transmission as shown below, repair or replace if necessary.


1. Gaskets, O-rings, and plugs
2. Oil hoses and oil pipes, and connections
3. Oil cooler(s)



9MU0K1-087



2BU0K2-014



2BU0K2-015

REPLACEMENT

1. Jack up the vehicle and support it with safety stands.

Warning

Be careful when draining; the ATF is hot.

2. Loosen the oil pan mounting bolts, and drain the ATF into a container.
3. Remove the oil pan and gasket.
4. Clean the oil pan and the magnet.

5. Install the oil pan along with a new gasket.

Tightening torque:

4.9—7.8 N·m (50—80 cm·kg, 43—69 in·lb)

6. Jack down the vehicle and add **approx. 4.0 liters (4.2 US qt, 3.5 Imp qt)** ATF.

Specified ATF: Dexron®II or M-III

7. Check the ATF level. (Refer to page K2-42.)

TRANSMISSION


TRANSMISSION UNIT (REMOVAL)

1. Disconnect the negative battery cable.
2. Jack up the vehicle and support it with safety stands.
3. Remove in the order shown in the figure, referring to **Removal Note**.

Caution


Do not turn the transmission over before removing the oil pan.

4. After removal, remove the oil pan to check condition of the transmission.



- 1. Selector knob
- 2. Console box
- 3. Insulator plate and boot
- 4. 4x4 shift lever
- 5. Under cover
- 6. Exhaust pipe
- 7. Rear propeller shaft
Service..... Section L
- 8. Front propeller shaft
Service..... Section L
- 9. Speedometer cable
- 10. Selector cable
- 11. No.2 cross member
Removal Note..... page K2-46
- 12. Under cover
- 13. Torque converter installation bolt
Removal Note..... page K2-46
- 14. Transmission installation bolt
- 15. Oil pipe connector and bracket
- 16. Cross member
Removal Note..... page K2-46
- 17. Connectors
- 18. Oil level gauge and pipe
- 19. Automatic transmission
- 20. Transmission mount


2BU0K2-017



OBU0K2-050


Removal note
No.2 cross member

1. Loosen the differential mounting bolts.



OBU0K2-051

2. Remove the cross member.




OBU0K2-052

Torque converter installation bolts

1. Hold the drive plate with the screwdriver.

2. Remove the torque converter installation bolts.



OBU0K2-054

Cross member





1. Support the transmission with the transmission jack.

2. Remove the cross member.

TRANSMISSION UNIT (DISASSEMBLY)

Preparation

SST

<p>49 0107 680A Engine stand</p>		<p>49 U019 0A0A Transmission hanger</p>	<p>49 H075 495B Body (Part of 49 U019 0A0A)</p> 
<p>49 U019 003 Holder (Part of 49 U019 0A0A)</p>		<p>49 0378 390 Puller, oil pump</p> 	<p>2BU0K2-018</p>

Precaution

General Notes:


1. Disassemble the transmission in a clean area (dustproof work space) to prevent entry of dust into the mechanisms.
2. Inspect the individual transmission components in accordance with the QUICK DIAGNOSIS CHART during disassembly.
3. Use only plastic hammers when applying force to separate the light alloy case joints.
4. Never use rags during disassembly; they may leave particles that can clog fluid passages.
5. Several parts resemble one another; organize them so that they do not get mixed up.
6. Disassemble the control valve assembly and thoroughly clean it when the clutch or brake band has burned or when the ATF has degenerated.

Cleaning Notes:

1. Clean the transmission exterior thoroughly with steam or cleaning solvents, or both, before disassembly.
2. Clean the removed parts with cleaning solvent, and dry with compressed air. Clean out all holes and passages with compressed air, and check that there are no obstructions.
3. Wear eye protection when using compressed air to clean components.

2BU0K2-019


Component



1BU0K2-031

- | | | |
|----------------------------|-----------------------------|----------------------------|
| 1. Transfer case | 5. Speed sensor 1 | 10. Control valve body |
| 2. Input sleeve | Inspection page K2-38 | Disassembly and Inspection |
| 3. Adapter case | 6. Torque converter | page K2-105 |
| Disassembly and Inspection | Inspection page K2-58 | Assembly page K2-123 |
| page K2-99 | 7. Oil pan | |
| Assembly page K2-100 | 8. Converter housing | |
| 4. Inhibitor switch | 9. Oil strainer | |
| Inspection page K2-36 | | |
| Adjustment... page K2-36 | | |

Components (cont'd)




1BU0K2-032

- 13. Input shaft
- 14. Oil pump
 - Disassembly and Inspection page K2-61
 - Assembly page K2-63
- 15. Brake band and strut
- 16. Reverse clutch
 - Disassembly and Inspection page K2-66
 - Assembly page K2-68
- 17. High clutch and front sun gear
 - Disassembly and Inspection page K2-72
 - Assembly page K2-74
- 18. Front planetary carrier
- 19. Rear sun gear

- 20. Snap ring
- 21. Parking gear and bearing
- 22. Snap ring
- 23. Output shaft
- 24. Front internal gear, rear internal gear, forward clutch hub, overrunning clutch hub
 - Disassembly and Inspection page K2-82
 - Assembly page K2-83
- 25. Forward clutch drum (forward clutch, overrunning clutch, low one-way clutch)
 - Disassembly and Inspection page K2-86
 - Assembly page K2-88

Components (cont'd)




1BU0K2-033



26. Accumulator spring and piston
Disassembly and Inspection
..... page K2-59
Assembly page K2-60

27. Band servo
Disassembly and Inspection
..... page K2-78
Assembly page K2-79


28. Low and reverse brake piston and spring
Disassembly and Inspection
..... page K2-95
Assembly page K2-96




1BU0K2-085



0BU0K2-059



0BU0K2-060



0BU0K2-061

Procedure

Caution

Keep the transmission oil-pan down so that any foreign material will remain in the pan.

1. Remove the transfer case. (Refer to Section J3.)
2. Place the transmission on wooden blocks under the converter housing and the extension housing.
3. Remove the oil pan and gasket.
Examine any material found in the pan or on the magnet to determine the condition of the transmission.
Clutch facing material Drive plate and brake band wear
Steel (magnet)..... Bearing, gear, and driven plate wear
Aluminum (nonmagnetic).... Bushings or cast aluminum parts wear
If large amounts of material are found, replace the torque converter and carefully check the transmission for the cause.
4. Install the oil pan with a few bolts to protect the valve body.

5. Remove the connector bracket from the transmission case.
6. Remove the inhibitor switch.

7. Remove the connector bracket from the extension housing.
8. Disconnect the harness from the harness bracket.


Caution

Do not damage the speed sensor.

9. Remove the speed sensor 1.
10. Remove the O-ring from the speed sensor 1.


Note

Be careful not to spill the ATF when removing the torque converter.




0BU0K2-062

11. Remove the torque converter.




0BU0K2-063

12. Assemble the **SST** as shown.



0BU0K2-064

13. Mount the transmission to the **SST**.
14. Remove the oil pan.



2BU0K2-020


15. Remove the adapter case and gasket.

Bolt length (Measured from below the head)

- Ⓐ: 30mm (1.181 in)
- Ⓑ: 45mm (1.772 in)
- Ⓒ: 50mm (1.969 in)


Caution

Do not damage the harness or connector.



0BU0K2-066


16. Remove the clip.
17. Disconnect the lockup solenoid connector.



2BU0K2-021

18. Disconnect the ATF thermosensor.

Bolt length (Measured from below the head):
45mm (1.772 In)




0BU0K2-068

19. Remove the oil strainer.


Bolt length (Measured from below the head):
50mm (1.969 In)

20. Remove the O-ring from the oil strainer.



0BU0K2-069

21. Separate the solenoid harness from the harness clip.




1BU0K2-035

22. Remove the bolts (A) and (B), and brackets shown in the figure.

Bolt length (Measured from below the head)

(A): 33mm (1.299 in)

(B): 45mm (1.772 In)




0BU0K2-071

Caution

Do not damage the harness or connector.

23. Remove the clip.
24. Disconnect the solenoid connectors.




0BU0K2-072

Caution

Do not remove the control valve body unless you also remove the oil pipes.

25. Remove the control valve body.




0BU0K2-073

Caution


Do not damage the solenoid connector.

26. Remove the solenoid connector from the transmission case.
27. Remove the O-ring from the solenoid connector.



0BU0K2-074

28. Remove the converter housing from the transmission case.




0BU0K2-075

29. Remove the O-rings from the converter housing.

Caution


Do not damage the converter housing.

30. Clean the sealing compound from the converter housing.




0BU0K2-086

45. Remove the bearing behind the transmission case.




0BU0K2-087

46. While pushing the output shaft forward in slightly, and remove the snap ring (front) from the output shaft.




0BU0K2-088

47. Pull out the output shaft.



0BU0K2-089


48. Remove the front internal gear (with rear planetary carrier).



0BU0K2-090

49. Remove the rear internal gear, forward clutch hub, and over-running clutch hub as an assembly.

50. Remove the forward clutch drum (forward clutch, overrunning clutch, low one-way clutch) from the transmission case.




0BU0K2-091

TORQUE CONVERTER

Inspection


1. Check the outside of the converter for damage and cracks, and replace the torque converter if there is any problem.
2. Check for rust on the pilot hub on the boss, and remove it completely if there is any.




9MU0K1-133

Washing inside the converter


1. Drain any ATF remaining in the converter.
2. Pour in solvent (**0.5 liter, 0.5 US qt, 0.4 Imp qt**).
3. Shake the converter to clean the inside. Pour out the solvent.
4. Pour in ATF.
5. Shake the converter to clean the inside. Pour out the ATF.




15U0KX-113




0BU0K2-076




0BU0K2-077



0BU0K2-078



0BU0K2-079



0BU0K2-080

Procedure

Caution

Keep the transmission oil-pan down so that any foreign material will remain in the pan.

1. Remove the transfer case. (Refer to Section J2.)
2. Place the transmission on wooden blocks under the converter housing and the extension housing.
3. Remove the oil pan and gasket.
Examine any material found in the pan or on the magnet to determine the condition of the transmission.
Clutch facing material..... Drive plate and brake band wear
Steel (magnet)..... Bearing, gear, and driven plate wear
Aluminum (nonmagnetic).... Bushings or cast aluminum parts wear
If large amounts of material are found, replace the torque converter and carefully check the transmission for the cause.
4. Install the oil pan with a few bolts to protect the valve body.

5. Remove the connector bracket from the transmission case.
6. Remove the inhibitor switch.

7. Remove the connector bracket from the extension housing.
8. Disconnect the harness from the harness bracket.

Caution


Do not damage the speed sensor.

9. Remove the speed sensor 1.
10. Remove the O-ring from the speed sensor 1.

Caution


To prevent the brake facing from cracking or peeling, do not stretch the brake band. Secure it with a wire clip.

40. Remove the brake band and the band strut.



0BU0K2-081

41. Remove the reverse clutch, high clutch, and the front sun gear from the transmission case as an assembly.



0BU0K2-082

42. Remove the front planetary carrier, bearings, and the rear sun gear.

Inspect the following parts, and repair or replace as necessary.

- 1) Front planetary carrier
Inspect individual gear teeth for damage, wear, or cracks, and rotation of pinion gears
- 2) Rear sun gear
Inspect individual gear teeth for damage, wear, or cracks
- 3) Bearing
Inspect for damage or rough rotation

REAR SUN GEAR

FRONT PLANETARY CARRIER

BEARING

FRONT SIDE


BEARING

REAR SIDE

FRONT PLANETARY CARRIER


0BU0K2-083

43. Remove the snap ring (rear) from the output shaft.



0BU0K2-084

44. Remove the parking gear.




0BU0K2-085

ACCUMULATORS


Disassembly and Inspection

Disassemble in the order shown in the figure, referring to **Disassembly Note**.
Inspect all parts, and repair or replace if necessary.



1BU0K2-036

- | | | |
|--|--|--------------------------------|
| 1. 3-4/N-R accumulator spring
Inspection page K2-60 | 4. N-D accumulator piston | 9. 1-2 accumulator piston |
| 2. 1-2 accumulator spring
Inspection page K2-60 | 5. O-rings | 10. O-rings |
| 3. 2-3 accumulator spring
Inspection page K2-60 | 6. N-D accumulator spring
Inspection page K2-60 | 11. 3-4/N-R accumulator piston |
| | 7. 2-3 accumulator piston | 12. O-rings |
| | 8. O-rings | 13. Transmission case |




9MU0K1-136


Disassembly note
Accumulator piston

Remove the accumulator pistons, and springs from transmission case by applying compressed air through the oil passage as shown in the figure.


Accumulator	Item	Location	Oil passage
N-D accumulator		A	a
2-3 accumulator		B	b
1-2 accumulator		C	c
3-4/N-R accumulators		D	d




1BU0K2-037



1BU0K2-038



9MU0K1-139



9MU0K1-140

Inspection Accumulator, spring

Measure the spring free length.

	Outer dia. mm (In)	Free length mm (In)	No. of coil	Wire dia. mm (In)
N-D accumulator piston	18.0 (0.709)	43.0 (1.693)	12.3	2.3 (0.091)
1-2 accumulator piston	29.3 (1.154)	45.0 (1.772)	3.6	4.0 (0.157)
2-3 accumulator piston	20.0 (0.787)	66.0 (2.598)	11.4	3.5 (0.138)
3-4/N-R accumulators piston	17.3 (0.681)	58.4 (2.299)	12.3	2.3 (0.091)

If not within specification, replace the spring.

Assembly

Note

Installation order

N-D accumulator: Spring — Piston

2-3 accumulator: Piston — Spring

1-2 accumulator: Piston — Spring

3-4/N-R accumulators: Piston — Spring

Outer diameter of spring

Spring	Outer dia. mm (In)
a N-D accumulator	18.0 (0.709)
b 2-3 accumulator	20.0 (0.787)
c 1-2 accumulator	29.3 (1.154)
d 3-4/N-R accumulators	17.3 (0.681)


Apply even pressure to the perimeter of the accumulator pistons to avoid damaging the O-rings when installing.

1. Apply ATF to the new O-rings and install them on to the accumulator pistons.

Piston	O-ring	mm (In)	
		Large	Small
A N-D accumulator		45.0 (1.772)	29.0 (1.142)
B 2-3 accumulator		50.0 (1.969)	32.0 (1.260)
C 1-2 accumulator		50.0 (1.969)	45.0 (1.772)
D 3-4/N-R accumulators		45.0 (1.772)	29.0 (1.142)

2. Install the accumulator pistons and springs.


**OIL PUMP
Preparation
SST**

49 G030 795 Installer, oil seal		49 G030 796 Body (Parts of 49 G030 795)	49 G030 797 Handle (Parts of 49 G030 795)
---	---	--	--

9MU0K1-486


Disassembly and Inspection

Disassemble in the order shown in the figure, referring to **Disassembly Note**.
 Inspect all parts, and repair or replace as necessary.



1BU0K2-039

- | | |
|---|---|
| <ul style="list-style-type: none"> 1. Bearing
 Inspect for damage or rough rotation 2. Oil pump cover
 Disassembly Note page K2-62
 Inspection page K2-62 3. Seal ring (small diameter) 4. Seal ring (large diameter) 5. Seal ring 6. Vane ring 7. Rotor
 Disassembly Note page K2-62
 Inspection page K2-63 8. Vane
 Inspection page K2-63 9. Vane ring 10. Pivot pin
 Disassembly Note page K2-62 | <ul style="list-style-type: none"> 11. Cam ring
 Disassembly Note page K2-62
 Inspection page K2-63 12. Spring
 Inspection page K2-63 13. Spring seat 14. Friction ring 15. O-Ring 16. Pivot pin 17. Control piston
 Inspection page K2-63 18. Side seal 19. Oil pump housing
 Inspection page K2-63 20. Oil seal |
|---|---|




9MU0K1-142

Disassembly note

Oil pump cover

Loosen the mounting bolts evenly in the pattern shown and remove the oil pump cover from the oil pump housing.




9MU0K1-143

Rotor

Caution

Do not use a punch to mark the rotor.

Mark the rotor and cam ring; then separate the rotor and vanes from the cam ring.




9MU0K1-144

Pivot pin

Caution

Do not scratch the oil pump housing.

1. Wrap a screwdriver with tape.
2. While pushing on the cam ring, remove the pivot pin.



9MU0K1-145


Cam ring

Caution

a) Do not to scratch the oil pump housing.

b) Hold the cam ring spring to prevent it from popping out.

Remove the cam ring and cam ring spring.



9MU0K1-147

Inspection

Oil pump cover


1. Apply petroleum jelly to new seal ring.
2. Measure the clearance between the seal ring and the ring groove.

Standard clearance:

0.10—0.25mm (0.0039—0.0098 In)

Maximum clearance: 0.25mm (0.0098 In)

3. If not within specification, replace the oil pump as an assembly.



9MUOK1-146

Oil pump housing, cam ring, rotor, vane, and control piston

Note

Do not install the friction ring, O-ring, control piston side seals, or cam ring spring.


1. Install the cam ring vanes, rotor and control piston.
2. Measure the clearance between the end of the oil pump housing and cam ring, rotor, vanes and control piston in at least four places along their circumferences.

Clearance

mm (in)

Port	Clearance	Standard	Maximum
Cam ring		0.010—0.024 (0.0004—0.009)	0.030 (0.0012)
Rotor, vane, control piston		0.030—0.044 (0.0012—0.0017)	0.050 (0.0020)

3. If not within specification, replace the oil pump as an assembly.



9MUOK1-487


Cam ring spring

1. Measure the spring specification.

Specification

Outer dia. mm (In)	Free length mm (In)	No. of coil	Wire dia. mm (In)
13.7 (0.539)	39.8 (1.567)	7.8	2.3 (0.091)


2. If not correct, replace the cam ring spring.



9MUOK1-148


Assembly

1. Apply ATF to the new oil seal. Install the oil seal with the **SST**.



9MUOK1-149

2. Apply ATF to side seal, and install them on the control piston with the black surface facing toward the control piston.
3. Install the control piston and pivot pin.




9MU0K1-151

4. Apply petroleum jelly to the cam ring groove and install a new O-ring and friction ring into the cam ring.
5. Install the cam ring and spring while compressing the spring against the oil pump housing.


Caution

Do not scratch the oil pump housing.



9MU0K1-152

6. Wrap a screwdriver with tape.
7. While pushing on the cam ring, install the pivot pin.




9MU0K1-153

8. Confirm the marks and install the rotor, vanes, and vane rings.

Caution

Do not damage the oil seal with the splines of the oil pump cover.



9MU0K1-154

9. Install the oil pump cover onto the oil pump housing.
10. Tighten the bolts evenly and gradually in the order shown.

Tightening torque:

16—21 N·m (1.6—2.1 m·kg, 12—15 ft·lb)

Caution


Do not overexpand the seal rings when installing.

Note

- a) Press the seal rings down into the petroleum jelly to hold them.
- b) Seal rings come in two different diameters.


Small dia seal ring: No mark

Large dia seal ring: Yellow mark in area shown by arrow



9MU0K1-499

11. Put petroleum jelly into the ring grooves, and install the new seal rings.
12. Apply ATF to a new O-ring, and install it on the oil pump.




9MU0K1-157

13. Apply petroleum jelly to the bearing, and set it on the oil pump.

Bearing outer diameter: 47.0mm (1.850 in)

**REVERSE CLUTCH
Preparation
SST**

<p>49 G019 0A7A Compressor set, return spring</p>		<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p>	<p>49 G019 026 Plate (Part of 49 G019 0A7A)</p>
<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p>		<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p>	<p>2BU0K2-022</p>



9MU0K1-159

Preinspection

Reverse clutch operation

1. Install the reverse clutch onto the oil pump along with the seal rings. Apply compressed air to the oil passage as shown.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.


2. Verify that the retaining plate moves to the snap ring. If not, the D-ring or the oil seal may be damaged or fluid may be leaking at the piston check ball. Inspect them and replace when assembling.

Clearance between retaining plate and snap ring

Measure the clearance between the retaining plate and the snap ring.

Standard clearance: 0.50—1.20mm (0.020—0.047 in)


Select the correct retaining plate when assembling.



9MU0K1-160


Disassembly and Inspection

Disassemble in the order shown in the figure, referring to **Disassembly Note**.
 Inspect all parts and repair or replace as necessary.




2BU0K2-023


- | | |
|-----------------------------------|--|
| 1. Snap ring | 7. Return spring |
| 2. Retaining plate | Inspection page K2-67 |
| 3. Drive plates and driven plates | 8. Clutch piston |
| Inspect for wear or burning | Inspect balls for sticking by shaking piston |
| Inspection page K2-67 | Disassembly Note page K2-67 |
| 4. Dished plate | Inspection page K2-67 |
| 5. Snap ring | 9. Seal ring |
| Disassembly Note page K2-67 | 10. D-ring |
| 6. Spring retainer | 11. Reverse clutch drum |




9MUOK1-162




9MUOK1-163



9MUOK1-164



9MUOK1-165



9MUOK1-166

Disassembly note
Snap ring

Caution

- a) **Depress the spring retainer only enough to remove the snap ring.**
- b) **Do not damage the snap ring.**

1. Compress the spring with the **SST**, then remove the snap ring with snap ring pliers.
2. Remove the spring retainer and spring.

Piston

1. Install the reverse clutch onto the oil pump along with the seal rings.
2. Remove the piston by applying compressed air to the oil passage.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

Inspection

Drive plates

1. Measure the facing thickness in three places, and determine the average of the three readings.

Standard thickness: 2.0mm (0.079 in)
Minimum thickness: 1.8mm(0.071 in)

2. If not within specification, replace the drive plates.

Return spring

1. Measure the spring specifications.

Specification

Outer dia. mm (in)	Free length mm (in)	No. of coil	Wire dia. mm (in)
11.6 (0.457)	19.69 (0.775)	4.0	1.3 (0.051)

2. If not within specification, replace the return spring.

Clutch piston

1. Verify that there is no air leakage when applying Compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

Assembly

1. Apply ATF to the new D-ring and install it into the clutch piston.

2. Apply ATF to the new seal ring and install it into the clutch piston.

3. Apply ATF to the inner surface of the reverse clutch drum.

Caution

Apply even pressure to the perimeter of the clutch piston to avoid damaging the seal ring and D-ring when installing.

4. Install the clutch piston in the reverse clutch drum by turning it evenly and gradually.


5. Install the return springs and spring retainer.

Caution


a) Depress the spring retainer only enough to install the snap ring.

b) Do not overexpand the snap ring when installing.


c) Do not align the snap ring end-gap with the spring retainer.




9MU0K1-167




9MU0K1-168




9MU0K1-169




9MU0K1-170




9MU0K1-171




9MU0K1-488




9MU0K1-172



9MU0K1-173



9MU0K1-174



9MU0K1-175

6. Install the snap ring while compressing the springs with the **SST**.

7. Install the dished plate as shown in the figure.

Note

Installation order: Driven-Drive-Driven-Drive

8. Apply ATF to the drive plates and driven plates, and install them into the reverse clutch drum.

9. Install the retaining plate.

Caution

Do not deform the snap ring.

10. Install the snap ring.

11. Measure the clearance between the retaining plate and snap ring with a feeler gauge. If not within specification, adjust the clearance by installing the correct retaining plate.


Standard clearance:

0.50—1.20mm (0.020—0.047 in)

Retaining plate sizes

mm (in)

4.6 (0.181)	4.8 (0.189)	5.0 (0.197)	5.2 (0.205)
5.4 (0.213)	5.6 (0.220)	5.8 (0.228)	



9MU0K1-176

12. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining plate.

Standard Clearance: 0.50—0.80mm (0.020—0.031 in)

Retaining plate sizes

mm (in)


4.6 (0.185)	4.8 (0.189)	5.0 (0.197)	5.2 (0.205)
5.4 (0.213)	5.6 (0.220)	5.8 (0.228)	

Caution

Apply air for no more than 3 seconds.

13. Install the reverse clutch on to the oil pump along with the seal rings. Apply compressed air to the oil passage and check the clutch operation.





Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.




9MU0K1-177

HIGH CLUTCH AND FRONT SUN GEAR

**Preparation
SST**

<p>49 G019 0A7A Compressor set, return spring</p>		<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p>	<p>49 G019 026 Plate (Part of 49 G019 0A7A)</p> 
<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p>		<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p> 	<p>2BU0K2-024</p>



9MU0K1-179

**Preinspection
High clutch operation**

1. Install the high clutch onto the oil pump along with the seal rings. Apply compressed air to the oil passage as shown.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.


2. Verify that the retaining plate moves toward the snap ring. If not, the D-ring may be damaged or fluid may be leaking at the piston check ball. Inspect them and replace when assembling.

Clearance between retaining plate and snap ring

Measure the clearance between the retaining plate and the snap ring.

Standard clearance: 1.8—3.0mm (0.071—0.118 In)


Select and install the correct retaining plate when assembling.



9MU0K1-180


Disassembly and Inspection

Disassemble in the order shown in the figure, referring to **Disassembly Note**.
Inspect all parts, and repair or replace as necessary.




1BU0K2-041


- | | |
|---|--|
| <p>1. Front sun gear
Inspect individual gear teeth for damage, wear, or cracks</p> <p>2. Bearing race
Inspect bearing surface for scoring or scratches</p> <p>3. Bearing
Inspect for damage or rough rotation</p> <p>4. High clutch hub</p> <p>5. Bearing
Inspect for damage or rough rotation</p> <p>6. Bearing race
Inspect bearing surface for scoring or scratches</p> <p>7. Snap ring</p> <p>8. Retaining plate</p> <p>9. Drive plates and driven plates
Inspect for wear or burning
Inspection page K2-73</p> | <p>10. Snap ring
Inspect for fracture or wear
Disassembly Note page K2-73</p> <p>11. Spring retainer
Inspect for deformation or wear</p> <p>12. Return spring
Inspection page K2-73</p> <p>13. Clutch piston
Inspect balls for sticking by shaking the piston
Disassembly Note page K2-73
Inspection page K2-73</p> <p>14. D-ring</p> <p>15. D-ring</p> <p>16. Bearing race
Inspect bearing surface for scoring or scratches</p> <p>17. High clutch drum</p> |
|---|--|




9MU0K1-182




9MU0K1-183



9MU0K1-184



1BU0K2-042



9MU0K1-186

Disassembly note
Snap ring

Caution

- a) **Depress the spring retainer only enough to remove the snap ring.**
- b) **Do not damage the snap ring.**

1. Compress the spring with the **SST**, then remove the snap ring with snap ring pliers.
2. Remove the spring retainer and spring.

Piston

1. Install the high clutch onto the oil pump along with the seal rings.
2. Remove the piston by applying compressed air through the oil passage.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

Inspection

Drive plates

1. Measure the facing thickness in three places, and determine the average of the three reading.

Standard thickness: 1.6mm (0.063 in)
Minimum thickness: 1.4mm (0.055 in)

2. If not within specification, replace the drive plates.

Return spring

1. Check the spring specifications.

Specifications

Outer dia. mm (in)	Free length mm (in)	No. of coils	Wire dia. mm (in)
11.6 (0.457)	22.1 (0.870)	6.0	1.3 (0.051)

2. If not within specification, replace the return spring.


Clutch piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.


Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

Assembly High clutch

1. Apply ATF to the new D-rings and install them into the clutch piston.



RETURN SPRING SIDE



CLUTCH DRUM SIDE


9MU0K1-187

2. Apply ATF to the inner surface of the high clutch drum.

Caution


Apply even pressure to the perimeter of the clutch piston to avoid damaging the D-rings when installing.

3. Install the clutch piston in the high clutch drum by turning it evenly and gradually.



9MU0K1-188

4. Install the return springs and spring retainer.




9MU0K1-189

Caution

a) Depress the spring retainer only enough to install the snap ring.

b) Do not over expand the snap ring when installing.

c) Do not align the snap ring end-gap with the spring retainer stop.



STOPPER


SNAP RING

9MU0K1-190

5. Install the snap ring while compressing the springs with the SST.

49 G019 029


49 G019 026




49 G019 025

49 G019 027


9MU0K1-489




9MU0K1-191




9MU0K1-192



9MU0K1-193



9MU0K1-194



9MU0K1-195

6. Install the dished plate as shown in the figure.

Note

Installation order:

Driven-Drive-Driven-Drive-Drive-Driven-Drive-Driven-Driven-Drive

7. Apply ATF to the drive plates and driven plates, and install them into the high clutch drum.

8. Install the retaining plate.

Caution

Do not deform the snap ring.

9. Install the snap ring.

10. Measure the clearance between the retaining plate and the snap ring with a feeler gauge. If not within specification adjust the clearance by installing the correct retaining plate.

Standard clearance: 1.8—3.0mm (0.071—0.118 in)

Retaining plate sizes

mm (in)

3.0 (0.118)	3.2 (0.126)	3.4 (0.134)	3.6 (0.142)
3.8 (0.150)	4.0 (0.157)	4.2 (0.165)	4.4 (0.173)

11. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining plate.

Standard clearance: 1.8—2.2mm (0.071—0.087 in)

Retaining plate sizes

mm (in)


3.0 (0.118)	3.2 (0.126)	3.4 (0.134)	3.6 (0.142)
3.8 (0.150)	4.0 (0.157)	4.2 (0.165)	4.4 (0.173)

Caution

Apply air for no more than 3 seconds.

12. Install the high clutch onto the oil pump along with the seal rings. Apply compressed air to the oil passage and check the clutch operation.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.




9MU0K1-196

13. Apply petroleum jelly to the bearing races and install them in the high clutch as shown.

Bearing race outer diameter

Front side: 43.5mm (1.713 in)

Rear side : 51.5mm (2.028 in)




9MU0K1-197

14. Apply petroleum jelly to the bearing and install it in the high clutch hub.

Bearing outer diameter: 53.0mm (2.087 in)

15. Apply ATF to the high clutch hub, and install it in the high clutch by turning it evenly and gradually.




9MU0K1-198

Front sun gear

Apply petroleum jelly to the bearing and bearing race, and install them to the front sun gear.

Bearing outer diameter : 53.0mm (2.087 in)

Bearing race outer diameter: 75.0mm (2.953 in)



9MU0K1-199


MEMO

BAND SERVO Preinspection Band servo

1. Apply compressed air to the oil passage as shown.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.


2. Verify that the piston stem moves to the brake band.
If not the D-ring or the oil seal may be damaged or fluid may be sticking at the piston assembly.
Inspect them, and replace when assembling.




9MUOK1-490

Disassembly and Inspection

Disassemble in the order shown in the figure, referring to **Disassembly Note**.
Inspect all parts, and repair or replace as necessary.



- | | | |
|--------------------------------------|--|--------------------------------------|
| 1. Locknut | 9. Piston assembly and servo piston retainer | 17. D-ring |
| 2. Anchor end bolt | 10. Retaining ring (small) | 18. Servo piston retainer |
| 3. Band strut | 11. Spring retainer | Disassembly Note
..... page K2-79 |
| 4. Brake band | 12. Return spring C | 19. O-ring |
| 5. Band servo retainer | Inspection page K2-79 | 20. Return spring B |
| 6. Gasket | 13. Piston stem | Inspection page K2-79 |
| 7. OD band servo piston | 14. Retaining ring (large) | 21. Return spring A |
| Disassembly Note
..... page K2-79 | 15. Servo cushion retainer | Inspection page K2-79 |
| 8. D-ring | 16. Band servo piston | 1BU0K2-043 |




9MU0K1-201

Disassembly note

Piston assembly and servo piston retainer

Apply compressed air to the oil hole in the transmission case to remove the piston assembly and servo piston retainer from the transmission case.


Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.



9MU0K1-202

OD band servo piston

1. Block one oil hole OD servo piston retainer and the center hole in the OD band servo piston.
2. Apply compressed air to the other oil hole in the OD servo piston retainer to remove OD band servo piston from.
3. Remove the D-ring from the OD band servo piston.



1BU0K2-044

Inspection

Return spring

1. Measure the spring specifications.


Specifications

	Outer dia. mm (In)	Free length mm (In)	No. of coil	Wire dia. mm (In)
Return A	40.3 (1.587)	53.8 (2.118)	3.0	2.3 (0.091)
Return B	34.3 (1.350)	45.6 (1.795)	3.0	2.3 (0.091)
Return C	27.6 (1.087)	29.7 (1.169)	3.2	2.6 (0.102)

2. If not within specification, replace the return spring.

Assembly

1. Apply ATF to the new O-rings and install them onto the servo piston retainer.
2. Apply ATF to the new D-rings and install them onto the band servo piston.




9MU0K1-204

Caution

Do not deform the retaining ring.

3. Apply ATF to the servo cushion spring retainer, and retaining ring, and assemble them in the band servo piston.




9MU0K1-205

4. Apply ATF to the piston stem return spring, and spring retainer, and assemble them in the band servo piston.

Caution

Do not deform the retaining ring.

5. Install the retaining ring.




1BU0K2-045

Caution


Apply even pressure to the perimeter of the piston to avoid damaging the O-rings and D-rings when installing.

6. Apply ATF to the band servo piston, and install it onto the servo piston retainer.



1BU0K2-046

7. Apply ATF to the new D-ring, and install it onto the OD band servo piston.




9MU0K1-208


Caution

Apply even pressure to the perimeter of the piston to avoid damaging the D-ring when installing.

8. Apply ATF to the OD band servo piston, and install it into the band servo retainer.



9MU0K1-209




9MU0K1-210

9. Install return springs A and B.

Caution


Apply even pressure to the perimeter of the body to avoid damaging the O-rings when installing.

10. Apply ATF to the piston assembly, and install it into the transmission case.



9MU0K1-211

11. Apply ATF to the band servo retainer and a new gasket, and install them on the transmission case.




9MU0K1-212

12. Tighten the bolts evenly and gradually in the order shown.


Tightening torque:


6.9—8.8 N·m (70—90 cm·kg, 61—78 in·lb)



9MU0K1-213

13. Check the servo piston operation by applying compressed air through the oil holes.





9MU0K1-492

FRONT INTERNAL GEAR, REAR INTERNAL GEAR, FORWARD CLUTCH HUB, OVERRUNNING CLUTCH HUB Preinspection

Forward one-way clutch operation


While holding the forward clutch hub, check that the rear internal gear rotate smoothly when turned clockwise and lock when turned counterclockwise.

If not, replace the one-way clutch.

Disassembly and Inspection

Disassemble in the order shown in the figure.

Inspect all parts, and repair or replace if necessary.




9MU0K1-493

1. Front internal gear (with rear planetary carrier)
Inspect individual gear teeth for damage, wear, or cracks, and rotation of pinion gears
2. Bearing race
Inspect for bearing surface scoring or scratches


3. Bearing
Inspect for damage or rough rotation
4. Rear internal gear
Inspect individual gear teeth for damage, wear, or cracks
5. Thrust washer

6. Bearing
Inspect for damage or rough rotation
7. Overrunning clutch hub
8. Thrust washer
9. Snap ring
10. Forward one-way clutch
Inspection page K2-82
11. Snap ring
12. Forward clutch hub


1BU0K2-047




9MU0K1-215



9MU0K1-216



9MU0K1-217



9MU0K1-218

Assembly

Caution

- a) Do not deform the snap ring.
- b) Install the side indicated by an arrow in the figure toward the front when inserting the one-way clutch into the one-way clutch outer race.

1. Install the snap ring into the forward clutch hub.
2. Apply ATF to the forward one-way clutch. Install it in the forward clutch hub and the snap ring.

Note

Be sure the locating tabs of the thrust washer are set into the holes in the rear internal gear.

3. Apply petroleum jelly to the thrust washer and set it on the rear internal gear.

4. Apply ATF to the rear internal gear, and install it in the forward clutch hub by turning it evenly and gradually.

Note

If it turns counterclockwise, the one-way clutch is installed upside down.

5. While holding the forward clutch hub, check the forward one-way clutch operation by turning right and left. It should turn clockwise only and locked counterclockwise.


6. Apply petroleum jelly to the bearing, and install it on the rear internal gear.

Bearing outer diameter: 78.0mm (3.071 in)

Note


Be sure the locating tabs of the thrust washer are set into the holes in the overrunning clutch hub.

7. Apply petroleum jelly to the thrust washer, and set it in the overrunning clutch hub.



9MU0K1-219


8. Set the overrunning clutch hub on the rear internal gear.



9MU0K1-220

9. Apply petroleum jelly to the bearing, and set it on the overrunning clutch hub.


Bearing outer diameter: 59.0mm (2.322 in)



9MU0K1-221

10. Apply petroleum jelly to the bearing race, and set it on the front internal gear.







Bearing race outer diameter: 75.0mm (2.953 in)




9MU0K1-222

**FORWARD CLUTCH DRUM
(FORWARD CLUTCH, OVERRUNNING CLUTCH, LOW ONE-WAY CLUTCH)**


**Preparation
SST**

<p>49 G019 0A7A Compressor set, return spring</p>		<p>49 G019 025 Body B (Part of 49 G019 0A7A)</p>		<p>49 G019 026 Plate (Part of 49 G019 0A7A)</p>	
<p>49 G019 027 Attachment A (Part of 49 G019 0A7A)</p>		<p>49 G019 029 Nut (Part of 49 G019 0A7A)</p>		<p>49 L019 001 Bolts</p>	


2BU0K2-025



9MU0K1-494



9MU0K1-224



0BU0K2-188

Preinspection

Low one-way clutch operation

Install the forward clutch drum into the transmission case, check that the forward clutch drum rotate smoothly when turned clockwise and lock when turned counterclockwise. If not, replace the one-way clutch.

Forward clutch and overrunning clutch operation

1. Install the forward clutch drum and low one-way clutch inner race into the transmission case. Apply compressed air through the oil passage as shown.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

2. Verify that the retaining plates move toward the snap ring. If not, the D-ring or the seal ring may be damaged or fluid may be leaking at the piston check ball. Inspect the parts, and replace if necessary when assembling.

Clearance between retaining plate and snap ring

Measure the clearance between the retaining plate and the snap ring of the forward clutch and the overrunning clutch.

Standard clearance


Forward clutch : 0.45—2.05mm (0.18—0.081 in)

Overrunning clutch: 1.0—2.0mm (0.039—0.079 in)

Select the correct retaining plate when assembling if not within specification.

Disassembly and Inspection


Disassemble in the order shown in the figure, referring to **Disassembly Note**.
Inspect all parts, and repair or replace if necessary.




- 1. Snap ring
- 2. Snap ring
- 3. Retaining plate
- 4. Drive plates and driven plates
Inspect for wear or burning
Inspection page K2-88
- 5. Dished plate
- 6. Snap ring
- 7. Retaining plate
- 8. Drive plates and driven plates
Inspect for wear or burning
Inspection page K2-88
- 9. Dished plate
- 10. Snap ring
Disassembly Note page K2-87
- 11. Spring retainer
- 12. Return spring
Inspection page K2-88

- 13. Forward clutch piston
Disassembly Note page K2-87
- 14. Seal ring
- 15. D-ring
- 16. Overrunning clutch piston
Inspect balls for sticking by shaking piston
Disassembly Note page K2-87
Inspection page K2-88
- 17. Seal ring
- 18. D-ring
- 19. Snap ring
- 20. Side plate
- 21. Low one-way clutch
Inspection page K2-85
- 22. Snap ring
- 23. Bearing (radial bearing)
Inspect for damage or rough rotation
- 24. Forward clutch drum
Inspection page K2-88


2BU0K2-026



9MU0K1-227



9MU0K1-228



9MU0K1-229

Disassembly note

Snap ring

- 1. Assemble the **SST**.

Caution

- a) **Depress the spring retainer only enough to remove the snap ring.**
- b) **Do not damage the snap ring.**


- 2. Compress the springs with the **SST**, then remove the snap ring with snap ring pliers.
- 3. Remove the spring retainer and springs.

Piston

- 1. Set the forward clutch drum in the transmission case.
- 2. Remove the piston by applying compressed air through the oil passage.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

- 3. Remove the overrunning clutch piston from the forward clutch piston.




9MU0K1-230

Inspection Drive plates

1. Measure the facing thickness in three places, and determine the average of the three reading.

Standard thickness: 2.0mm (0.079 in)
Minimum thickness: 1.8mm (0.071 in)

2. If not within specification, replace the drive plates.



9MU0K1-231


Return spring

1. Measure the spring specifications.

Specifications

Outer dia. mm (in)	Free length mm (in)	No. of coils	Wire dia. mm (in)
9.7 (0.382)	35.8 (1.409)	10.3	1.3 (0.051)

2. If not within specification, replace the spring.




9MU0K1-232

Clutch piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on return spring side.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.




9MU0K1-233

Forward clutch drum

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the low and reverse brake.
2. Verify that there is air flow when applying compressed air through the oil hole on the low and reverse brake side.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.



9MU0K1-234


Assembly

1. Apply ATF to the bearing, and install it into the forward clutch drum.


Caution

- a) Do not scratch the forward clutch inner surface when fixing the low one-way clutch.
- b) Do not deform the snap ring.


2. Install the snap ring.




9MU0K1-235




9MU0K1-236



9MU0K1-237



1BU0K2-049



9MU0K1-239

Caution
Install the low one-way clutch with the flange facing outward.

3. Apply ATF to the low one-way clutch, and install it in the forward clutch drum.

Caution
Do not deform the snap ring.


4. Apply ATF to the side plate and snap ring, and install them into the forward clutch drum.

5. Apply ATF to the new D-ring and seal ring, and install them into the forward clutch as shown.

6. Apply ATF to the new D-ring and install them into the overrunning clutch piston as shown.

Caution
Apply even pressure to the perimeter of the piston to avoid damaging the seal ring, and D-ring when installing.

7. Apply ATF to the inner surface of the forward clutch drum and overrunning clutch piston.
8. Install the overrunning clutch piston in the forward clutch drum by turning it evenly and gradually. Align the notches in forward clutch piston with the grooves in forward clutch drum.




9MU0K1-240

Caution


Apply even pressure to the perimeter of the piston to avoid damaging the D-ring and the seal ring when installing.

- 9. Apply ATF to the inner surface of the forward clutch piston and overrunning clutch piston.
- 10. Install the overrunning clutch piston in the forward clutch piston by turning it evenly and gradually.



9MU0K1-241

- 11. Install the springs and spring retainer.




9MU0K1-242

Caution

- a) Depress the spring retainer only enough to install the snap ring.
- b) Do not over expand the snap ring.
- c) Do not align the snap ring end-gap with the spring retainer stop.


- 12. Install the snap ring while compressing the springs with the SST.



STOPPER

SNAP RING

- 13. Install the dished plate as shown.



DISHED PLATE


Note

Installation order:

Driven-Drive-Driven-Driven-Drive-Driven-Driven-Drive

- 14. Apply ATF to the drive plates and driven plates and install them into the forward clutch piston.


9MU0K1-243



9MU0K1-244

15. Install the retaining plate.

Caution
Do not deform the snap ring.



9MU0K1-245

16. Install the snap ring.


17. Measure the clearance between the retaining plate and the snap ring with a feeler gauge. If not within specification, adjust the clearance by installing the correct retaining plate.

Standard clearance: 1.0—2.0mm (0.039—0.079 in)

Retaining plate sizes

mm (in)

4.0 (0.157)	4.2 (0.165)	4.4 (0.173)	4.6 (0.181)
4.8 (0.189)	5.0 (0.197)	5.2 (0.205)	



9MU0K1-246


18. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining plate.

Standard clearance: 1.0—1.4mm (0.039—0.055 in)

Retaining plate sizes

mm (in)


4.0 (0.157)	4.2 (0.165)	4.4 (0.173)	4.6 (0.181)
4.8 (0.189)	5.0 (0.197)	5.2 (0.205)	



9MU0K1-247

19. Install the dished plate as shown.

Note
Installation order:
Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive



9MU0K1-248

20. Apply ATF to the drive plates and driven plates, and install them into the forward clutch drum.

21. Install the retaining plate.

Caution
Do not deform the snap ring.

22. Install the snap ring.

23. Measure the clearance between the retaining plate and the snap ring with a feeler gauge. If not within specification, adjust the clearance by installing the correct retaining plate.

Standard clearance: 0.45—2.05mm (0.018—0.081 in)

Retaining plate sizes

mm (in)

4.0 (0.157)	4.2 (0.165)	4.4 (0.173)	4.6 (0.181)
4.8 (0.189)	5.0 (0.197)	5.2 (0.205)	

24. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining ring.

Standard clearance: 0.45—0.85mm (0.018—0.033 in)

Retaining plate sizes


mm (in)

4.0 (0.157)	4.2 (0.165)	4.4 (0.173)	4.6 (0.181)
4.8 (0.189)	5.0 (0.197)	5.2 (0.205)	


Caution

Do not deform the snap rings.


25. Install the snap ring.



9MU0K1-249




9MU0K1-250




9MU0K1-251



Installation of proper assembly




9MU0K1-252




9MU0K1-253



9MU0K1-254



9MU0K1-255



1BU0K2-050

Caution

Apply air for no more than 3 seconds.

26. Set the forward clutch drum in the transmission. Apply compressed air through the oil passage, and check the forward clutch and overrunning clutch operation.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

Note

If it turns counterclockwise, the one-way clutch is installed upside down.

27. Check the low one-way clutch operation by turning right and left. It should turn clockwise only, and locked counterclockwise.

LOW AND REVERSE BRAKE**Preinspection****Low and reverse brake operation**

1. Apply compressed air through the oil passage as shown.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

2. Verify that the retaining plates move forward the snap ring. If not the D-ring or the seal ring may be damaged or fluid may be leaking at the piston check ball. Inspect them, and replace when assembling if necessary.

Clearance between retaining plate and snap ring


Measure the clearance between the retaining plate and the snap ring to the forward clutch and the overrunning clutch.

Standard clearance: 0.7—2.3mm (0.028—0.091 in)

Select the correct retaining plate when assembling if not within specification.

Disassembly and Inspection


Disassemble in the order shown in the figure, referring to **Disassembly Note**.
Inspect all parts, and repair or replace if necessary.



N·m (m·kg, ft·lb)

1BU0K2-051

- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Snap ring 2. Retaining plate 3. Drive plates and driven plates
Inspect for damage or burning
Inspection page K2-95 4. Allen head bolts and washers 5. Low one-way clutch inner race
Disassembly Note page K2-95
Inspection page K2-96 6. Spring retainer | <ul style="list-style-type: none"> 7. Return spring
Inspection page K2-95 8. Bearing
Inspect for damage or rough rotation 9. Seal rings 10. Low and reverse brake piston
Inspect balls for sticking by shaking piston
Disassembly Note page K2-95
Inspection page K2-95 11. D-ring 12. Seal ring |
|--|--|




9MU0K1-258

Disassembly note
Low one-way clutch Inner race

Caution
Do not lose the springs.

1. Remove the Allen head bolts holding the low one-way clutch inner race and spring retainer.
2. Remove the low one-way clutch inner race, spring retainer, and return springs.




9MU0K1-259

Low and reverse brake piston

Remove the low and reverse brake piston apply compressed air through the oil passage as shown in the figure.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.




9MU0K1-260

Inspection
Drive plates

1. Measure the facing thickness in three places, and determine the average of the three reading.

Standard thickness: 2.0mm (0.079 in)
Minimum thickness: 1.8mm (0.071 in)

2. If not within specification, replace the drive plates.



9MU0K1-261


Return spring

1. Measure the spring specifications.

Specifications

Outer dia. mm (in)	Free length mm (in)	No. of coils	Wire dia. mm (in)
11.6 (0.457)	23.7 (0.933)	5.0	1.1 (0.043)

2. If not within specification, replace the spring.




9MU0K1-262

Low and reverse brake piston

1. Verify that there is no air leakage when applying compressed air through the oil hole opposite the return spring.
2. Verify that there is air flow when applying compressed air through the oil hole on the return spring side.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.



9MU0K1-263

Low one-way clutch inner race


1. Apply petroleum jelly to a new seal ring and install the seal ring.
2. Measure the clearance between the seal ring and the ring groove.

Standard clearance:

0.10—0.25mm (0.0039—0.0098 in)

Maximum clearance: 0.25mm (0.0098 in)

3. If not within specification, replace the low one-way clutch inner race.




9MU0K1-264

Assembly

1. Apply ATF to the new D-ring and seal ring and install them to the low and reverse brake piston.


Caution

Apply even pressure to the perimeter of the brake piston to avoid damaging the D-ring and seal ring when installing.



9MU0K1-265


2. Apply ATF to the inner surface of the transmission case.
3. Install the low and reverse brake piston in the transmission case by turning it evenly and gradually.



9MU0K1-266


4. Apply petroleum jelly to the bearing, and install it on the low one-way clutch inner race.

Bearing outer diameter: 78.0mm (3.071 in)




9MU0K1-267


5. Assemble the return spring, spring retainer and low one-way clutch inner race to the low and reverse brake piston.




9MU0K1-268




9MU0K1-269



9MU0K1-270



9MU0K1-271



1BU0K2-052

6. Check that the return spring, spring retainer, and low one-way clutch inner race are properly positioned before securing them with the Allen head bolts.

7. Tighten the Allen head bolts evenly and gradually in the order shown.

Tightening torque:

21—26 Nm (2.1—2.7 m·kg, 15—20 ft·lb)

Note

Installation order

Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive-Driven-Drive

8. Apply ATF to the drive plates and driven plates, and install them into the transmission case.

9. Install the retaining plate.

Caution

Do not deform the snap ring.

10. Install the snap ring.


11. Measure the clearance between the retaining plate and the snap ring with a feeler gauge. If not within specification, adjust the clearance by installing the correct retaining plate.

Standard clearance: 0.7—2.3mm (0.028—0.091 in)


Retaining plate sizes

mm (in)


9.0 (0.354)	9.2 (0.362)	9.4 (0.370)
9.6 (0.378)	9.8 (0.386)	10.0 (0.394)



1BU0K2-053



9MU0K1-274



9MU0K1-275

12. If the clearance cannot be brought to within specification after installation of the thickest retaining plate, replace the dished plate, driven plates and drive plates. Adjust the clearance by installing the correct retaining plate.

Standard clearance: 0.7—1.1mm (0.028—0.043 in)

Retaining plate sizes

mm (in)

9.0 (0.354)	9.2 (0.362)	9.4 (0.370)
9.6 (0.378)	9.8 (0.386)	10.0 (0.394)

Caution

Apply air for no more than 3 seconds.

13. Check operation of the piston by applying compressed air through the oil passage of the low and reverse brake.

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.

Caution

Make sure the seal rings are pressed firmly into place and held by petroleum jelly.

14. Apply petroleum jelly to the seal rings and install them onto the low one-way clutch inner race.


ADAPTER CASE AND PARKING MECHANISM

Disassembly and Inspection

Caution

Do not remove the oil seals if not necessary to do so for repairs.

Disassemble in the order shown in the figure, referring to **Disassembly Note**.
Inspect all parts, and repair or replace if necessary.




1BU0K2-054

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Adapter case 2. Parking gear
Inspect individual gear teeth for damage or wear and rough rotation of bearing 3. Output shaft
Inspect splines for damage or wear 4. Parking pawl spacer 5. Return spring 6. Parking pawl 7. Parking pawl shaft 8. Parking actuator 9. Parking rod guide 10. Locknuts | <ol style="list-style-type: none"> 11. Manual plate 12. Parking rod 13. Roll pin 14. Manual shaft 15. Spacer 16. Detent spring
Inspect for fracture or wear 17. Transmission case
Inspection <ol style="list-style-type: none"> a) Damage or wear of oil seal
Disassembly page K2-100 b) Damage or rough rotation of inner bearing |
|--|--|

Disassembly note
Oil seal (Transmission side)

Caution
Do not remove the seal unless necessary.

Remove the oil seal with a screwdriver.




9MU0K1-277

Assembly
Extension housing


1. Apply ATF to the parking rod guide and parking actuator, and install them in the extension housing.

Tightening torque:
 24—29 N·m (2.4—3.0 m·kg, 17—22 ft·lb)



9MU0K1-278


2. Apply ATF to the parking pawl shaft and install it in the extension housing
3. Apply ATF to the parking pawl, return spring and spacer, and install them in the extension housing.



9MU0K1-279


Manual shaft

1. Apply ATF to the lip surface of a new oil seal and install it onto the manual shaft.
2. Wrap the threads of the manual shaft with tape.




9MU0K1-280

3. Apply ATF to the bearing in the transmission case.
4. Install the manual shaft into the transmission case.
5. Push the oil seal squarely into the transmission case.
6. Remove the tape.




9MU0K1-281



9MU0K1-282

7. Align the groove in manual shaft with the roll pin hole, then tap the roll pin into the case as shown in the figure.




9MU0K1-283

8. Install the detent spring and spacer.


Tightening torque:

3.9—5.9 N·m (40—60 cm·kg, 35—52 in·lb)



9MU0K1-284

9. Install the manual plate and parking rod.




9MU0K1-285

10. Tighten the locknuts.

Tightening torque:

29—39 N·m (3.0—4.0 m·kg, 22—29 ft·lb)






9MU0K1-286


11. Check the parking mechanism operation.

OIL SEAL Preparation SST

Following **SSTs** used for 4WD model.

<p>49 U027 003 Installer, oil seal</p> 	<p>49 G030 795 Installer, oil seal</p> 	<p>49 G030 797 Handle (Part of 49 G030 795)</p> 
--	--	---

0MU0K1-050



0BU0K2-107

Inspection


Check for damage, wear, or oil leaking of oil seal. Replace if necessary.

On-vehicle Replacement

Caution

Do not damage the mainshaft splines.

1. Remove the transfer case.
2. Remove the oil seal from the adapter case.
3. Apply ATF to outer periphery and lip surface.
4. Install the new oil seal with the **SST**.
5. Install the transfer case.



0BU0K2-108


CONTROL VALVE BODY (DISASSEMBLY AND INSPECTION)**Disassembly and Inspection****Caution**

- a) Be especially careful when handling the control valve because it consists of the most precise and delicate parts of the transmission.
- b) Neatly arrange the removed parts to avoid confusing them with similar parts.
- c) Clean the removed parts with cleaning solvent, and dry them with compressed air. Clean out all holes and passages with compressed air.

Disassemble in the order shown in the figure.
Inspect all parts, and repair or replace as necessary.


0BU0K2-169

Components




- 1. Lockup solenoid
Inspect filter for clogging or damage
Inspection..... page K2- 38
- 2. Side plate
- 3. Line pressure solenoid
Inspect filter for clogging or damage
Inspection..... page K2- 38
- 4. Overrunning clutch solenoid, shift solenoid A,
and shift solenoid B
Inspect filter for clogging or damage
Inspection..... page K2- 38
- 5. Support plate
- 6. Retaining bolts and nuts
Installation position page K2-120
- 7. Brackets
Installation position page K2-119
- 8. ATF thermoswitch
Inspection..... page K2- 38
- 9. Lower valve body
Disassembly and Inspection .. page K2-116
Installation..... page K2-117
- 10. Steel ball
Installation position page K2-119
- 11. Upper gasket
- 12. Separate plate
Inspect fluid passages for clogging or
damage
- 13. Lower gasket
- 14. Accumulator filter
Inspect for clogging or damage
- 15. Orifice check valve and spring
- 16. Pilot filter
Inspect for clogging or damage
- 17. Manual valve
Inspect for sticking, scoring, or scratches
- 18. Upper valve body
Disassembly and Inspection .. page K2-108
Assembly..... page K2-111


2BU0K2-027



9MU0K1-301




9MU0K1-302



9MU0K1-303


Procedure

- 1. Remove the lockup solenoid and side plate.
- 2. Remove the O-ring from the lockup solenoid.
- 3. Remove the line pressure solenoid.
- 4. Remove the O-ring from the line pressure solenoid.



9MUOK1-304


5. Remove the solenoids.
6. Remove the O-rings from the solenoids.



ATF THERMOSWITCH

0BUOK2-110

7. Remove the support plate.
8. Remove the bolts, nuts, brackets, and ATF thermoswitch.




9MUOK1-308

Caution

- a) Do not scratch the lower valve body.
- b) Be careful not to drop the pilot filter, orifice check valve or spring.

9. Hold the lower valve body, lower and upper gaskets and separate plate with a large clip.
10. Separate the lower valve body from the upper valve body.




9MUOK1-307

Caution

Do not drop or lose the steel balls.

11. Remove the steel balls from the upper valve body.




9MUOK1-308

12. Face the lower valve body downward, and remove the holding clip.

Caution


Do not lose the pilot filter, orifice check valve or spring.

13. Remove the separate plate and gaskets.



9MU0K1-309

14. Remove the orifice check valve, spring, accumulator filter, and pilot filter.



9MU0K1-310

15. Remove the manual valve from the upper valve body.

UPPER VALVE BODY

Disassembly and Inspection


Caution

- a) Each valve should slide out by its own weight.
- b) When a valve will not slide out by its own weight, depending on the valve, push it out with a wire or place the valve body open-side down and lightly tap it with a soft hammer. Never scratch or otherwise damage the valve surface or bore.
- c) Do not drop or lose the valves or internal parts.

Disassemble in the order shown in the figure, referring to **Disassembly Note**.
Inspect all parts, repair or replace as necessary.




APPLY SPECIFIED ATF TO INDIVIDUAL PARTS




0BU0K2-170


1. Retainer Disassembly Note page K2-110	28. Shift valve A spring Inspection page K2-111
2. Torque converter relief spring Inspection page K2-110	29. Shift valve A Inspect for sticking, scoring or scratches
3. Torque converter relief valve Inspect for sticking, scoring or scratches	30. Stopper pin Disassembly Note page K2-110
4. Stopper pin Disassembly Note page K2-110	31. 4-2 relay plug
5. Pressure regulator sleeve Inspect for sticking, scoring or scratches	32. 4-2 relay valve Inspect for sticking, scoring or scratches
6. Pressure regulator spring Inspection page K2-110	33. 4-2 relay spring Inspection page K2-111
7. Pressure regulator plug Inspect for sticking, scoring or scratches	34. Stopper pin Disassembly Note page K2-110
8. Pressure regulator valve Inspect for sticking, scoring or scratches	35. Overrunning clutch control plug
9. Stopper pin Disassembly Note page K2-110	36. Overrunning clutch control spring Inspection page K2-111
10. Pressure modifier plug	37. Overrunning clutch control valve Inspect for sticking, scoring or scratches
11. Pressure modifier spring Inspection page K2-110	38. Stopper pin Disassembly Note page K2-110
12. Pressure modifier valve Inspect for sticking, scoring or scratches	39. Overrunning clutch reducing plug
13. Stopper pin Disassembly Note page K2-110	40. Overrunning clutch reducing valve Inspect for sticking, scoring or scratches
14. Accumulator control plug	41. Overrunning clutch reducing spring Inspection page K2-111
15. Accumulator control valve Inspect for sticking, scoring or scratches	42. Stopper pin Disassembly Note page K2-110
16. Accumulator control sleeve Inspect for sticking, scoring or scratches	43. Shuttle shift valve S plug
17. Stopper pin Disassembly Note page K2-110	44. Shuttle shift valve S spring Inspection page K2-111
18. Shuttle shift valve D plug	45. Shuttle shift valve S Inspect for sticking, scoring or scratches
19. Shuttle shift valve D Inspect for sticking, scoring or scratches	46. Retainer Disassembly Note page K2-110
20. Shuttle shift valve D spring Inspection page K2-110	47. Pilot spring Inspection page K2-111
21. Retainer Disassembly Note page K2-110	48. Pilot valve Inspect for sticking, scoring or scratches
22. Shift valve B spring Inspection page K2-111	49. Stopper pin Disassembly Note page K2-110
23. Shift valve B Inspect for sticking, scoring or scratches	50. Lockup control sleeve
24. Stopper pin Disassembly Note page K2-110	51. Lockup control plug Inspect for sticking, scoring or scratches
25. 4-2 sequence plug	52. Lockup control valve Inspect for sticking, scoring or scratches
26. 4-2 sequence valve Inspect for sticking, scoring or scratches	53. Lockup control spring Inspection page K2-111
27. 4-2 sequence spring Inspection page K2-110	54. Upper valve body Inspect for damage or scoring




9MU0K1-312



9MU0K1-313



9MU0K1-314



9MU0K1-315

Disassembly note Stopper pin

Caution

Do not use a magnet to hold the pin.

1. Push the stopper pin part way out with a wire.
2. Depress and hold the plug or sleeve with a finger to prevent the valve from jumping out.
3. Remove the stopper pin, and remove the valve and internal parts.

Retainer

Caution

Do not use a magnet to hold the retainer.

1. Push the retainer part way out with a wire.
2. Hold the inside parts with a finger to prevent the valve from popping out.
3. Remove the retainer, the valve, and the internal parts.

4-2 sequence valve and 4-2 relay valve

Caution

a) Removal may be difficult.

b) Do not use a magnet to hold the stopper pin.

1. Push the stopper pin part way out with a wire.
2. Depress the plug with a vinyl tape wrapped **1.5mm (0.060 In)** thick around the diameter rod to prevent the valve from popping out.
3. Remove the stopper pin, the valve, and the internal parts.

Inspection


1. Measure the spring specifications.
2. If not within specification, replace the spring(s).

Spring	Item	Outer dia. mm (In)	Free length mm (In)	No. of coils	Wire dia. mm (In)
Torque converter relief valve		9.0 (0.354)	38.0 (1.496)	12.7	1.4 (0.055)
Pressure regulator valve		14.0 (0.551)	44.0 (1.732)	7.9	1.4 (0.055)
Pressure modifier valve*	A	6.8 (0.268)	31.95 (1.258)	15.5	0.8 (0.031)
	B	6.9 (0.272)	32.60 (1.283)	22.2	0.9 (0.035)
	C	6.9 (0.272)	32.80 (1.291)	15.6	0.9 (0.035)
Shuttle shift valve D		6.0 (0.236)	26.5 (1.043)	12.0	0.7 (0.028)


*: Either A, B or C type spring is installed at shipment. Only A type spring is available for replacement.

Spring	Item	Outer dia. mm (in)	Free length mm (in)	No. of coils	Wire dia. mm (in)
4-2 sequence valve		6.95 (0.274)	29.1 (1.146)	11.0	0.55 (0.022)
Shift valve B		7.0 (0.276)	25.0 (0.984)	9.5	0.65 (0.026)
4-2 relay valve		6.95 (0.274)	29.1 (1.146)	11.0	0.55 (0.022)
Shift valve A		7.0 (0.276)	25.0 (0.984)	9.5	0.65 (0.026)
Overrunning clutch control valve		7.0 (0.276)	23.6 (0.929)	7.9	0.6 (0.024)
Overrunning clutch reducing valve		7.0 (0.276)	32.5 (0.984)	12.6	0.85 (0.033)
Shuttle shift valve S		5.5 (0.217)	43.0 (1.693)	22.2	0.85 (0.033)
Pilot valve		9.1 (0.358)	25.7 (1.012)	8.3	1.1 (0.043)
Lockup control valve		13.0 (0.512)	18.5 (0.728)	3.5	0.75 (0.030)

2BU0K2-030



OBU0K2-113




OBU0K2-114

Assembly Procedure

Caution

- a) Before assembly, make sure all parts are thoroughly clean.
- b) Apply ATF to all parts and bores.
- c) Note the proper direction of the valve and internal parts.
- d) Do not reuse any parts that have been dropped.
- e) Do not scratch the valve or valve body.
- f) Wrap a screwdriver or rod with tape before using it to insert a valve.

1. Insert the torque converter relief valve and spring.
2. Install the retainer while compressing the spring.




9MU0K1-320

3. Insert the pressure regulator valve, plug, spring, and sleeve.


Note

- a) If the plug is not centered properly, the sleeve cannot be inserted into the bore in the upper body.
- b) Center the plug with a vinyl tape wrapped screwdriver until the sleeve can be inserted.
- c) Turn the sleeve slightly while installing.



9MU0K1-321


4. Insert the stopper pin while pushing the sleeve.



9MU0K1-322

5. Insert the pressure modifier valve, spring, and plug.


6. Insert the stopper pin while pushing the sleeve.



9MU0K1-323

Note


Align the notch of the sleeve with the plug and insert the stopper pin while pushing the plug.



0BU0K2-115


7. Insert the accumulator control valve, sleeve, and plug.

8. Insert the stopper pin while pushing the plug.




9MU0K1-325

- 9. Insert the shuttle valve D, spring, and plug.
- 10. Insert the stopper pin while pushing the plug.




9MU0K1-326

- 11. Insert the 4-2 sequence valve, spring, and plug.




9MU0K1-327

- 12. Push in the plug with a vinyl tape wrapped 1.5mm (0.060 in) diameter rod.
- 13. Insert the stopper pin.




9MU0K1-328

- 14. Insert the shift valve B.
- 15. Insert the spring.




9MU0K1-329

- 16. Insert the 4-2 relay valve and spring.
- 17. Insert the stopper pin while pushing the plug.
- 18. Insert the shift valve A and spring.
- 19. Insert the retainer while compressing the spring.




9MU0K1-330

- 20. Insert the overrunning clutch control valve, spring, and plug.
- 21. Insert the stopper pin while pushing the plug.




9MU0K1-331

- 22. Insert the overrunning clutch reducing valve, spring, and plug.
- 23. Insert the stopper pin while pushing the plug.




0BU0K2-116

- 24. Insert the shuttle shift valve S, spring, and plug.
- 25. Insert the stopper pin while pushing the plug.



9MU0K1-333

- 26. Insert the lockup control valve, spring, plug, and sleeve.
- 27. Insert the stopper pin while pushing the sleeve.



9MU0K1-334

- 28. Insert the pilot valve and spring.
- 29. Insert the retainer while pushing the spring.


MEMO

LOWER VALVE BODY Disassembly and Inspection

Caution


- a) Each valve should slide out by its own weight.
- b) When a valve will not slide out by its own weight, depending on the valve, push it out with a wire or place the valve body open-side down and lightly tap it with a soft hammer. Never scratch or otherwise damage the valve surface or bore.
- c) Do not drop or lose the valves or internal parts.

Disassemble in the order shown in the figure.
Inspect all parts, repair or replace as necessary.



- 1. Stopper pin
Disassembly Note page K2-110
- 2. Modifier accumulator plug
- 3. Modifier accumulator spring
Inspection page K2-117
- 4. Modifier accumulator valve
Inspect for sticking, scoring or scratches
- 5. Retainer
- 6. 1st reducing spring
Inspection page K2-117
- 7. 1st reducing valve
Inspect for sticking, scoring or scratches
- 8. Retainer
Disassembly Note page K2-110
- 9. 3-2 timing spring
Inspection page K2-117
- 10. 3-2 timing valve
Inspect for sticking, scoring or scratches
- 11. Stopper pin
Disassembly Note page K2-110
- 12. Servo charger plug
- 13. Servo charger valve
Inspect for sticking, scoring or scratches
- 14. Servo charger spring
Inspection page K2-110
- 15. Lower valve body
Inspect for damage or scoring

1BU0K2-058




9MU0K1-338

Inspection

1. Measure the spring specifications.
2. If not within specification, replace the spring(s).

Spring	Item	Outer dia. mm (In)	Free length mm (In)	No. of coils	Wire dia. mm (In)
Modifier accumulator piston		9.8 (0.386)	30.5 (1.201)	8.75	1.3 (0.051)
1st reducing valve		6.75 (0.266)	25.4 (1.0)	12.5	0.75 (0.030)
Servo charger valve		6.5 (0.256)	33.2 (1.307)	12.0	0.5 (0.020)
3-2 timing valve		6.75 (0.266)	20.55 (0.809)	7.5	0.75 (0.030)


1BU0K2-059



9MU0K1-340


Installation

1. Insert the servo charger valve, spring, and plug.
2. Insert the stopper pin while pushing the plug.




1BU0K2-086

3. Insert the 3-2 timing valve and spring.
4. Insert the retainer while compressing the spring.



9MU0K1-342


5. Insert the 1st reducing valve and spring.
6. Insert the retainer while compressing the spring.



9MU0K1-343


7. Insert the modifier accumulator valve, spring, and plug.
8. Insert the stopper pin while pushing the plug.

Steel ball installation positions




9MUOK1-344

Bracket installation positions










9MUOK1-345
K2-119

Bolts and nuts installation positions



9MU0K1-346

Identification letter	Bolts and nuts	Length mm (in)	Torque specification N·m (cm·kg, in·lb)
A		65 (2.559)	6.9—8.8 (70—90, 61—78)
B		50 (1.969)	
C		33 (1.299)	
D		27 (1.063)	
E		55 (2.165)	
F		40 (2.559)	
G		40 (2.559)	


OBU0K2-120

CONTROL VALVE BODY (ASSEMBLY)


Caution

- a) Before assembly, make sure all parts are perfectly clean.
- b) Apply ATF to all parts.
Do not reuse the gasket or O-ring.


9MU0K1-348




1BU0K2-060



2BU0K2-032



9MU0K1-351



Procedure


1. Install the steel balls and reamer bolts into their proper positions of the upper valve body.
(Refer to page K2-121 for installation positions.)

2. Install the pilot filter, accumulator filter, and orifice check valve and spring into their proper positions in the lower valve body.

Caution


- a) Do not mixup the upper and lower gaskets.
 - b) Do not scratch the lower valve body.
3. Install a new gasket and the separate plate onto the lower valve body and hold both them with a large clip.

4. Set the lower valve body onto the upper valve body.
5. Remove a holding clip.



9MU0K1-352

6. The support plate locations are as shown.




9MU0K1-353

7. Install the bolts, nuts, support plates, ATF thermoswitch, and brackets in their proper positions. (Refer to page K2-122 for installation positions.) Tighten the fasteners evenly and gradually.

Tightening torque:


6.9—8.8 N·m (70—90 cm·kg, 61—78 in·lb)



ATF THERMOSWITCH

1BU0K2-061

8. Install a new O-ring onto the lockup solenoid.




9MU0K1-355


9. Install the lockup solenoid and side plate to the control valve body assembly.

Tightening torque:

9.8—13 N·m (1.0—1.3 m·kg, 87—113 in·lb)




9MU0K1-356



9MU0K1-357

10. The side plate installation are as shown.




9MU0K1-358

11. Install the new O-rings onto the solenoids.
 12. Install the solenoids into the control valve body assembly.

Tightening torque:

6.9—9.8 N·m (70—100 cm·kg, 61—87 in·lb)




9MU0K1-359

13. Install a new O-ring onto the line pressure solenoid.
 14. Install the line pressure solenoid into the control valve body assembly.

Tightening torque:

6.9—9.8 N·m (70—100 cm·kg, 61—87 in·lb)




9MU0K1-360


15. Insert the manual valve.

ON-VEHICLE REMOVAL


1. Disconnect the negative battery cable.
2. Jack up the vehicle and support it with a safety stand.
3. Loosen the oil pan installation bolts, and drain the ATF into a container.




9MU0K1-381




9MU0K1-362



0BU0K2-172



0BU0K2-173



9MU0K1-365

4. Remove the oil pan and gasket.
5. Remove the magnet from the oil pan.


6. Remove the clip.

Caution
Do not damage the harness.

7. Disconnect the lockup solenoid connector.


8. Disconnect the ATF thermosensor.

9. Remove the oil strainer.
10. Remove the O-ring from the oil strainer.




9MU0K1-366

11. Separate the harness of the solenoid connectors from the harness clip.




9MU0K1-367

12. Remove the (A) and (B) bolts and bracket shown in the figure.



9MU0K1-368

13. Remove the clip.
14. Separate the solenoid connectors.




9MU0K1-369

Caution

- a) Do not damage the oil pipes.
- b) Do not drop the springs.

15. Remove the control valve body assembly and accumulator springs.




9MU0K1-370

16. If necessary, remove the solenoid connector from the transmission case.

ON-VEHICLE INSTALLATION

1. Install the solenoid connector into the transmission case if removed.
2. Connect the solenoid connector to the solenoids.
3. Install the clip.



9MU0K1-371

4. Set the accumulator springs into the control valve body as shown.

Spring specifications


mm (in)

Spring	Item	Outer dia	Free length	No. of coil	Wire dia.
3-4/N-R accumulator piston		17.3 (0.681)	58.4 (2.299)	12.3	2.3 (0.091)
1-2 accumulator piston		29.3 (1.154)	45.0 (1.772)	3.6	4.0 (0.157)
2-3 accumulator piston		20.0 (0.787)	66.0 (2.598)	11.4	3.5 (0.138)

Note

- a) Verify that the manual valve and manual shaft are assembled correctly.
- b) Verify that the accumulator springs are installed correctly.

5. Set the control valve into the transmission case and secure it.



9MU0K1-372

6. Install the control valve mounting bolts and brackets as shown.

Bolt length (Measured from below the head)

- (A): 33mm (1.299 in)**
- (B): 45mm (1.772 in)**

7. Tighten the bolts in sequence.

Tightening torque:


6.9—8.8 N·m (70—90 cm·kg, 61—78 in·lb)

8. Apply ATF to a new O-ring and install it onto the oil strainer.
9. Install the oil strainer.


Bolt length (Measured from below the head):
50mm (1.969 in)

Tightening torque:


6.9—8.8 N·m (70—90 cm·kg, 61—78 in·lb)




9MU0K1-373



1BU0K2-062




9MU0K1-375



9MU0K1-376

10. Mount the harness of the solenoid connectors with the harness clip.




1BU0K2-063

11. Install the ATF thermosensor.

Tightening torque:


6.9—8.8 N·m (70—90 cm·kg, 61—78 in·lb)

**Bolt length (Measured from below the head):
33mm (1.299 in)**



0BU0K2-175

12. Connect the lockup solenoid connector.
13. Install the clip.




9MU0K1-379

14. Set the magnet into the oil pan.
15. Install the oil pan along with a new gasket.

Tightening torque:

4.9—7.8 Nm (50—80 cm·kg, 43—69 in·lb)







1BU0K2-064

16. Add **approx. 4.0 liters (4.2 US qt, 3.5 Imp qt)** ATF, and check the ATF level. (Refer to page K2-42.)

TRANSMISSION UNIT (ASSEMBLY)


Preparation SST

<p>49 0107 680A Engine stand</p> 	<p>49 U019 0A0A Transmission hanger</p> 	<p>49 H075 495B Body (Part of 49 U019 0A0A)</p> 
2BU0K2-033		
<p>49 U019 003 Holder (Part of 49 U019 0A0A)</p> 		

Precaution

1. If the drive plates or brake band is replaced with new ones, soak in ATF for at least 2 hours before installation.
2. Before assembly, apply ATF to all seal rings, rotating parts, O-rings, D-rings and sliding parts.
3. All O-rings, D-rings, seals, and gaskets must be replaced with new ones included in the overhaul kit.
4. Use petroleum jelly, not grease, during reassembly.
5. When it is necessary to replace a bushing, replace the subassembly that includes that bushing.
6. Assemble the housing within 10 minutes after applying sealant, and allow it to cure at least 30 minutes after assembly before filling the transmission with ATF.

Thrust washer, bearing, and race locations




Outer diameter of bearing and race

		1	2	3	4	5	6
Bearing	mm (in)	47.0 (1.850)	53.0 (2.087)	53.0 (2.087)	78.0 (3.071)	53.0 (2.087)	78.0 (3.071)
Race	mm (in)	43.5 (1.713)	51.5 (2.028)	—	75.0 (2.953)	—	75.0 (2.953)

		7	8	9
Bearing	mm (in)	59.0 (2.323)	78.1 (3.075)	64.0 (2.520)
Race	mm (in)	—	—	—

9MU0K1-383

Torque specifications



N-m (m-kg, ft-lb)

9MU0K1-384

Procedure

Caution

Do not damage the seal ring on the low one-way clutch inner race.

1. Install the forward clutch drum while slowly turning it clockwise until its hub passes fully over the clutch inner race.

2. Verify that the forward clutch assembly will turn only clockwise.


3. Install the rear internal gear, forward clutch hub, and over-running clutch hub in the forward clutch assembly.

4. Measure the height difference between forward clutch retaining plate and top of the forward clutch drum.


Height: Approx. 2.0—3.0mm (0.079—0.118 In)

5. Install the front internal gear and rear planetary carrier into the forward clutch assembly.


6. Insert the output shaft.




9MU0K1-385




9MU0K1-386




9MU0K1-387



9MU0K1-388




9MU0K1-389




9MU0K1-390

7. Push the output shaft forward slightly, and install a new snap ring on it. Verify that the output shaft will not be removed from the rear.




9MU0K1-391

8. Apply petroleum jelly to the bearing and install it to the transmission case with the black surface facing toward the rear.




9MU0K1-495

9. Install the parking gear.



9MU0K1-392


10. Pull the output shaft back slightly, and install a new snap ring on it. Verify that the output shaft will not move forward.



OBU0K2-124

11. Install the new gasket.

TRANSMISSION



2BU0K2-034

12. Install the extension housing.

Bolt length (Measured from below the head)

- Ⓐ: 30mm (1.181 in)
- Ⓑ: 45mm (1.772 in)
- Ⓒ: 50mm (1.969 in)

Tightening torque:


20—25 N·m (2.0—2.5 m·kg, 14—18 ft·lb)

13. Install the O-ring onto the speedometer driven gear.

14. Install the speedometer driven gear into the extension housing.

Tightening torque:

4.9—6.9 N·m (50—70 cm·kg, 43—61 in·lb)




0BU0K2-126

Caution

Be sure the oil grooves of the rear sun gear face forward as shown.


15. Install the rear sun gear into the front internal gear.



0BU0K2-127

16. Check that the bearing, and bearing race are installed correctly.

17. While rotating the forward clutch drum clockwise, install the front planetary carrier into the forward clutch assembly.



0BU0K2-128


18. The reverse clutch, high clutch, and front sun gear. Install into the transmission case as an assembly.

Caution

When any parts listed in the following table is replaced, total end play or reverse clutch end play must be adjusted.

Part name	Item	Total end play	Reverse end play
Transmission case		○	○
Low one-way clutch inner race		○	○
Overrunning clutch hub		○	○
Rear internal gear		○	○
Rear planetary carrier		○	○
Rear sun gear		○	○
Front planetary carrier		○	○
Front sun gear		○	○
High clutch hub		○	○
High clutch drum		○	○
Oil pump cover		○	○
Reverse clutch drum		—	○


9MU0K1-399



0BU0K2-129


19. Adjust total end play.

(1) Install the oil pump gasket.



9MU0K1-401

(2) Measure height A with vernier calipers and a straight edge.




9MU0K1-402


(3) Measure height B with vernier calipers.

- (4) Install the needle bearing on the oil pump.
- (5) Measure height C with vernier calipers and a straight edge.
- (6) Calculate the total end play by using the formula below.

Formula: $T1 = A - B - C - 0.1\text{mm (0.0039 in)}$



9MU0K1-403



9MU0K1-404

- T1 : Oil pump end play
- A : Distance between bearing race of front side of transmission case and reverse clutch
- B : Distance between front side of transmission case and oil pump gasket
- C : Distance between upper surface of needle bearing of oil pump and oil pump gasket contact surface
- 0.1: Amount of compression of new oil pump gasket

**Oil pump end play specification:
0.25—0.55mm (0.010—0.022 in)**


- (7) If the total end play is not within specification, adjust it by selecting and installing the proper bearing race.

Bearing race size

mm (in)

0.8 (0.031)	1.0 (0.039)	1.2 (0.047)	1.4 (0.055)
1.6 (0.063)	1.8 (0.071)	2.0 (0.079)	


9MU0K1-405



9MU0K1-406


20. Adjust reverse clutch end play.

- (1) Install the thrust washer on the reverse clutch.
- (2) Measure height E with vernier calipers and a straight edge.




9MU0K1-407

- (3) Measure height B with vernier calipers and a straight edge.



9MUOK1-408



9MUOK1-409

- (4) Measure height F with vernier calipers and a straight edge.
- (5) Calculate the reverse clutch end play by using the formula below.

Formula: $T2 = E - B - F - 0.1\text{mm (0.0039 in)}$

- T2 : Reverse clutch end play
- B : Distance between front side of transmission case and oil pump gasket
- E : Distance between thrust washers of front side of transmission case and reverse clutch
- F : Distance between reverse clutch thrust washer contact surface of oil pump and oil pump gasket contact surface
- 0.1: Amount of compression of new oil pump gasket


**Reverse clutch end play specification:
0.55—0.90mm (0.022—0.035 in)**

- (6) If the reverse clutch end play is not within specification, adjust it by selecting and installing the proper reverse clutch thrust washer.


Thrust washer size

			mm (in)
0.7 (0.028)	0.9 (0.035)	1.1 (0.043)	1.3 (0.051)
1.5 (0.059)	1.7 (0.067)	1.9 (0.075)	

9MUOK1-410




9MUOK1-411



9MUOK1-412


21. Apply ATF to the brake band and band strut, and install them into the transmission.

22. Install a new anchor end bolt.




9MU0K1-413

23. Apply ATF to the input shaft, and install it into the transmission case.



9MU0K1-414

24. Apply petroleum jelly to the oil pump assembly as shown.




9MU0K1-415

Caution

- a) Do not damage the seal rings or O-ring.
- b) Do not use a hammer, plastic or any other kind to install the oil pump.


25. Turn the transmission as shown. Install the oil pump assembly into the transmission case by using two converter housing bolts as a guide. Measure the height difference between top of the transmission case and oil pump as shown.

Height: Approx. 1.0mm (0.039 in)





9MU0K1-416

26. Apply ATF to a new O-ring, and install it onto the input shaft.



9MU0K1-417

27. Apply ATF to the new O-rings, and install them into the converter housing, as shown.
 28. Apply sealant lightly, as shown.




9MU0K1-418

29. Remove the converter housing bolts used as guide.
 30. Install the converter housing onto the transmission case, and tighten the bolts evenly in a crisscross pattern.

Tightening torque:

61—64 N·m (6.2—6.5 m·kg, 45—47 ft·lb)




9MU0K1-419

31. Adjust the brake band.
 (1) Tighten the anchor end bolt with the hex wrench.

Tightening torque:

3.9—5.9 N·m (40—60 cm·kg, 35—52 in·lb)




9MU0K1-420

- (2) Loosen the anchor end bolt **2.5** turns.
 (3) Install the locknut.
 (4) Hold the anchor end bolt with the hex wrench and tighten the locknut.

Tightening torque:

31—42 N·m (3.2—4.3 m·kg, 23—31 ft·lb)




9MU0K1-421


32. Apply ATF to a new O-ring, and install it onto the speed sensor 1.
 33. Mount the speed sensor 1 into the extension housing.

Tightening torque:


4.9—6.9 N·m (50—70 cm·kg, 43—61 in·lb)




9MU0K1-422



9MU0K1-423



0BU0K2-178



1BU0K2-067

34. Apply ATF to a new O-ring, and install it onto the solenoid connector.

Caution

Do not damage the solenoid connector.

35. Install the solenoid connector into the transmission case.

36. Connect the solenoid connector to the solenoids.

37. Install the clip.

Note

a) Verify that the manual valve and manual shaft are assembled correctly.

b) Verify that the accumulator springs are installed correctly.

38. Install the valve body assembly, and tighten bolts (A) and (B) evenly.


Bolt length (Measured from below the head)

(A): 33mm (1.299 in)

(B): 45mm (1.772 in)

Tightening torque:

6.9—8.8 N·m (70—90 cm·kg, 61—78 in·lb)




0BU0K2-177

- 39. Apply ATF to a new O-ring, and install it onto the oil strainer.
- 40. Install the oil strainer.


Bolt length (Measured from below the head):
50mm (1.969 in)

Tightening torque:
6.9—8.8 N·m (70—90 cm·kg, 61—78 in·lb)



9MU0K1-426

- 41. Mount the solenoid harness with the clips.




1BU0K2-068

- 42. Install the ATF thermosensor as shown in the figure.


Bolt length (Measured from below the head):
45mm (1.772 in)

Tightening torque:
6.9—8.8 N·m (70—90 cm·kg, 61—78 in·lb)



0BU0K2-178


- 43. Connect the lockup solenoid connector.
- 44. Install the clip.




9MU0K1-429

- 45. Set the magnet into the oil pan.
- 46. Install the oil pan along with the new gasket.


Tightening torque:
4.9—7.8 N·m (50—80 cm·kg, 43—70 in·lb)




9MU0K1-430



2BU0K2-035



9MU0K1-432



1BU0K2-070

47. Install the inhibitor switch.
 - (1) Install the bracket.

Tightening torque:
7.8—12 N·m (80—120 cm·kg, 69—104 in·lb)

- (2) Verify that the manual shaft is positioned at the L position (fully forward).
- (3) Install the inhibitor switch over the manual shaft.

- (4) Turn the manual shaft fully rearward, then return it two (2) notches (N range position).
- (5) Insert a **4.0mm (0.157 in)** pin through the holes of the inhibitor switch and the manual shaft lever.
- (6) Tighten the new inhibitor switch retaining bolts.

Tightening torque:
2.5—3.9 N·m (25—40 cm·kg, 22—35 in·lb)

- (7) Remove the pin.

48. Stand the torque converter upright, and fill it with ATF.

Note

- a) **Approximately 2 liters (2.1 US qt, 1.8 Imp qt) of ATF are required for a new torque converter.**
- b) **When reusing previous torque converter, add the same amount of ATF as was drained.**

49. Install the torque converter into the transmission.


50. Measure the installation depth of the torque converter with vernier calipers and a straight edge.

Specification: 36.0mm (1.417 in)

51. Install the transfer case. (Refer to Section J3.)


TRANSMISSION UNIT (INSTALLATION)

Preparation SST




2BU0K2-036

1. Raise the vehicle and support it with safety stands.
2. Install in the order shown in the figure, referring to **Installation Note**.
3. Fill the transmission with the specified amount of the ATF after installation.
4. Warm up the engine and transmission, and inspect for oil leakage and transmission operation.



2BU0K2-037

- | | |
|---|---|
| 1. Transmission mount | 12. Speedometer cable |
| 2. Automatic transmission | 13. Front propeller shaft
Service..... Section L |
| 3. Oil level gauge and pipe | 14. Rear propeller shaft
Service..... Section L |
| 4. Connectors | 15. Exhaust pipe |
| 5. Cross member | 16. Under cover |
| 6. Oil pipe connector and bracket | 17. 4x4 shift lever |
| 7. Transmission installation bolt | 18. Insulator plate and boot |
| 8. Torque converter installation bolt
Installation Note..... page K2-144 | 19. Console box |
| 9. Under cover | 20. Selector knob |
| 10. No.2 cross member | |
| 11. Selector cable | |




0BU0K2-133

Installation Note

Torque converter installation bolts

1. Hold the drive plate with the screwdriver.



49 0877 435

0BU0K2-134

2. Loosely and evenly tighten the torque converter installation bolts, then further tighten them to the specified torque with the **SST**.

Tightening torque:

34—49 N·m (3.5—5.0 m·kg, 25—36 ft·lb)


OIL COOLER

Removal, Inspection, and Installation

Remove in the order shown in the figure.

Inspect all parts and repair or replace as necessary.

Install in the reverse order of removal, referring to **Installation Note**.



1BU0K2-072

- | | |
|---|---|
| <p>1. Connector bolts
Inspect for clogging</p> <p>2. Packing</p> <p>3. Transmission
Removal page K2- 45
Installation..... page K2-141</p> | <p>4. Oil pipe
Inspect for damage or cracks
Installation Note..... page K2-143</p> <p>5. Oil hose
Inspect for damage or cracks</p> <p>6. Radiator
Service Section E</p> |
|---|---|


Installation Note

Oil pipe

Caution

If reuse the hose clamp, position the hose clamp in the original location on the hose. Squeeze the clamp lightly with large pliers to ensure a good fit.





1. Align the marks, and slide the oil cooler hoses onto the oil cooler pipes until it contacts the ridge.
2. Install the hose clamp onto the hose at the center of the mark and at the angle shown.
3. Verify that the hose clamp does not interfere with any other parts.



2BU0K2-038


DRIVE PLATE

Preparation SST

<p>49 E011 1A0 Brake set, ring gear</p> 	<p>49 E011 103 Shaft (Part of 49 E011 1A0)</p> 	<p>49 E011 104 Collar (Part of 49 E011 1A0)</p> 
<p>49 E011 105 Stopper (Part of 49 E011 1A0)</p> 	<p>2BU0K2-039</p>	

Removal and Inspection and Installation


Remove in the order shown in the figure, referring to **Removal Note**.
Inspect all parts, and repair or replace as necessary.
Install in the reverse order of removal, referring to **Installation Note**.




- 1. Transmission
 - Removal page K2- 45
 - Installation page K2-141
- 2. Bolts
 - Removal Note below
 - Installation Note below

- 3. Backing plate
- 4. Drive plate
 - Inspect for cracks and ring gear for wear or damage
- 5. Adapter

2BU0K2-041



9MUOK1-457



1BU0K2-074

**Removal Note
Bolts**

- 1. Remove the drive plate using the **SST** or equivalent.

**Installation Note
Bolts**

- 1. Assemble the adapter, drive plate and backing plate.
- 2. Install the **SST** or equivalent and tighten the bolts diagonally and evenly.


Tightening torque:

91—98 Nm (8.3—10.0 m-kg, 67—72 ft-lb)

- 3. Install the transmission. (Refer to page K2-141.)


SHIFT MECHANISM

SHIFT-LOCK SYSTEM COMPONENTS



OBUOK2-140


TROUBLESHOOTING Circuit Diagram




OBUOK2-141

Diagnosis chart


Problem	Possible Cause	Action	Page
Selector lever cannot be moved from P range with brake pedal depressed and ignition switch ON	ROOM 15A fuse not installed or burned	Install or replace	K2-146
	IG1 system malfunction <ul style="list-style-type: none"> • Wire harness broken • Poor connection • METER 10A fuse burned 	Repair or replace Connect firmly Replace	K2-146 K2-146 K2-146
	Ignition switch malfunction	Inspect and replace	Section T
	Stoplight switch remains OFF	Inspect and replace	Section T
	Stoplight system malfunction <ul style="list-style-type: none"> • Wire harness broken • Poor connection • STOP 15A fuse burned 	Repair or replace Connect firmly Replace	K2-146 K2-146 K2-146
	P range switch remains OFF	Inspect and replace	K2-148
	P range switch system malfunction <ul style="list-style-type: none"> • Wire harness broken (Poor ground) • Poor connection 	Repair or replace Connect firmly	K2-146 K2-146
	Shift-lock actuator malfunction <ul style="list-style-type: none"> • Wire harness broken • Poor connection 	Inspect and replace Repair wiring harness Connect firmly	K2-148 K2-146 K2-146
	Misadjustment of selector lever or improper assembly of shift-lock actuator	Adjust or repair	K2-148
Selector lever can be moved from P range with ignition switch ON, but without brake pedal depressed	ROOM 15A fuse burned	Replace	K2-146
	Stoplight switch remains ON	Inspect and replace	Section T
	Shift-lock actuator malfunction	Inspect and replace	K2-148
	Misadjustment of selector lever or improper assembly of shift-lock actuator	Adjust or repair	K2-148
Selector lever can be moved from P range with ignition switch OFF and brake pedal depressed	ROOM 15A fuse burned	Replace	K2-146
	Ignition switch malfunction	Inspect and repair	Section T
	Shift-lock actuator malfunction	Inspect and replace	K2-148
	Misadjustment of selector lever or improper assembly of shift-lock actuator	Adjust and repair	K2-148
Shift-lock actuator operation heard when brake pedal depressed with ignition switch ON in other than P range	P range switch remains ON	Inspect and replace	K2-148
Selector remains locked with emergency override button operated	Emergency override button not slide fully back	Slide fully back and hold emergency override button, move selector lever	—
	Broken emergency override link	Replace	K2-152
	Misadjustment of indicator panel	Adjust	K2-151
Ignition key can be turned to LOCK position with selector lever in ranges other than P range	Interlock cable <ul style="list-style-type: none"> • Disconnected • Kinked • Stuck • Spring damaged 	Inspect and replace	K2-151,152
	Key cylinder malfunction	Replace	Section N
Ignition key cannot be turned to LOCK position with selector lever in P range	Interlock cable <ul style="list-style-type: none"> • Disconnected • Kinked • Stuck • Spring damaged 	Inspect and replace	K2-151,152
	Key cylinder malfunction	Replace	Section N




OBU0K2-143




1BU0K2-076



OBU0K2-145



OBU0K2-146



OBU0K2-147

P RANGE SWITCH

Inspection

Continuity

1. Disconnect the negative battery cable.
2. Remove the selector knob, and then remove the console.
3. Disconnect the P range switch connector.

4. Check continuity of the terminals.

Range	Selector lever release button	Continuity
P	Released	Yes
	Depressed	No
R, N, D, S, L	—	No

5. If not as specified, replace the P range switch.
(Refer to page K2-152.)

6. Install the console.
7. Clean and apply locking compound to the selector knob screws threads. Tighten the screws.

Tightening torque:

1.5—2.9 N·m (15—30 cm·kg, 13—26 in·lb)

8. Connect the negative battery cable.
9. Check for correct operation of the shift-lock system.

SHIFT-LOCK ACTUATOR


Inspection

Terminal voltage and continuity

1. Remove the selector knob, and then remove the console.

Caution

Disconnect connector B to check continuity between terminal b (harness side) and a ground.




0BU0K2-148

- Turn the ignition switch ON, and check terminal voltages and continuity, referring to the chart below.
- If not as specified, repair the wire harness and/or shift-lock actuator.

V_B: Battery voltage

Connector	Terminal	⊖ terminal connected to	Condition	Measurement valve
A	a	B—b	P range, selector lever release button not depressed	0Ω
A	b	B—b	Constant	0Ω
B	a	B—b	Brake pedal released → depressed	0V → V _B
B	b (harness side)	Body	Constant	0Ω
B	c	B—b	Ignition switch ON	V _B
B	d	B—b	Ignition switch OFF	V _B

2BU0K2-043



0BU0K2-149

- Install the console.
- Clean and apply locking compound to the selector knob screws threads. Tighten the screws.

Tightening torque:

1.5—2.9 N·m (15—30 cm·kg, 13—26 in·lb)


- Check for correct operation of the shift-lock system.

SELECTOR LEVER

Inspection


Caution

Shift the selector lever from P range to other ranges with ignition switch ON and brake pedal depressed.




97U0KX-308


- Check that the selector lever can only be shifted as shown in the figure.
- Make sure there is a click at each range when shifted from P → L range.
- Check that the positions of the selector lever and the indicator are aligned.
- Check that the button returns smoothly when pushed to shift.




0BU0K2-150



0BU0K2-151



0BU0K2-152



0BU0K2-153

Adjustment Lever position

1. Disconnect the negative battery cable to deactivate the shift-lock.
2. Remove the selector knob and console.
3. Loosen the locknut (A), (B), and lock bolt (C).

4. Shift the manual shaft to P range position.

5. Push and hold the selector lever forward by using a force of **39—98 N (4—10 kg, 8.8—22 lb)**, tighten the lock bolt (C) to the specified torque.

Tightening torque:

8—11 N·m (80—110 cm·kg, 67—95 in·lb)

6. Turn locknut (A) by hand until it just touches the spacer.
7. Tighten the locknut (B) to the specified torque.

Tightening torque:

8—11 N·m (80—110 cm·kg, 67—95 in·lb)


8. Check the lever so that the clearance between the guide plate and the guide pin in P range with the push rod lightly depressed is as shown.
9. Move the selector lever to N and D ranges and verify that there is the same clearance between the guide plate and guide pin.
10. If not as specified, readjust the lever.
11. Install the console.
12. Clean and apply locking compound to the selector knob screws threads. Tighten the screws.

Tightening torque:


1.5—2.9 N·m (15—30 cm·kg, 13—26 in·lb)

13. Check for correct operation of the shift-lock system.


0BU0K2-154




08U0K2-155



08U0K2-156



97U0KX-313



97U0KX-314

Indicator panel

1. Remove the selector knob and console.
2. Shift the selector lever to P range.
3. Loosen the indicator screws.
4. Align the alignment grooves in the slider with the holes in the indicator panel. Install suitable heavy-gauge wire to hold the slider.

5. Tighten the indicator screws in the order shown in the figure.
6. Remove the wire.
7. Verify that the selector lever properly aligns with the indicator in each range.
8. Install the console.
9. Clean and apply locking compound to the selector knob screws threads. Tighten the screws.

Tightening torque:

1.5—2.9 N·m (15—30 cm·kg, 13—26 In·lb)

Shift-lock System Operation Inspection

Caution


Service with engine OFF.

Shift-lock system

1. Turn the ignition switch ON.
2. Verify that the selector lever is in P range.
3. Without the brake pedal depressed, verify that the selector lever cannot be shifted from P range.
4. Depress the brake pedal. Verify that the selector lever can be shifted from P range.
5. Shift the selector lever to R range.
6. Verify that the ignition key cannot be turned to LOCK position.
7. Shift the selector lever to P range.
8. Verify that the ignition key can be turned to LOCK position.
9. If not as specified, inspect and repair as necessary, referring to Troubleshooting.

REMOVAL, INSPECTION, AND INSTALLATION

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Inspect all parts, and repair or replace as necessary.
4. Install in the reverse order of removal, referring to **Installation Note**.




N-m (m-kg, ft-lb)


1BU0K2-077

1. 4x4 shift lever knob
2. Selector knob
3. Console
4. Insulator plate and boot
Installation Note..... page K2-154
5. Indicator panel
Installation Note..... page K2-154
6. Connectors


7. Selector cable
Installation Note..... page K2-154
8. Selector lever
Removal Note..... page K2-153
Installation Note..... page K2-153
9. Interlock cable
Removal Note..... page K2-153
Installation Note..... page K2-153




0BU0K2-158



0BU0K2-159



0BU0K2-160



0BU0K2-161

Removal Note Selector lever

Caution

Do not loosen locknut (B), It is factory preset for proper shift-lock system operation.

1. Loosen the locknut (A).

Caution

Do not kink the cable.

2. Separate the cable from the selector lever.

Interlock cable

Note

Do not remove the Interlock cable if not necessary.

1. Remove the instrument panel. (Refer to Section S.)
2. Remove the interlock cable.

Installation Note

Interlock cable

1. Install the interlock cable.
2. Install the instrument panel. (Refer to Section S.)

Selector lever

1. Shift the selector lever to N range.
2. Install the selector lever.

Tightening torque:

7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)

Caution


Do not kink the cable.

3. Install the cable and tighten locknut (A).

Tightening torque:

9.8—15 N·m (1.0—1.5 m·kg, 7.2—11 ft·lb)


4. Check shift-lock system operation.



0BU0K2-163

Selector cable


1. Install the selector cable as shown in the figure.
2. Adjust the lever position. (Refer to page K2-154.)



1BU0K2-078

Indicator panel

1. Install the indicator panel.
2. Adjust the indicator panel. (Refer to page K2-151.)




0BU0K2-165


Insulator panel and boot

1. Install the insulator panel and boot as shown in the figure.

HYDRAULIC CIRCUIT


P RANGE






- OPERATING LINE PRESSURE
- ▨ LINE PRESSURE
- ▬ OIL PUMP FEEDBACK PRESSURE
- ▩ PILOT PRESSURE
- ▧ THROTTLE PRESSURE (LINE PRESSURE SOL. OUTPUT PRESSURE)
- MODIFIER PRESSURE
- ▬ ACCUMULATOR CONTROL PRESSURE
- ▨ 1ST REDUCING PRESSURE
- ▨ OVERRRUNNING CLUTCH REDUCING PRESSURE
- ▨ TORQUE CONVERTER PRESSURE

N RANGE




D RANGE; 1ST GEAR




9MUOK1-474

D RANGE; 2ND GEAR




D RANGE; 3RD GEAR



HYDRAULIC CIRCUIT


K2

D RANGE; OD, LOCKUP OFF



HYDRAULIC CIRCUIT

D RANGE; OD, LOCKUP ON




- OPERATING LINE PRESSURE
- LINE PRESSURE
- OIL PUMP FEEDBACK PRESSURE
- PILOT PRESSURE
- THROTTLE PRESSURE
- LINE PRESSURE SOL. OUTPUT PRESSURE
- MODIFIER PRESSURE
- ACCUMULATOR CONTROL PRESSURE
- 1ST REDUCING PRESSURE
- OVERRUNNING CLUTCH REDUCING PRESSURE
- TORQUE CONVERTER PRESSURE


HYDRAULIC CIRCUIT

K2

S RANGE; 1ST GEAR




S RANGE; 2ND GEAR



HYDRAULIC CIRCUIT


K2

S RANGE; 3RD GEAR



L RANGE; 1ST GEAR


- OPERATING LINE PRESSURE
- LINE PRESSURE
- OIL PUMP FEEDBACK PRESSURE
- PILOT PRESSURE
- THROTTLE PRESSURE (LINE PRESSURE SOL. OUTPUT PRESSURE)
- MODIFIER PRESSURE
- ACCUMULATOR CONTROL PRESSURE
- 1ST REDUCING PRESSURE
- OVERRUNNING CLUTCH REDUCING PRESSURE
- TORQUE CONVERTER PRESSURE



HYDRAULIC CIRCUIT

K2

L RANGE; 2ND GEAR



AUTOMATIC TRANSMISSION (TRANSFER CASE)

INDEX	K3- 2
OUTLINE	K3- 3
SPECIFICATION	K3- 3

0BU0K3-001

INDEX

4x4
INDICATOR
LAMP
SERVICE,
SECTION T



HOLD
INDICATOR
LAMP
SERVICE,
SECTION T



HOLD

NEUTRAL
INDICATOR
LAMP
SERVICE,
SECTION T



A/T OIL
TEMP
INDICATOR
LAMP
SERVICE,
SECTION T


A/T
OIL TEMP





AUTOMATIC TRANSMISSION FLUID
SERVICE,
SECTION K2



TRANSFER CASE OIL SERVICE,
SECTION J3



TRANSFER CASE SERVICE, SECTION J3



AUTOMATIC TRANSMISSION SERVICE, SECTION K2

OUTLINE

SPECIFICATIONS

Item	Engine/Transmission		B2600I
			R4AX-EL
			4x4
Synchromesh system			Constant-mesh
Shift type			
Gear ratio	Low		2.210
	High		1.000
Oil	Grade		API Service GL-4 or GL-5
	Viscosity	Above 10°C (50°F)	SAE 80W-90
		All season type	SAE 75W-90
Capacity	liters (US qt, Imp qt)		2.0 (2.1, 1.8)

1BU0K3-001

K3