


BRAKING SYSTEM

INDEX	P- 2
OUTLINE	P- 3
SPECIFICATIONS	P- 3
CONVENTIONAL BRAKE SYSTEM	P- 4
PREPARATION	P- 4
TROUBLESHOOTING GUIDE	P- 4
BRAKE HYDRAULIC LINE	P- 5
BRAKE PEDAL	P- 7
MASTER CYLINDER	P- 9
POWER BRAKE UNIT	P-13
FRONT BRAKE (DISC)	P-19
REAR BRAKE (DRUM, 4x4)	P-23
REAR BRAKE (DRUM, 4x2)	P-27
PROPORTIONING BYPASS VALVE (PBV)	P-30
PARKING BRAKE SYSTEM	P-31
TROUBLESHOOTING GUIDE	P-31
PARKING BRAKE LEVER	P-31
PARKING BRAKE CABLE	P-33
REAR-WHEEL ANTI-LOCK BRAKE SYSTEM (REAR-WHEEL ABS)	P-35
PREPARATION	P-35
DESCRIPTION	P-35
TROUBLESHOOTING GUIDE	P-36
CONTROL UNIT	P-52
HYDRAULIC UNIT	P-53
SPEED SENSOR	P-54
SENSOR ROTOR	P-55
PRESSURE DIFFERENTIAL SWITCH	P-55
WIRING DIAGRAM	P-56

INDEX

FLUID SPECIFICATION
FMVSS 116 DOT-3 or SAE J1703



2BU0PX-022

- | | |
|---|--|
| <p>1. Brake hydraulic line
On-vehicle inspection page P- 5
Removal and Installation page P- 5
Air bleeding page P- 5</p> <p>2. Brake pedal
On-vehicle inspection page P- 7
Removal, Installation and
Inspection page P- 8</p> <p>3. Master cylinder
Removal and Installation page P- 9
Inspection page P-10
Disassembly, Assembly and
Inspection page P-11</p> <p>4. Power brake unit
On-vehicle inspection page P-13
Removal and Installation page P-15
Disassembly and Inspection
(4x2) page P-16
Assembly (4x2) page P-17</p> <p>5. Front brake (disc)
On-vehicle inspection page P-19
Replacement page P-19
Removal and Installation page P-20
Inspection page P-21
Disassembly (caliper) page P-21
Inspection (caliper) page P-22
Assembly (caliper) page P-22</p> | <p>6. Rear brake (drum, 4x4)
Removal, Installation and
Inspection page P-23
Disassembly, Assembly and
Inspection (wheel cylinder) page P-26
Rear brake (drum, 4x2)
Removal, Installation and
Inspection page P-27
Disassembly, Assembly and
Inspection (wheel cylinder) page P-29</p> <p>7. Proportioning bypass valve (PBV)
Function check page P-30
Removal and Installation page P-30</p> <p>8. Parking brake lever
On-vehicle inspection page P-31
Removal, Installation and
Inspection page P-32</p> <p>9. Parking brake cable
Removal and Installation page P-33</p> <p>10. ABS control unit
Inspection page P-52</p> <p>11. ABS hydraulic unit
Removal and Installation page P-53</p> <p>12. ABS speed sensor
Removal, Inspection,
Installation page P-54</p> <p>13. Pressure differential switch
On-vehicle inspection page P-55</p> |
|---|--|

OUTLINE

SPECIFICATIONS




Item		Model	4x4	4x2	
Brake pedal	Type		Suspended		
	Pedal lever ratio		3.75	4.5	
	Max. stroke	mm (in)	112.5 (4.43)	135 (5.31)	
Master cylinder	Type		Tandem (with level sensor)		
	Cylinder inner diameter	mm (in)	22.22 (0.875)		
Front disc brake	Type		Ventilated disc		
	Cylinder inner diameter	mm (in)	53.98 (2.125)		
	Pad dimensions (area x thickness)	mm ² x mm (in ² x in)	4,800 x 10.0 (7.44 x 0.39)		
	Disc plate dimensions	mm (in) (outer diameter x thickness)	272 x 22 (10.7 x 0.87)	256 x 20 (10.1 x 0.79)	
Rear drum brake	Type		Duo-servo	Leading-trailing	
	Wheel cylinder inner diameter	mm (in)	17.46 (0.688)	19.05 (0.750)	
	Lining dimensions	mm (in) (width x length x thickness)	Ⓟ 50 x 248 x 5 (1.97 x 9.76 x 0.20) Ⓢ 50 x 260 x 5 (1.97 x 10.24 x 0.20)	45 x 261 x 6.3 (1.77 x 10.28 x 0.25)	
	Drum inner diameter	mm (in)	260 (10.24)		
	Shoe clearance adjustment		Increment type automatic adjuster		
Power brake unit	Type		Tandem	Single	
	Size	mm (in)	187 + 213 (7.36 + 8.39)	238 (9.37)	
Braking force control device	Type		Rear-wheel Anti-lock Brake System		
Brake fluid			FMVSS 116 DOT-3 or SAE J1703		
Parking brake	Type		Mechanical, 2 rear brakes		
	Operation system		Stick type		

2BU0PX-001

Ⓟ Primary
Ⓢ Secondary

CONVENTIONAL BRAKE SYSTEM

PREPARATION


<p>49 0259 770B Wrench, flare nut</p> 	<p>49 F043 001 Adjust gauge</p> 	<p>49 0221 600C Expand tool, disc brake</p> 
---	---	---

2BU0PX-002


TROUBLESHOOTING GUIDE

Problem	Possible cause	Remedy	Page
Poor braking	Leakage of brake fluid Air in system Worn pad or lining Brake fluid, grease, oil, or water on pad or lining Hardening of pad or lining surface or poor contact Malfunction of disc brake piston Malfunction of master cylinder or wheel cylinder Malfunction of power brake unit Malfunction of check valve (vacuum hose) Damaged vacuum hose Deterioration of flexible hose Malfunction of PBV	Repair Bleed air Replace Clean or replace Grind or replace Replace Repair or replace Repair or replace Repair or replace Replace Replace Replace	— P-5 P-19,23,27 P-19,23,27 P-19,23,27 P-21 P-9 P-15 P-15 P-15 — P-30
Brakes pull to one side	Worn pad or lining Brake fluid, grease, oil, or water on pad or lining Hardening of pad or lining surface or poor contact Abnormal wear or distortion of disc, drum, pad, or lining Malfunction of automatic adjuster Looseness of backing plate mounting bolts Malfunction of wheel cylinder Improperly adjusted wheel alignment Unequal tire air pressures	Replace Clean or replace Grind or replace Repair or replace Repair or replace Tighten Repair or replace Adjust Repair or replace	P-19,23,27 P-19,23,27 P-19,23,27 P-19,23,27 — P-23,27 P-23,27 Section R Section Q
Brakes do not release	No brake pedal play Improperly adjusted push rod clearance Clogged master cylinder return port Weak shoe return spring Wheel cylinder not returning properly Malfunction of piston seal of disc brake Excessive runout of disc plate	Adjust Adjust Clean Replace Clean or replace Replace Replace	P-7 P-10 — P-23,27 P-23,27 P-21 Section M
Pedal goes too far (too much pedal stroke)	Air in system Improperly adjusted pedal play Worn pad or lining	Bleed air Adjust Replace	P-5 P-7 P-19,23,27
Abnormal noise or vibration during braking	Worn pad or lining Deteriorated pad or lining Brakes do not release Foreign material or scratches on disc plate or drum contact surface Looseness of backing plate or caliper mounting bolts Poor contact of pad or lining Insufficient grease on sliding parts	Replace Grind or replace Repair Clean Tighten Repair or replace Apply grease	P-19,23,27 P-19,23,27 — — P-23,27 P-19,23,27 —

1BU0PX-004



9MU0PX-007



9MU0PX-008

BRAKE HYDRAULIC LINE

On-vehicle Inspection

Check for the following and replace parts as necessary.

1. Cracking, damage, or corrosion of brake hose
2. Damage to brake hose threads
3. Scars, cracks, or swelling of flexible hose
4. All lines for fluid leakage

Removal and Installation

1. Loosen or tighten the flare nut with the SST.

Flare nut tightening torque:

13—22 N·m (1.3—2.2 m·kg, 9.4—16 ft·lb)

2. When connecting the flexible hose, do not overtighten or twist it.
3. After installation:
 - (1) Check that the hose does not contact other parts when the vehicle bounces or when the steering wheel is turned fully right or left.
 - (2) Bleed the air from the brake system.

Air-Bleeding

Air-bleeding locations are as follows:


Removed part			Air-bleeding locations		
			Front		Rear
			Right	Left	Left
Master cylinder			*	*	*
Wheel cylinder or caliper	Front	Right	*	*	—
		Left	*	*	—
	Rear	Right	—	—	*
		Left	—	—	*
Hydraulic unit			—	—	*
Proportioning bypass valve (PBV)			*	*	*

*: Indicates locations where air bleeding is necessary.


0MU0PX-076

Note


- a) Air bleeding must be done from the bleeder screw farthest from the removed parts to the nearest.
- b) It is not necessary to energize the solenoid valves electrically to bleed the rear brakes.




9MU0PX-010



2BU0PX-031



9MU0PX-012



2BU0PX-023

Bleed air as described below.

1. Jack up the vehicle and support it with safety stands.
2. Fill the reserve tank with brake fluid. Be sure that the reserve tank is at least half full at all times during the air bleeding process.

Caution

- a) Be careful not to spill brake fluid onto a painted surface.
- b) Use only the specified brake fluid. Do not mix it with any other type.

3. After removing the bleeder cap, connect one end of a transparent vinyl tube to the bleeder screw with the **SST** and place the other end in a receptacle.
4. One person should depress the brake pedal a few times, and then hold it in the depressed position.
5. A second person should loosen the bleeder screw, drain out the fluid, and retighten the screw.

Caution

- a) The two people should stay in voice contact with each other.
- b) Be sure the pedal remains depressed until the air bleed screw is tightened.

6. Repeat steps 4 and 5 until no air bubbles are seen.


Caution

- a) After tightening the bleeder screw, check to be sure that there is no fluid leakage.
- b) Be sure to clean away any spilled fluid with rags.


7. After bleeding the air, add brake fluid to the reserve tank up to the specified level.

Bleeder screw tightening torque


Front: 6—9 N·m (60—90 cm·kg, 52—78 in·lb)
Rear : 6—7 N·m (60—70 cm·kg, 52—61 in·lb)




2BU0PX-003



9MU0PX-015



9BU0PX-008



1BU0PX-007

BRAKE PEDAL On-vehicle Inspection Pedal height Inspection

Check that the distance from the center of the upper surface of the pedal pad to the carpet is as specified.

**Pedal height: 180—185mm (7.09—7.28 in)
(With carpet)**

Adjustment

1. Disconnect the stoplight switch connector.
2. Loosen locknut (B) and turn switch (A) until it does not contact the pedal.
3. Loosen locknut (D) and turn rod (C) to adjust the height.
4. Adjust the pedal free play and tighten locknut (D).
5. Turn the stoplight switch until it contacts the pedal; then turn an additional 1/2 turn. Tighten locknut (B).

**Locknut (B) tightening torque:
14—18 N·m (1.4—1.8 m·kg, 10—13 ft·lb)**

**Locknut (D) tightening torque:
20—29 N·m (2.0—3.0 m·kg, 14—22 ft·lb)**

6. Connect the stoplight switch connector.

Pedal play Inspection

1. Depress the pedal a few times to eliminate the vacuum in the system.
2. Gently depress the pedal again by hand and check the free play (until the valve plunger contacts the stopper plate = until the power piston begins to move).

Pedal play: 4.0—7.0mm (0.16—0.28 in)

Adjustment

Loosen locknut (D) of operating rod (C); then turn the rod to adjust the free play.

**Locknut (D) tightening torque:
20—29 N·m (2.0—3.0 m·kg, 14—21 ft·lb)**

Pedal-to-floor clearance Inspection

Check that the distance from the floor panel to the center of the upper surface of the pedal pad is as specified when the pedal is depressed with a force of **589 N (60 kg, 132 lb)**.

**Pedal-to-floor clearance: 105mm (4.1 in) min.
(Without carpet)**

If the distance is less than specified, check for the following problems:

1. Air in brake system
2. Malfunction of automatic adjuster (rear drum brakes)
3. Worn shoes or pads


CONVENTIONAL BRAKE SYSTEM

Removal, Installation, and Inspection

1. Remove in the order shown in the figure.
2. Inspect all components and parts. Replace parts if necessary.
3. Install in the reverse order of removal.
4. After installation, check and adjust the pedal height and free play if necessary.

Caution

Apply grease to the inner surface of the bushing and to the contact surfaces of the clevis pin and spring.



- 1. Cotter pin
- 2. Clevis pin
- 3. Return spring
Inspect for weakness or damage
- 4. Nut
- 5. Bolt
Inspect for bending

- 6. Brake pedal
Inspect for bending
- 7. Bushing
Inspect for wear
- 8. Pedal pad
Inspect for wear or damage
- 9. Rubber stopper
Inspect for wear or damage

N-m (m-kg, ft-lb)

2BU0PX-024


MASTER CYLINDER

Removal and Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal.
3. After installation, add brake fluid, bleed air, and check for fluid leakage.


Caution

Brake fluid will damage painted surfaces. If it does get on a painted surface, wipe it off immediately.



N-m (m-kg, ft-lb)
2BU0PX-004


- | | |
|-------------------------------|---------------------------------------|
| 1. Fluid level sensor coupler | 4. Reserve tank and master cylinder |
| 2. Brake pipe | Installation Note..... page P-10 |
| Removal Note..... below | 5. Proportioning bypass valve bracket |
| 3. Nuts and washers | |




9MU0PX-020

Removal note
Brake pipe


Disconnect/connect the brake pipe from/to the master cylinder with the **SST**.




2BU0PX-005




9MU0PX-022



2BU0PX-006



1BU0PX-009



2BU0PX-007

Installation note
Reserve tank and master cylinder
Push rod clearance

Check the clearance between the push rod of the power brake unit and the piston of the master cylinder.

1. Place the **SST** a top the master cylinder. Turn the adjusting bolt until it bottoms in the push rod hole in the piston.
2. Apply **500 mmHg (19.7 inHg)** vacuum to the power brake unit with a vacuum pump.
3. Invert the adjustment gauge used in Step 1, and place it on the power brake unit.
4. Check the clearance between the end of the adjusting bolt and the push rod of the power brake unit. If it is not **0mm (0 in)**, loosen the push rod locknut and turn the push rod to make the adjustment.

Reference

By making the above adjustment, the clearance between the push rod and piston (after installation of the brake master cylinder and the power brake unit) will be as shown in the table below.

	Push rod-to-piston clearance
When vacuum applied to unit is approx. 500 mmHg (19.7 inHg)	0.1—0.4mm (0.004—0.016 in)

Inspection of fluid level sensor


1. Disconnect the fluid level sensor connector.
2. Fill the reservoir with brake fluid up to the specified level.
3. Connect a circuit tester to the connector.
4. Check for continuity when the float is moved up and down.
5. The sensor is good if there is continuity when the float is below the "MIN" mark, and there is no continuity when the float is above it.
6. Replace the sensor if necessary.

Disassembly, Assembly, and Inspection

1. After removing the brake fluid, disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all components and parts.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.


Caution

- a) Secure the master cylinder flange in a vise when necessary.
- b) Replace the piston assembly, if necessary.
- c) Do not let foreign material enter the cylinder, and do not scratch the inside of the cylinder or the outer surface of the piston.



2BU0PX-008


- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Fluid level sensor 2. Screw 3. Reserve tank assembly
Inspect for damage or deformation 4. Bushings 5. Stopper screw and O-ring
Assembly Note page P-12 6. Snap ring
Disassembly Note page P-12 | <ol style="list-style-type: none"> 7. Primary piston assembly
Inspect for abnormal wear, rust, or damage 8. Secondary piston assembly
Disassembly Note page P-12
Inspect for abnormal wear, rust, or damage 9. Cylinder
Inspect for abnormal wear, rust, or damage |
|--|---|



9MU0PX-027

Disassembly note**Snap ring**

Push the piston in to remove or install the snap ring with snap-ring pliers.




9MU0PX-028

Secondary piston assembly

Remove the secondary piston assembly by gradually blowing compressed air into the cylinder.

Caution


Use a rag to catch the secondary piston assembly.




2BU0PX-009

Assembly note**Stopper screw and O-ring**


1. Push the primary piston assembly in fully.
2. Install and tighten the stopper screw and new O-ring.
3. Push and release the piston to verify that it is held by the stopper screw.




9MU0PX-030




9MU0PX-031



9MU0PX-032



9MU0PX-033



9MU0PX-034

POWER BRAKE UNIT

On-vehicle Inspection

Power brake unit function check (Simple method)

Step 1

1. With the engine stopped, depress the pedal a few times.
2. With the pedal depressed, start the engine.
3. If immediately after the engine starts the pedal moves down slightly, the unit is operating.

Step 2

1. Start the engine.
2. Stop the engine after it has run for **1 or 2 minutes**.
3. Depress the pedal with the usual force.
4. If the first pedal stroke is long and becomes shorter with subsequent strokes, the unit is operating.
5. If a problem is found, inspect for damage of the check valve or vacuum hose, and examine the installation. Repair if necessary, and inspect it once again.

Step 3

1. Start the engine.
2. Depress the pedal with the usual force.
3. Stop the engine with the pedal held depressed.
4. Hold the pedal down for **about 30 seconds**.
5. If the pedal height does not change, the unit is operating.
6. If there is a problem, check for damage to the check valve or vacuum hose, and check the connection. Repair if necessary, and check once again.

If the nature of the problem is still not clear after following the 3 steps above, follow the more detailed check described in "Method-using tester," below.

(Method-using tester)

Connect a pressure gauge, vacuum gauge, and pedal depression force gauge as shown in the figure. After bleeding the air from the pressure gauge, conduct the test as described in the 3 steps below.

Note


Use commercially available gauges and pedal depression force gauge.

a) Checking for vacuum loss


Unloaded condition

1. Start the engine.
2. Stop the engine when the vacuum gauge reading reaches **500 mmHg (19.7 inHg)**.
3. Observe the vacuum gauge for **15 seconds**. If the gauge shows **475—500 mmHg (18.7—19.7 inHg)**, the unit is operating.


CONVENTIONAL BRAKE SYSTEM




9MU0PX-035



9BU0PX-013



9BU0PX-014



9MU0PX-038

Loaded condition

1. Start the engine.
2. Depress the brake pedal with a force of **196 N (20 kg, 44 lb)**.
3. With the brake pedal depressed, stop the engine when the vacuum gauge reading reaches **500 mmHg (19.7 inHg)**.
4. Observe the vacuum gauge for **15 seconds**. If the gauge shows **475–500 mmHg (18.7–19.7 inHg)**, the unit is operating.

b) Checking for hydraulic pressure

1. If with the engine stopped (vacuum **0 mmHg**) the fluid pressure is within specification, the unit is operating.

Pedal force	Fluid pressure
147 N (15 kg, 33 lb)	1,962 kPa (20.0 kg/cm ² , 284 psi) min...Tandem 1,078 kPa (11.0 kg/cm ² , 156 psi) min...Single

2. Start the engine. Depress the brake pedal when the vacuum reaches **500 mmHg (19.7 inHg)**. If the fluid pressure is within specification, the unit is operating.

Pedal force	Fluid pressure
147 N (15 kg, 33 lb)	5,886 kPa (60.0 kg/cm ² , 853 psi) min...Tandem 5,390 kPa (55.0 kg/cm ² , 782 psi) min...Single

Inspection of check valve

Note

The check valve is pressed into the vacuum hose. There is an arrow on the hose to indicate direction of hose installation.

Inspection


1. Disconnect the vacuum hose from the engine.
2. Apply suction and pressure to the hose from the engine side. Check that air flows only toward the engine. If the air passes in both directions or not at all, replace the check valve (along with the hose).

Removal and Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.
3. Take the following steps after installation:
 - (1) Check and adjust the push rod and piston clearance. (Refer to page P-10.)
 - (2) Add fluid and bleed the air. (Refer to page P-5.)
 - (3) Check all parts for fluid leakage.
 - (4) Make an on-vehicle check of the unit. (Refer to page P-13.)
 - (5) Check that the vacuum hose does not contact other parts.

Caution

Apply sealant to the gasket contact surface.



1. Nuts and washers
2. Master cylinder
Removal and Installation page P-9
3. Proportioning bypass valve bracket
4. Vacuum hose
5. Cotter pin
6. Clevis pin
7. Nuts


8. Power brake unit
Disassembly and Inspection
(Single diaphragm, 4x2) page P-16
Assembly page P-17
9. Gasket

Note
Do not disassemble the tandem diaphragm power brake unit (4x4).

CONVENTIONAL BRAKE SYSTEM

Disassembly and Inspection (Single diaphragm, 4x2)


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Wipe free of fluid and carefully inspect all rubber parts for cuts, nicks, or other damage.
3. Inspect all components and parts. Replace parts if necessary.
4. Make sure the seats of the valve rod and plunger are smooth and free of nicks and scars. Replace if defective.



2BU0PX-011

- 1. Dust boot
- 2. Rear shell assembly
Disassembly Note..... page P-17
Inspect for scratches, scores, pits, dents, or other damage
- 3. Retainer
- 4. Bearing
- 5. Dust seal
- 6. Retainer
- 7. Air filter
- 8. Air silencer
- 9. Diaphragm and plate
Inspect for cuts or other damage

- 10. Power piston assembly
Inspect for cracks, distortion, chipping, or damaged seats
- 11. Retainer key
Disassembly Note..... page P-17
- 12. Valve rod and plunger assembly
- 13. Reaction disc
Inspect for deterioration
- 14. Spring
- 15. Push rod
- 16. Front shell assembly
Inspect for scratches, scores, pits, dents, or other damage
- 17. Retainer
- 18. Seal




2BU0PX-025

Disassembly note
Rear shell assembly

1. Before separating the front and rear shells, make mating marks to be used in reassembly.
2. Fit a locally obtained spanner onto the studs of the rear shell, and rotate the rear shell counterclockwise to unlock it.

Caution

The rear shell is spring loaded; loosen it carefully.




9MU0PX-042

Retainer key

Press the valve rod in to remove the valve retainer key. Remove the valve rod and plunger assembly.

Caution


The valve rod and plunger must be serviced as an assembly.



2BU0PX-012

Assembly (4x2)

1. Install the valve rod and plunger assembly.
2. Install the new air filter and silencer.
3. Install a new retainer.




9MU0PX-044

4. Install the retainer key.

Caution

Push down the valve rod, align the groove in the valve plunger with the slot of the power piston, and insert the valve retainer key.




0BU0PX-060

5. Connect the new diaphragm to the power piston and new plate.

Caution

Make certain the diaphragm is well seated in the groove.

CONVENTIONAL BRAKE SYSTEM




9MU0PX-046

6. Assemble the rear shell assembly.


Caution

Carefully guide the tube end of the power piston through the seal in the rear shell.



9MU0PX-047

7. Push the reaction disc into the power piston with the push rod.




0BU0PX-061

8. Put the new dust seal and new retainer into the front shell.


Caution

Place the front shell assembly in a vise to complete the following operations.




9MU0PX-049

9. Install the push rod.
10. Install the return spring.



9MU0PX-050

11. Press the rear shell down and rotate it clockwise until the matching marks are aligned.
12. Set the dust boot onto the rear shell.




9BU0PX-017

FRONT BRAKE (DISC)

On-vehicle Inspection

Disc pad

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Sight through the caliper inspection hole and see if the remaining thickness of the pad is at least **3.0mm (0.118 in)**.



9MU0PX-066


Replacement

Disc pad

Caution

Replace the left and right pads as a set.

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove the lower lock-pin bolt; then lift the caliper and support it.
4. Remove the pads.
5. Push the piston inward with the **SST**.
6. Install the new pads in the mounting support.



9BU0PX-018

7. Lower the caliper assembly onto the mounting support.
8. Tighten the lock bolt to the specified torque.


Tightening torque:

31—41 N·m (3.2—4.2 m·kg, 23—30 ft·lb)

9. Mount the wheels.

Caution

Apply the brakes 2—3 times. Rotate the wheels and check to see if the brakes drag.



9BU0PX-019

10. Lower the vehicle.


CONVENTIONAL BRAKE SYSTEM

Removal and Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels; then remove components in the order shown in the figure.
3. Install in the reverse order of removal.
4. Tighten all nuts and bolts to the specified torque, referring to the figure.
5. After installation, add brake fluid, bleed air, and check for fluid leakage.
6. Install the wheels.

Tightening torque: Non-styled wheel 88—118 N-m (9—12 m-kg, 65—87 ft-lb)
Styled wheel 118—147 N-m (12—15 m-kg, 87—108 ft-lb)


7. Lower the vehicle.



N-m (m-kg, ft-lb)
 2BU0PX-013

- 1. Clip
- 2. Bolt
- 3. Brake hose
- 4. Lock bolts
- 5. Brake caliper assembly
 - Disassembly page P-21
 - Assembly page P-22

- 6. Disc pad
 - Inspection page P-21
- 7. Shims
- 8. Bolts
- 9. Mounting support
- 10. Disc plate
 - Removal and Installation Section M
 - Inspection page P-21



0BU0PX-062


Inspection

Check the following and replace parts as necessary.

Disc pad

1. Oil or grease on facing
2. Abnormal wear or cracks
3. Deterioration or damage by heat
4. Remaining lining thickness

Thickness: 3.0mm (0.118 in) min.



9BU0PX-022


Disc plate

1. Runout.

Runout: 0.15mm (0.006 in) max.

Caution

- a) There must be no wheel bearing looseness.
- b) The measurement location is the outer edge of the disc plate surface.



9BU0PX-023

2. Wear or damage.

Thickness

4x4 model


Standard value: 22mm (0.87 in)

Minimum: 20mm (0.79 in)

4x2 model

Standard value: 20mm (0.79 in)

Minimum: 18mm (0.71 in)




9BU0PX-024

Disassembly (Caliper)

Disassemble in the order shown in the figure, referring to **Disassembly note**.

1. Piston
2. Dust seal
3. Piston seal
4. Bleeder screw and cap
5. Pin boot
6. Pin
7. Bushing



9MU0PX-075

Disassembly note


Piston

Place a piece of wood in the caliper; then blow compressed air through the hole to force the piston out of the caliper.

Caution

Blow the compressed air slowly to prevent the piston from popping out.

CONVENTIONAL BRAKE SYSTEM




9MU0PX-076

Inspection (Caliper)

Inspect each part; if necessary replace parts.


1. Cylinder and piston for wear or rust
2. Caliper body for damage or cracks
3. Boot for damage or poor sealing



2BU0PX-026


Assembly (Caliper)

1. Coat a new piston seal with the grease supplied in the seal kit; then install it in the caliper.



2BU0PX-027

2. Coat the piston and the cylinder with brake fluid and insert the piston squarely into the cylinder.
3. Coat a new dust seal with the grease supplied in the seal kit; then install it in the caliper.



2BU0PX-028

4. Coat the following parts with pink grease.

- (1) Pin (outside).
- (2) Pin boot (inside and outside)
- (3) Bushing (inside)
- (4) Bleeder screw cap (inside)

Tightening torque:

6—9 N·m (60—90 cm·kg, 52—78 in·lb)

5. Install the bleeder screw and cap.
6. Fit the pin boot and pin to the caliper, and fit the bushing to the lock pin.

REAR BRAKE (DRUM, 4x4)

Removal, Installation, and Inspection

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels and remove the brakes in the order shown in the figure, referring to **Removal Note**.
3. Inspect all components and parts. Replace parts if necessary.
4. Install in the reverse order of removal.
5. After installation, add brake fluid, bleed the air, and check for fluid leakage.
6. Install the wheels.

Tightening torque: Non-styled wheel 88—118 N·m (9—12 m·kg, 65—87 ft·lb)
Styled wheel 118—147 N·m (12—15 m·kg, 87—108 ft·lb)


7. Lower the vehicle.
8. Adjust the parking lever stroke. (Refer to page P-31.)

Note

Before removal, release the parking brake.

Caution

There are identification marks in the hold springs because they are different between the primary side and secondary side. Use correct hold springs for each side, otherwise, it may cause the malfunction of automatic adjuster.



1. Brake drum
Inspection page P-24
2. Parking brake cable
3. Hold spring and sleeve, pin


Caution

Primary side Yellow
Secondary side White

4. Adjust lever
5. Link
6. Pull-off spring
7. Shoe spring
8. Return spring

9. Return spring
10. Adjuster
11. Primary brake shoe
Inspection page P-24
Adjustment of brake shoes page P-25
12. Secondary brake shoe
Inspection page P-24
Adjustment of brake shoes page P-25
13. Strut
14. Brake pipe
Removal Note page P-24
15. Wheel cylinder assembly
Disassembly, Assembly and
Inspection page P-26

CONVENTIONAL BRAKE SYSTEM



9MU0PX-081


Removal note

Brake pipe

Disconnect or connect the brake pipe from/to the wheel cylinder with the **SST**.

Tightening torque:

13—22 N·m (1.3—2.2 m·kg, 9.4—16 ft·lb)



9MU0PX-082

Inspection


Check for the following and repair or replace parts as necessary.

Brake drum

1. Scratches, uneven or abnormal wear inside drum

Note

Repair if the problem is minor.



9MU0PX-083


2. Drum inner diameter

Standard diameter: 260mm (10.24 in)

Diameter limit: 261.5mm (10.30 in)

Caution

When repairing or replacing the drum, check the contact with the shoe.



9MU0PX-084


Brake shoe

1. Peeling, cracking, or extremely uneven wear of lining
2. Lining wear

Thickness: 1.0mm (0.04 in) min.

Caution

When replacing the shoe assembly, replace as a set and with shoes of the same quality.




9MU0PX-085

Installation note

Brake shoe


When installing the brake shoes, be careful not to confuse the primary and secondary shoes.



9MU0PX-086

Grease points

- (1) Piston of wheel cylinder
- (2) Anchor sliding parts
- (3) Projection of backing plate
- (4) Adjusting screw
- (5) Adjusting sleeve contact surfaces



(L.H.)


9MU0PX-087

Adjustment of brake shoes


The rear brakes are self-adjusting and require a manual adjustment only after the brake shoes have been replaced or when the operating lever has been moved during some other service operation.

To adjust the rear brake shoes, proceed as follows:

1. Jack up the rear of the vehicle until the wheels are free to turn. Then support it with safety stands.
2. Make sure the parking brake is fully released.
3. Remove the two hole plugs from the backing plate.
4. Place a screwdriver against the adjuster through hole (A) and turn the adjuster in the direction of the arrow marked on the backing plate until the wheel is locked.
5. Using hole (B), push the pawl lever of the self-adjuster and back off the star wheel about **8—10 notches** so that the drum rotates freely without drag.
6. Repeat the above adjustment on the other rear wheel. The adjustment must be the same on both rear wheels.
7. Adjust the parking lever stroke. (Refer to page P-31.)
8. Install the hole plugs into the backing plate.



9MU0PX-088



2BU0PX-029

CONVENTIONAL BRAKE SYSTEM

Disassembly, Assembly, and Inspection (Wheel cylinder)


1. Disassemble in the order shown in the figure.
Inspect all components and parts. Replace parts if necessary.
2. Assemble in the reverse order of disassembly.

Note

- a) Use a new boot set.
- b) Apply brake fluid to the points shown in the figure.

Caution

Do not allow foreign material to enter, and do not scratch the inside of the cylinder or the outer surface of the pistons.



1BU0PX-016

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Dust boot 2. Piston
Inspect for wear of contact surface 3. Piston rubber cup 4. Spring
Inspect for wear or breaks | <ol style="list-style-type: none"> 5. Rubber cap 6. Bleeder screw 7. Steel ball 8. Wheel cylinder
Inspect for wear, rust, or damage |
|---|---|

REAR BRAKE (DRUM, 4x2)

Removal, Installation, and Inspection


1. Jack up the rear of the vehicle, and support it with safety stands.
2. Remove the wheels, then the rear drum brakes in the sequence shown in the figure.
3. Inspect all components and parts. Replace parts if necessary.
4. Install in the reverse order of removal.
5. After installation, add brake fluid and bleed the air; then check for fluid leakage.
6. Install the wheels.

Tightening torque: Non-styled wheel 88—118 N·m (9—12 m·kg, 65—87 ft·lb)
Styled wheel 118—147 N·m (12—15 m·kg, 87—108 ft·lb)

7. Lower the vehicle.
8. Adjust the parking brake lever stroke. (Refer to page P-31.)

Note


Before removal, release the parking brake.



N·m (m·kg, ft·lb)

2BU0PX-015

- | | | |
|--|---|---|
| <ol style="list-style-type: none"> 1. Brake drum
Inspection..... page P-28 2. Parking brake cable 3. Return spring 4. Brake shoe spring 5. Brake shoe pin | <ol style="list-style-type: none"> 6. Brake shoe
Inspection..... page P-28
Brake shoe
adjustment..... page P-28 7. Adjust screw 8. Operating lever | <ol style="list-style-type: none"> 9. Pawl lever return spring 10. Pawl lever 11. Brake pipe
Removal Note .. page P-24 12. Wheel cylinder assembly
Disassembly, Assembly
and Inspection
..... page P-29 |
|--|---|---|



9BU0PX-028

Inspection

Inspect for the following problems, and repair or replace any faulty parts.

Brake drum

1. Scratches and uneven or abnormal wear inside the drum.

Note


Repair if the problem is minor.

2. Drum inner diameter

Standard diameter: 260mm (10.24 in)
Diameter limit : 261.5mm (10.30 in)

Caution

When repairing or replacing the drum, examine the contact with the shoe.



4BG11X-666


Brake shoe

1. Peeling, cracks, and extremely uneven wear of the lining.
2. Wear of the lining.

Thickness limit: 1.0mm (0.04 in)

Caution


When replacing the shoe assembly, replace it as a set and with an assembly of the same quality.



9BU0PX-029

Grease points

Before installation, apply grease to the wheel cylinder and anchor sliding parts (⇔), the projections of the backing plate (→).




8BU11X-027


Brake Shoe Adjustment

To adjust the rear brake shoes, proceed as follows:

1. Jack up the rear of the vehicle until the wheels are free to turn. Then support it with stands.
2. Make sure the parking brake is fully released.
3. Remove the two shoe-adjusting hole plugs from the back of the backing plate.



7BU11X-070



4. Place a screwdriver against the star wheel of the adjust screw through hole (A), and turn the star wheel toward the arrow direction (←) marked on the backing plate until the wheel is locked.
5. Through hole (B), push the pawl lever of the self-adjuster with a suitable drift, and back off the star wheel about **6—7 notches** so that the drum rotates freely without drag.
6. Repeat this adjustment on the other rear wheel. The adjustment must be the same on both rear wheels.
7. Adjust the parking lever stroke. (Refer to page P-31.)
8. Install the adjusting hole plugs into the backing plate.

Disassembly, Assembly, and Inspection (Wheel cylinder)


1. Disassemble in the order shown in the figure.
2. Inspect all components and parts. Replace parts if necessary.
3. Assemble in the reverse order of disassembly.

Note

- a) Use a new boot set.
- b) Apply brake fluid to the points shown in the figure.

Caution

Do not allow foreign material to enter, and do not scratch the inside of the cylinder or the outer surface of the pistons.



N·m (cm·kg, In·lb)

1BU0PX-019

1. Dust boot
2. Piston
Inspect for wear of contact surface
3. Piston rubber cup
4. Spring
Inspect for wear or breaks


5. Rubber cap
6. Bleeder screw
7. Steel ball
8. Wheel cylinder
Inspect for wear, rust, or damage

CONVENTIONAL BRAKE SYSTEM


PROPORTIONING BYPASS VALVE (PBV)

Function Check

As shown in the figure, connect two pressure gauges (9,810 kPa [100 kg/cm², 1,422 psi]), depress the brake pedal, and measure the fluid pressure of the master cylinder and the fluid pressure to the rear brakes.



OBU0PX-022



OBU0PX-023


Fluid pressure		kPa (kg/cm ² , psi)	
A	A'	B	B'
3,826 (39,555)	3,826 ± 294 (39 ± 3.0, 555 ± 43)	7,848 (80, 1,138)	6,180 ± 294 (63 ± 3.0, 896 ± 43)

Caution

If there is a malfunction of the valve, replace it as an assembly.

Removal and Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal.
3. After installation, bleed the air from the brake system. (Refer to page P-5.)



N-m (m-kg, ft-lb)

2BU0PX-016


1. Pressure differential switch coupler

2. Brake pipes

Removal Note..... page P-31

3. Bolt

4. Proportioning bypass valve



1BU0PX-021

Removal note

Brake pipes


Disconnect or connect the brake pipes from/to the proportioning bypass valve with the **SST**.

PARKING BRAKE SYSTEM

TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
Brakes do not release	Improper return of parking brake cable or improper adjustment	Repair or adjust	P-31
Parking brake does not hold well	Excessive lever stroke Brake cable stuck or damaged Brake fluid or oil on lining Hardening of lining surface or poor contact	Adjust Repair or replace Clean or replace Grind or replace	P-31 P-33,34 P-23,27 P-23,27

1BU0PX-022



0BU0PX-026


PARKING BRAKE LEVER

On-vehicle Inspection

Inspection

Check that the stroke is within specification when the parking brake lever is pulled with a force of **196 N (20 kg, 44 lb)**.

Stroke: 7—12 notches



7BU11X-012

Adjustment

1. Before adjustment, depress the brake pedal several times while the vehicle is moving in reverse.
2. Loosen locknut (A) and turn the adjusting nut (B) so that the stroke is within the above range.
3. After adjustment, tighten locknut (A).

Tightening torque:

7—10 N·m (0.7—1.0 m·kg, 5—7 ft·lb)

4. Make sure that the parking brake warning light illuminates when the brake lever is pulled one notch.


Caution

Be sure that the brakes are not dragging.

PARKING BRAKE SYSTEM

Removal, Installation, and Inspection

1. Block the wheels firmly.
2. Release the parking brake.
3. Remove in the order shown in the figure.
4. Inspect all components and parts. Replace parts if necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. After installation:
Adjust the parking lever stroke. (Refer to page P-31.)




N-m (m-kg, ft-lb)
2BUOPX-017

- | | | |
|----------------------------|------------------------------|--|
| 1. Clip | 11. Parking-brake switch | 20. Fork joint |
| 2. Joint pin | Installation Notebelow | 21. Spring |
| 3. Parking cable connector | | Inspect for weakness or breakage |
| 4. Bolt | 12. Bolt and nut | 22. Guide |
| 5. Bolt | 13. Pin | 23. Stopper |
| 6. Bolt and nut | 14. Clip and joint pin | 24. Stopper seat |
| 7. Harness band connector | 15. Lever | 25. Rod |
| 8. Nut | 16. Pin and clip | Inspect sector and ratchet pawl for wear or damage |
| 9. Bolt | 17. Spring | |
| 10. Bracket | 18. Ratchet pawl | |
| | 19. Stopper | |

Installation note Parking brake switch


1. Install the parking brake switch so that it contacts the parking brake lever when the lever is fully released.
2. Turn the ignition switch ON, and check that the parking brake warning lamp illuminates with the lever pulled one notch.



9MUOPX-110

PARKING BRAKE SYSTEM

4x2



N-m (m-kg, ft-lb)

1BU0PX-025

- | | |
|--------------------------|------------------------|
| 1. Nut | 7. Bolts |
| 2. Bolt | 8. Spring |
| 3. Front brake cable | 9. Clip |
| 4. Spring | 10. Rear cable (left) |
| 5. Brake cable connector | 11. Rear cable (right) |
| 6. Clip | |

REAR-WHEEL ANTI-LOCK BRAKE SYSTEM (REAR-WHEEL ABS)

PREPARATION

SST

49 0259 770B


Wrench, flare nut



0MU0PX-021

DESCRIPTION

The Rear-wheel Anti-lock Brake System (Rear-wheel ABS) is equipped on all B2200 and B2600i. The ABS control unit senses the drop in rear wheel speed and modulates hydraulic pressure to the rear brakes, inhibiting lockup.



1BU0PX-026

- 1. Control unit
- 2. Hydraulic unit (Solenoid valves)
- 3. Speed sensor

- 4. ABS check connector
- 5. Pressure differential switch
- 6. ABS fuse

TROUBLESHOOTING GUIDE


Outline

The Rear-wheel ABS is composed of electrical components, mechanical components (hydraulic unit), and the components of the standard brake system.


Fundamentally, malfunction of the ABS electrical or mechanical components is judged by the self-diagnosis function within the ABS control unit. And malfunctions are indicated by the warning lamp in the instrument panel. The location of a malfunction is indicated by the technician obtaining a flashing pattern of the ABS warning lamp. The self-diagnosis and indication functions must be used when diagnosing malfunctions of the ABS.

1BU0PX-027


Troubleshooting Main Flowchart




1BU0PX-028



0MU0PX-025



1BU0PX-038



1BU0PX-029

Obtaining A Flashing Pattern

1. Locate the ABS check connector.

Note

The check connector (Blue: 3-pls), is located in the left in the engine compartment.

2. Attach a jumper wire to the terminal © (yellow wire) and ground it to the chassis for one second and release it. When the ground is made and broken the ABS warning lamp will begin to flash.

3. Count a flashing number of the ABS warning lamp.

Note

- a) A flashing pattern consists of a number of short flashes and ends with a long flash. Count the short flashes and include the long flash in the count.
- b) A same flashing pattern repeats until ignition switch is turned off. After the ignition switch is turned off, then when the ignition switch is turned on again, a same flashing pattern appears.
- c) If there is more than one system fault only the first recognized flashing pattern will be obtained.
- d) Verify the flashing pattern by reading it several times.

REAR-WHEEL ANTI-LOCK BRAKE SYSTEM

Flashing Pattern Chart

Number of flashing	Failure location	Failure condition	Flowchart number
1	—	(1 flash should not occur)	ABS-1
2	Hydraulic unit	Open in isolation solenoid circuit	ABS-2
3		Open in dump solenoid circuit	ABS-3
4		Solenoid valve switch closed	ABS-4
5	—	System dumps too many times in 4x2 (4x2 and 4x4 vehicles) (condition occurs while making normal or hard stops. Rear brake may lock.)	ABS-5
6	Speed sensor	(Speed sensor signal rapidly cuts in and out) condition only occurs while driving	ABS-6
7	Hydraulic unit	Shorted ground circuit (Isolation solenoid)	ABS-7
8		Shorted ground circuit (Dump solenoid)	ABS-8
9	Speed sensor	High speed sensor resistance	ABS-9
10		Low speed sensor resistance	ABS-10
11	Stoplight switch	Stoplight switch circuit defective. (Condition indicated only when driving above 56 km/h [35 mph])	ABS-11
12	—	(12 flashes should not occur)	ABS-12
13	Control unit	Control unit speed circuit phase lock loop failure detected during self-test	ABS-13
14		Control unit program check sum failure detected during self-test	ABS-14
15		Control unit RAM failure detected during self-test	ABS-15
16	—	(16 or more flashes should not occur)	ABS-16

1BU0PX-030

Diagnosis Flowchart

Caution

When checking resistance at the control unit terminals, always disconnect the battery cable. Improper resistance may occur with the vehicle battery connected.

When using a test lead for testing at the control unit terminals, use a fine needle to prevent damage to the terminal.

ABS-1	(1 flash should not occur)
--------------	----------------------------


After repeated attempts to take the flashing pattern, 1 flash is still obtained

Check for following:

- Intermittent power to control unit (Refer to page P-52)
- Grounded check connector lead (Refer to page P-52)
- Faulty control unit ground (Refer to page P-52)

1BU0PX-031

ABS-2	Open isolation solenoid circuit
--------------	---------------------------------

2a	Check for open isolation solenoid wiring or control unit as follows:
<ol style="list-style-type: none"> 1. Turn ignition switch to the OFF position 2. Disconnect battery cable 3. Set the ohmmeter to the 10 ohm scale 4. Disconnect control unit harness connector from control unit 5. Check for resistance between harness connector pin [C] (orange wire) and chassis ground 	
 <p>PIN [C]</p> <p>CONTROL UNIT HARNESS CONNECTOR</p>	

Resistance is 3 to 6 ohms

Replace control unit

Resistance over 6 ohms


Go to 2b

0BU0PX-035

REAR-WHEEL ANTI-LOCK BRAKE SYSTEM

2b Check for open isolation solenoid or wiring as follows:

1. Disconnect battery cable
2. Set ohmmeter to 10 ohm scale
3. Check resistance between valve connector isolation solenoid pin (orange/white wire) and connector ground pin (black wire)



SOLENOID VALVE CONNECTOR

Resistance is 3 to 6 ohms

Repair open in isolation solenoid wire from valve to control unit
Check for dirty or loose connector pins

Resistance over 6 ohms

Replace hydraulic unit

1MU0PX-026

ABS-3	Open dump solenoid circuit
--------------	----------------------------

3a	Check for open dump solenoid wiring or control unit as follows:
<ol style="list-style-type: none"> 1. Turn ignition switch to the off position 2. Disconnect battery cable 3. Disconnect control unit harness connector from control unit 4. Place the ohmmeter on the 10 ohm scale 5. Check resistance between pin [B] (orange/blue wire) or pin [A] (orange/blue wire) and chassis ground 	
<p style="text-align: center;">CONTROL UNIT HARNESS CONNECTOR</p>	

Resistance is 1 to 3 ohms

Replace control unit

Resistance greater than 3 ohms

Go to Test 3b

0BU0PX-037

3b	Check for open dump solenoid or wiring as follows:
<ol style="list-style-type: none"> 1. Turn the ignition switch to the off position 2. Disconnect battery cable 3. Disconnect solenoid valve harness connector from valve connector 4. Check resistance between valve connector dump solenoid pin (orange/blue wire) and ground pin (black wire) 	
<p style="text-align: center;">SOLENOID VALVE CONNECTOR</p>	

Resistance is 1 to 3 ohms

Repair open dump solenoid wire, from valve to control unit
Check for loose or dirty connector pins

Resistance greater than 3 ohms

Replace hydraulic unit


0BU0PX-038

REAR-WHEEL ANTI-LOCK BRAKE SYSTEM

ABS-4 Solenoid valve switch closed

4a Check for closed solenoid valve switch as follows:

1. Disconnect solenoid valve harness connector from valve connector
2. Place ohmmeter on the 20k ohm scale
3. Check resistance between valve connector switch pin (orange wire) and valve body



SOLENOID VALVE CONNECTOR


Resistance greater than 10k ohms → Go to Test 4b

Resistance less than 10k ohms → Replace hydraulic unit

1MU0PX-027

4b Check for short between solenoid valve switch and valve ground lead as follows:

1. Set the ohmmeter on the 20k ohm scale
2. Check resistance between valve connector switch pin (orange wire) and valve solenoid ground pin (black wire)




SOLENOID VALVE CONNECTOR

Resistance greater than 10k ohms → Go to Test 4c

Resistance less than 10k ohms → Replace hydraulic unit

1MU0PX-028




OBU0PX-040


P

REAR-WHEEL ANTI-LOCK BRAKE SYSTEM


ABS-5	System dumps too many times in 4x2 (4x2 and 4x4 vehicles) (condition occurs while making normal or hard stops. Rear brake may lock)
--------------	---



1BU0PX-039



1BU0PX-040




1BU0PX-032

ABS-6 (Speed sensor Signal rapidly cuts in and out) condition only occurs while driving

6a Check for erratic speed sensor signal and loose wire connections as follows:

1. Turn ignition off
2. Disconnect battery cable
3. Set ohmmeter on the 2,000 ohm scale
4. Check resistance between pin [O] (blue wire) and pin [L] (green wire) of the harness connector while shaking the harness from sensor to control unit



CONTROL UNIT HARNESS CONNECTOR

Constant reading of 1,000 to 2,000 ohms → Go to Test 6b

Reading is erratic → Repair loose connection in speed sensor leads. Check for dirty or loose pins, frayed or shorted connectors

1BU0PX-041

6b Check for metal chips on speed sensor magnet pole piece as follows:

Remove the sensor from the differential and inspect for a build-up of metal chips on sensor magnetic pole

No metal chips are present → Go to Test 6c

Metal chips are present → Drain and clean differential. Check the sensor rotor for broken or chipped teeth

0MU0PX-042

6c Check for erratic or low speed sensor output on control unit

1. Locate the ABS check connector (blue: 3-pins)

Note
The ABS check connector is located in the left in the engine compartment (Refer to page P-37)

2. Position vehicle on a hoist and raise the rear wheels to clear the floor
3. Start the engine and turn the wheels at 8 km/h (5 mph)
4. Place voltmeter on the 2000 mV AC scale
5. Measure voltage at the two pins (blue and green wires) of the check connector

Voltage greater than 210 mV RMS (At 3 mph) 350 mV RMS (At 5 mph) and steady → Replace control unit

Voltage less than 210 mV RMS (At 3 mph) 350 mV RMS (At 5 mph) or erratic → Go to Test 6d

1BU0PX-033

6d Check for sensor rotor damage as follows:

1. Remove sensor from carrier
2. Rotate sensor rotor and check for damage to teeth

Teeth are intact and no visible lateral runout is observed → Replace speed sensor and recheck output


Teeth are damaged or lateral runout of sensor rotor is visible → Replace the sensor rotor (Refer to page P-55)

1BU0PX-034

ABS-7 Shorted ground circuit (Isolation solenoid)

7a Check for isolation solenoid or wiring shorted to ground as follows:

1. Turn ignition off
2. Disconnect the solenoid valve harness connector from the solenoid valve connector
3. Set the ohmmeter on the 10 ohm scale
4. Measure the resistance between the isolation solenoid pin (orange/white wire) and the solenoid ground pin (black wire) in the solenoid valve connector



SOLENOID VALVE CONNECTOR


Resistance is 3 to 6 ohms → Go to Test 7b

Resistance is less than 3 ohms → Replace hydraulic unit

2BU0PX-018

7b Check for control unit and wiring shorted to ground as follows:

1. Turn ignition off
2. Disconnect battery cable
3. Disconnect the solenoid valve harness connector from the solenoid valve
4. Disconnect the control unit harness connector from the control unit
5. Place the ohmmeter on the 20k ohm scale
6. Measure the resistance between control unit harness connector pin [C] (orange wire) and chassis ground




CONTROL UNIT HARNESS CONNECTOR

Resistance greater than 20k ohms → Replace control unit

Resistance less than 20k ohms → Repair short between solenoid valve and control unit. Reconnect control unit and solenoid valve

0BU0PX-048

ABS-8	Shorted ground circuit (Dump solenoid)
--------------	--

8a	Check for dump solenoid or wiring shorted to ground as follows:
<ol style="list-style-type: none"> 1. Turn ignition switch off 2. Disconnect solenoid valve harness connector from valve connector 3. Set the ohmmeter on the 10 ohm scale 4. Measure the resistance between the dump solenoid pin (orange/blue wire) and the solenoid valve ground pin (black wire) in the solenoid valve connector 	
 <p style="text-align: center;">SOLENOID VALVE CONNECTOR</p>	

Resistance is 1 to 3 ohms

→


Go to Test 8b

Resistance is less than 1 ohm

→

Replace hydraulic unit

2BU0PX-019

8b	Check for control unit and wiring shorted to ground as follows:
<ol style="list-style-type: none"> 1. Turn ignition off 2. Disconnect battery cable 3. Disconnect solenoid valve harness connector from solenoid valve connector 4. Disconnect the control unit harness connector from the control unit 5. Set the ohmmeter on the 20k ohm scale 6. Measure the resistance between control unit harness connector pin [B] (orange/blue wire) or pin [A] (orange/blue wire) and chassis ground 	
 <p style="text-align: center;">CONTROL UNIT HARNESS CONNECTOR</p>	

Resistance greater than 20k ohms

→

Replace control unit

Resistance less than 20k ohms

→

Repair short between solenoid valve and control unit. Reconnect control unit and solenoid valve


OBU0PX-050

REAR-WHEEL ANTI-LOCK BRAKE SYSTEM

ABS-9	High speed sensor resistance
--------------	------------------------------

9a Check for open speed sensor or sensor wiring as follows:

1. Turn key off
2. Disconnect speed sensor harness connector from the speed sensor on the differential
3. Set the ohmmeter on the 20k ohm scale
4. Measure the resistance at the two sensor pins



SENSOR PINS

SPEED SENSOR CONNECTOR


Resistance is 1,000 to 2,500 ohms → Go to Test 9b

Resistance greater than 2,500 ohms → Replace speed sensor

0BU0PX-051

9b Check for open speed sensor harness wiring as follows:

1. Turn key off
2. Disconnect battery cable
3. Reconnect speed sensor harness connector to speed sensor
4. Disconnect control unit harness connector from control unit
5. Set the ohmmeter on the 20k ohm scale
6. Measure the resistance between harness connector pins [L] (green wire) and [O] (blue wire)



CONTROL UNIT HARNESS CONNECTOR


Resistance is 1,000 to 2,500 ohms → Replace control unit


Resistance greater than 2,500 ohms

Repair open in speed sensor wires between the speed sensor and control unit. Check for loose or dirty pin connectors


1BU0PX-042


ABS-10	Low speed sensor resistance
---------------	-----------------------------

10a	Check for shorted speed sensor as follows:
<ol style="list-style-type: none"> 1. Turn ignition off 2. Disconnect the speed sensor harness from the speed sensor 3. Place the ohmmeter on the 20k ohms scale 4. Measure the resistance at the two sensor pins 	
	
SPEED SENSOR CONNECTOR	





0BU0PX-053

10b	Check for grounded speed sensor wiring as follows:
<ol style="list-style-type: none"> 1. Turn ignition off 2. Disconnect battery cable 3. Disconnect the speed sensor harness connector from the speed sensor 4. Disconnect the control unit harness connector from the control unit 5. Set the ohmmeter on the 20k ohm scale 6. Measure the resistance from pin [O] (blue wire) of the harness connector to chassis ground 	
	
CONTROL UNIT HARNESS CONNECTOR	





1BU0PX-043

10c	Check for shorted speed sensor wiring as follows:
<ol style="list-style-type: none"> 1. Turn ignition off 2. Disconnect speed sensor harness connector from the speed sensor 3. Disconnect the control unit harness connector from the control unit 4. Place the ohmmeter on the 20k ohms scale 5. Measure the resistance from pin [L] (green wire) to pin [O] (blue wire) of the harness connector 	
	
CONTROL UNIT HARNESS CONNECTOR	



REAR-WHEEL ANTI-LOCK BRAKE SYSTEM

ABS-11 Stoplight switch always closed or stoplight switch circuit defective. (Condition indicated only when driving above 56 km/h [35 mph])



REAR-WHEEL ANTI-LOCK BRAKE SYSTEM

P

ABS-12	(12 flashes should not occur)
---------------	-------------------------------

After repeated attempts to take the flashing pattern, 12 flashes are still obtained	→	Replace control unit
---	---	----------------------

0MU0PX-056

ABS-13	Control unit speed circuit phase lock loop failure detected during control unit self-test
---------------	---

→	Replace control unit
---	----------------------

0MU0PX-057

ABS-14	Control unit program check sum failure detected during self-test
---------------	--

→	Replace control unit
---	----------------------

0MU0PX-058

ABS-15	Control unit RAM failure detected during self-test
---------------	--

→	Replace control unit
---	----------------------


0MU0PX-059

ABS-16	(16 or more flashes should not occur)
---------------	---------------------------------------

After repeated attempts to take the flashing pattern, 16 or more flashes are still obtained	→	Replace control unit
---	---	----------------------

0MU0PX-060

REAR-WHEEL ANTI-LOCK BRAKE SYSTEM



1BU0PX-035

CONTROL UNIT

Inspection

Inspection of control unit circuit

1. Remove the driver's seat.
2. Disconnect the harness connector from the control unit.
3. Check the control unit harness connector terminals for voltage or resistance referring to the table below.

V_B: Battery voltage


Tester connection () indicates wire color	Measured item	Remark	Resistance (Battery cable off)	Voltage (IG switch ON)
L (G) - 0 (L)	Speed sensor	—	Approx. 1.4 kΩ	—
P (L/W) - Ground	Battery	—	∞	V _B
N (R) - Ground	Pressure differential switch (PBV)	Parking sw. ON	1Ω	V _B
		Parking sw. OFF	540Ω	
L (G) - Ground	Speed sensor	—	∞	—
H (R/L) - Ground	RFB control unit (4x4 only)	4x2 mode	∞	—
		4x4 mode	0Ω	
F (O/W) - Ground	Pressure switch (Hydraulic unit)	—	∞	—
D (LG) - Ground	Warning lamp	—	Approx. 23Ω	V _B
B (O/L) - Ground	Dump solenoid	—	1-3Ω	0V
Q (L/W) - Ground	Battery	—	∞	V _B
O (L) - Ground	Speed sensor	—	∞	—
		Switch ON	Approx. 1.0Ω	V _B
M (W/G) - Ground	Stoplight switch	Switch OFF		0V
E (Y) - Ground	Check connector	—	∞	0V
C (O) - Ground	Isolation solenoid	—	3-6Ω	0V
A (O/L) - Ground	Dump solenoid	—	1-3Ω	0V
J (B) - Ground	Ground	—	Continuity	—

2BU0PX-020

Caution

- a) When checking resistance at the control unit terminals, always disconnect the battery cable. Improper resistance may occur with the vehicle battery connected.
- b) When using a test lead for testing, use a fine needle to prevent damage to the terminal.

CONTROL UNIT HARNESS CONNECTOR




HYDRAULIC UNIT

Removal and Installation

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal.
4. After installation, bleed air from the system. (Refer to page P-5.)

Note

It is not necessary to energize the solenoid valves electrically to bleed the rear brakes.




N-m (m-kg, ft-lb)
2BU0PX-021

1. Harness coupler
2. Brake pipe

3. Hydraulic unit bracket
4. Hydraulic unit


Removal Note below



OMU0PX-064

Removal Note
Brake pipe

1. Remove the brake pipes with the **SST**.




0MU0PX-065

SPEED SENSOR**Removal**

1. Remove the harness connector.
2. Remove the sensor fixing bolt and remove the speed sensor from the axle casing.

Inspection**Sensor O-ring**

1. Check the sensor O-ring for damage and replace if necessary.




0MU0PX-066

Clearance between sensor and sensor rotor

1. Measure the clearance between the sensor metal tip and the sensor rotor teeth as follows:

- (1) Measure the (A) between the sensor rotor teeth and the sensor attaching surface.
- (2) Measure the (B) between the sensor attaching surface and the sensor metal tip.
- (3) Obtain (A) — (B).



0BU0PX-057

Specified clearance


B2600I: 0.5—1.2mm (0.020—0.047 in)

B2200 : 0.5—1.0mm (0.020—0.039 in)

Note

If the clearance is less than specification, adjust it using the adjustment shim (P049 27 155) during sensor installation. If the clearance is more than specification, replace the speed sensor with new one.

1BU0PX-037




0MU0PX-069

Installation

1. Clean the axle mounting surface.
2. Lubricate the sensor O-ring with motor oil.
3. Install the speed sensor.

Tightening torque:

16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)




OMU0PX-070

SENSOR ROTOR

Removal and Installation

The sensor rotor is not serviceable. If there is a problem (rotor teeth damage etc.) in the sensor rotor, replace the gear case. (Refer to Section M for service.)




OMU0PX-073

PRESSURE DIFFERENTIAL SWITCH

On-vehicle Inspection

1. Connect one end of a vinyl tube to the front brake bleeder screw and place the other end in a receptacle.
2. Loosen the bleeder screw.



OMU0PX-074


3. Turn the ignition switch ON and make sure that the ABS warning lamp flashes and goes off.
4. Depress the brake pedal several times and check that the ABS warning lamp is illuminated because the pressure differential switch is ON.

Note

- a) One person should hold the vinyl tube to prevent the tube from being disconnected when the brake pedal is depressed.
- b) The brake warning lamp (red) is also illuminated when the pressure differential switch is ON.

WIRING DIAGRAM

REAR WHEEL ANTI-LOCK BRAKE SYSTEM



<p>D</p> <table border="1"> <tr><td>L/N</td><td>R</td><td>G</td><td>B</td><td>R/L</td><td>O/W</td><td>L6</td><td>D/L</td></tr> <tr><td>P</td><td>N</td><td>L</td><td>J</td><td>H</td><td>F</td><td>D</td><td>B</td></tr> </table>	L/N	R	G	B	R/L	O/W	L6	D/L	P	N	L	J	H	F	D	B	<p>O-01 REAR WHEEL ABS CONTROL UNIT (FR)</p>	<p>O-02 DIFFERENTIAL SWITCH (F)</p>	<p>O-03 REAR WHEEL ABS SOLENOID (F)</p>	<p>O-04 WHEEL SPEED SENSOR (R)</p>	<p>O-05 CHECK CONNECTOR (F)</p>
L/N	R	G	B	R/L	O/W	L6	D/L														
P	N	L	J	H	F	D	B														