


# SUSPENSION

<b>INDEX</b> .....	<b>R- 2</b>
<b>OUTLINE</b> .....	<b>R- 5</b>
SPECIFICATIONS .....	<b>R- 5</b>
<b>TROUBLESHOOTING GUIDE</b> .....	<b>R- 6</b>
<b>WHEEL ALIGNMENT</b> .....	<b>R- 7</b>
PRE-INSPECTION .....	<b>R- 7</b>
FRONT WHEEL ALIGNMENT .....	<b>R- 7</b>
<b>FRONT SUSPENSION</b>	
<b>(DOUBLE WISHBONE)</b> .....	<b>R- 9</b>
PREPARATION .....	<b>R- 9</b>
SHOCK ABSORBER (4x2 AND 4x4) .....	<b>R-10</b>
TORSION BAR SPRING AND	
LOWER ARM (4x2) .....	<b>R-11</b>
TORSION BAR SPRING AND	
LOWER ARM (4x4) .....	<b>R-16</b>
UPPER ARM (4x2 AND 4x4) .....	<b>R-21</b>
STABILIZER AND TENSION ROD (4x2) .....	<b>R-24</b>
STABILIZER (4x4) .....	<b>R-26</b>
<b>REAR SUSPENSION (LEAF SPRING)</b> .....	<b>R-28</b>
SHOCK ABSORBER AND LEAF SPRINGS	
(4x2 AND 4x4) .....	<b>R-28</b>

2BU0RX-001

### INDEX

#### FRONT SUSPENSION (4x2)



#### FRONT WHEEL ALIGNMENT

TOTAL TOE-IN:  $3 \pm 3\text{mm}$  ( $0.12 \pm 0.12\text{ in.}$ ,  $18' \pm 18'$ )

MAXIMUM STEERING ANGLE:  $35^{\circ}00' \pm 2^{\circ}$  (INNER)  
 $33^{\circ}00' \pm 2^{\circ}$  (OUTER)

CAMBER ANGLE:  $0^{\circ}45' \pm 20'$

CASTER ANGLE M/S:  $0^{\circ}50' \pm 45'$

P/S:  $1^{\circ}50' \pm 45'$

KINGPIN ANGLE:  $8^{\circ}15'$


KNUCKLE ASSEMBLY SERVICE,  
SECTION M

2BU0RX-002

- 1. Shock absorber  
Removal, Inspection, and  
Installation..... page R-10
- 2. Torsion bar spring and lower arm  
Removal ..... page R-11  
Inspection..... page R-13  
Installation..... page R-13

- 3. Upper arm  
Removal and Installation ..... page R-21  
Inspection..... page R-23
- 4. Stabilizer and tension rod  
Removal and Inspection ..... page R-24  
Installation..... page R-25

FRONT SUSPENSION (4x4)



FRONT WHEEL ALIGNMENT

TOTAL TOE-IN:  $3 \pm 3\text{mm}$  ( $0.12 \pm 0.12\text{ in}$ ,  $18' \pm 18'$ )  
 MAXIMUM STEERING ANGLE:  $33^{\circ}30' \pm 2^{\circ}$  (INNER)  
 $30^{\circ}00' \pm 2^{\circ}$  (OUTER)


CAMBER ANGLE:  $1^{\circ}00' \pm \begin{smallmatrix} +30' \\ -20' \end{smallmatrix}$   
 CASTER ANGLE:  $2^{\circ}00' \pm 45'$   
 KINGPIN ANGLE:  $10^{\circ}20'$

KNUCKLE ASSEMBLY SERVICE,  
 SECTION M

2BU0RX-003

- |   |   |
|---|---|
| <p>1. Shock absorber<br/>                 Removal, Inspection and<br/>                 Installation..... page R-10</p> <p>2. Torsion bar spring and lower arm<br/>                 Removal ..... page R-16<br/>                 Inspection ..... page R-18<br/>                 Installation..... page R-18</p> | <p>3. Upper arm<br/>                 Removal and Installation ..... page R-21<br/>                 Inspection ..... page R-23</p> <p>4. Stabilizer<br/>                 Removal and Inspection ..... page R-26<br/>                 Installation..... page R-27</p> |
|---|---|

REAR SUSPENSION (4x2 and 4x4)



2BU0RX-004

- 1. Shock absorber and leaf springs  
Removal and Inspection ..... page R-28  
Installation..... page R-30

OUTLINE

SPECIFICATIONS

Item		Model	4x2	4x4
<b>Front Suspension</b>				
Suspension type			Double wishbone	
Springs	Type		Torsion bar spring	
	Dimensions (bar diameter x length)	mm (in)	21.9 x 901 (0.86 x 35.47)	23.8 x 924 (0.94 x 36.38)
Stabilizer	Type		Torsion bar	
	Diameter	mm (in)	22 (0.87)	24 (0.94)
Shock absorbers	Type		Cylindrical, double-acting	
	Damping force N (kg, lb) at 0.3 m/s	Extended	785 ± 118 (80 ± 12, 176 ± 26)	1,825 ± 255 (186 ± 26, 409 ± 57)
		Compressed	245 ± 59 (25 ± 6, 55 ± 13)	530 ± 98 (54 ± 10, 119 ± 22)
Front wheel alignment (*Unladen condition)	Turning angle	Inner	35°00' ± 2°	33°30' ± 2°
		Outer	33°00' ± 2°	30°00' ± 2°
	Total toe-in	mm (in)	3 ± 3 (0.12 ± 0.12)	
		degree	18' ± 18'	
	Camber angle		0°45' <sup>+30'</sup> <sub>-20'</sub>	1°00' <sup>+30'</sup> <sub>-20'</sub>
	Caster angle		M/S: 0°50' ± 45' P/S: 1°50' ± 45'	2°00' ± 45'
	Kingpin angle		8°15'	10°20'
Caster trail	mm (in)	4.4 (0.17)	12 (0.47)	
<b>Rear Suspension</b>				
Suspension type			Leaf spring	
Springs	Type		Semielliptic leaf spring	
	Dimensions (length x width x thickness)	mm (in)	1,566 x 60 x 7 (61.65 x 2.36 x 0.28)	1,422 x 60 x 9 (55.98 x 2.36 x 0.35)
			1,132 x 60 x 6 (44.57 x 2.36 x 0.24)	979 x 60 x 6 (38.54 x 2.36 x 0.24)
			966 x 60 x 6 (38.03 x 2.36 x 0.24)	844 x 60 x 6 (33.23 x 2.36 x 0.24)
			790 x 60 x 14 (31.10 x 2.36 x 0.55)	639 x 60 x 12 (25.16 x 2.36 x 0.47)
Shock absorbers	Type		Cylindrical, double-acting	
	Damping force N (kg, lb) at 0.3 m/s	Extended	687 ± 108 (70 ± 11, 154 ± 24)	1,079 ± 167 (110 ± 17, 242 ± 37)
		Compressed	471 ± 98 (48 ± 10, 106 ± 22)	441 ± 98 (45 ± 10, 99 ± 22)

M/S: Manual steering P/S: Power steering

1BU0RX-001

\* Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack, and tools in designated position.

# R

## TROUBLESHOOTING GUIDE

### TROUBLESHOOTING GUIDE

Problem	Possible Cause	Remedy	Page
<b>Body rolls</b>	Weak stabilizer Worn or deteriorated stabilizer or tension rod bushing Malfunctioning shock absorber	Replace Replace Replace	R-24, 26 R-24, 26 R-10, 28
<b>Poor riding comfort</b>	Weak torsion bar or leaf spring Malfunctioning shock absorber Excessive tire pressure	Replace Replace Adjust	R-11,16,28 R-10, 28 Section Q
<b>Body leans</b>	Weak torsion bar or leaf spring Weak stabilizer bushing	Replace Replace	R-11,16,28 R-24, 26
<b>Abnormal noise from suspension system</b>	Poor lubrication or wear of upper or lower arm ball joint Looseness of peripheral connections Malfunctioning shock absorber Worn or deteriorated stabilizer or tension rod bushing	Lubricate or replace Tighten Replace Replace	R-11,16,21 — R-10, 28 R-24, 26
<b>Steering "heavy"</b>	Poor lubrication of or foreign material in upper or lower arm ball joint Stuck or damaged upper or lower arm ball joint Improperly adjusted front wheel alignment Problem related to steering system	Lubricate or replace  Replace Adjust —	R-11,16,21  R-11,16,21 R-7 Section N
<b>Steering wheel pulls to one side</b>	Weak torsion bar spring Worn or damaged stabilizer Improperly adjusted front wheel alignment Problem related to steering system Problem related to braking system Problem related to wheels and tires	Replace Replace Adjust — — —	R-11, 16 R-24, 26 R-7 Section N Section P Section Q
<b>Poor steering wheel return</b>	Stuck or damaged upper or lower arm ball joints Improperly adjusted front wheel alignment Problem related to steering system Problem related to wheels and tires	Replace Adjust — —	R-11,16,21 R-7 Section N Section Q
<b>General instability while driving</b>	Weak torsion bar spring Worn or damaged stabilizer Malfunctioning shock absorber Improperly adjust front wheel alignment Problem related to steering system Problem related to wheels and tires	Replace Replace Replace Adjust — —	R-11, 16 R-24, 26 R-10, 28 R-7 Section N Section Q
<b>"Shimmy" occurs (Steering wheel vibrates left/right)</b>	Stuck or damage upper or lower arm ball joints Malfunctioning shock absorber Loose shock absorber mounting bolts Cracked or worn suspension bushing Improperly adjusted front wheel alignment Problem related to steering system Problem related to wheels and tires	Replace Replace Tighten Replace Adjust — —	R-11,16,21 R-10, 28 R-10, 28 R-11,16,21,28 R-7 Section N Section Q

2BU0RX-005

WHEEL ALIGNMENT

PRE-INSPECTION

1. Check the tire inflations and set to the recommended pressure if necessary.
2. Inspect the front wheel bearing play and correct if necessary.
3. Inspect the wheel and tire runout.
4. Inspect the ball joints and steering linkage for any excessive looseness.
5. The vehicle must be on level ground and have no luggage or passenger load.
6. The difference in height between the left and right sides from the center of the wheel to the fender brim must not exceed **10mm (0.39 In)**.

0BU0RX-003


FRONT WHEEL ALIGNMENT  
Specifications

Item			Specifications	
			4x2	4x4
Front wheel alignment (*1Unladen)	Total toe-in	mm (in)	3 ± 3 (0.12 ± 0.12)	
		degree	18' ± 18'	
	Maximum steering angle	Inner	35°00' ± 2°	33°30' ± 2°
		Outer	33°00' ± 2°	30°00' ± 2°
	Camber angle		0°45' <sup>+30'</sup> / <sub>-20'</sub>	1°00' <sup>+30'</sup> / <sub>-20'</sub>
	Caster angle		M/S: 0°50' ± 45' P/S: 1°50' ± 45'	2°00' ± 45'
Kingpin angle		8°15'	10°20'	

M/S: Manual steering P/S: Power steering

2BU0RX-006

\*1 Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack, and tools in designated position.



1BU0RX-002

Adjustment

Maximum steering angle

Adjust the turning angle as follows:


1. Loosen the adjusting bolt locknut.
2. Turn the adjusting bolt to provide the correct turning angle.
3. After adjustment, tighten the locknut to the specified torque.

R

Tightening torque:

**39—59 N·m (4.0—6.0 m·kg, 29—43 ft·lb)**

## WHEEL ALIGNMENT



2BU0RX-051

**Total toe-in**

To adjust the toe-in, loosen the left and right tie rod locknuts, and turn each tie rod an equal amount.

**Locknut tightening torque:**


69—78 N·m (7.0—8.0 m·kg, 51—58 ft·lb)

**Note**

- a) The left and right tie rods are both right threaded. To increase the toe-in, turn the right tie rod toward the front of the vehicle, and turn the left tie rod by the same amount toward the rear.
- b) One turn of the tie rod (both sides) changes the toe-in by about 30mm (1.18 in).

**Camber and caster**

To adjust the camber and caster angles, loosen the bolts of the upper arm shaft and insert or remove adjustment shims.



N·m (m·kg, ft·lb)

1BU0RX-017

No.	Thickness mm (in)	No.	Thickness mm (in)
1	1.0 (0.004)	7	1.0 (0.004)
2	1.6 (0.063)	8	1.6 (0.063)
3	2.0 (0.079)	9	2.0 (0.079)
4	3.2 (0.126)	10	3.2 (0.126)
5	4.0 (0.157)	11	4.0 (0.157)
6	2.0 (0.079)		















**Note**

1. Shims No.1—5 are used at the left and right sides (2/side).
2. Shims No.7—11 are used at the front and rear of the left and right sides (2/side).
3. Shim No.6 is for models equipped with power steering and is used at the rear only of the left and right sides (1/side).
4. **Camber:** A change of shim thickness (at front and rear) of 1mm (0.004 in) results in a change of about 15'.
5. **Caster:** A change of shim thickness (at front or rear only) of 1mm (0.004 in) results in a change of about 30'.



FRONT SUSPENSION (DOUBLE WISHBONE)

PREPARATION

<p>49 0727 575</p> <p>Puller, ball joint</p> 	<p>49 S120 785</p> <p>Installer, dust boot</p> 	<p>49 0180 510B</p> <p>Attachment, preload measurement</p> 
<p>49 U034 2A0</p> <p>Lower arm bushing puller &amp; installer</p> 	<p>49 U034 201</p> <p>Shaft (Part of 49 U034 2A0)</p> 	<p>49 U034 202</p> <p>Support block (Part of 49 U034 2A0)</p> 
<p>49 U034 203</p> <p>Installer (Part of 49 U034 2A0)</p> 	<p>49 W034 305</p> <p>Bearing (Part of 49 U034 2A0)</p> 	<p>49 UB39 615</p> <p>Bushing puller and installer set</p> 
<p>49 UB39 616</p> <p>Shaft set (Part of 49 UB39 615)</p> 	<p>49 UB39 617</p> <p>Support block (Part of 49 UB39 615)</p> 	<p>49 UB39 618</p> <p>Attachment A (Part of 49 UB39 615)</p> 
<p>49 UB39 619</p> <p>Attachment B (Part of 49 UB39 615)</p> 	<p>49 U034 204</p> <p>Installer, dust boot</p> 	<p>9BU0RX-017</p>

# R

## FRONT SUSPENSION (DOUBLE WISHBONE)

### SHOCK ABSORBER (4x2 AND 4x4)


#### Removal, Inspection and Installation

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle, and support it with safety stands.
3. Remove the wheels.
4. Remove in the order shown in the figure.
5. Inspect the shock absorber components and repair or replace as necessary.
6. Install in the reverse order of removal.

#### Caution

Loosely tighten the shock absorber to the lower arm when installing. Lower the vehicle and tighten all nuts and bolts to the specified torques with the vehicle unladen.

7. Inspect front wheel alignment and adjust it as necessary.



1. Nuts
2. Retainers
3. Bushings

Check for damage or deterioration

4. Retainer


5. Bolt
6. Washer and nut
7. Shock absorber

Check for oil leakage, poor operation, damage, or deterioration

**TORSION BAR SPRING AND LOWER ARM (4x2)**

**Removal**

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.




N-m (m-kg, ft-lb)

2BU0RX-007

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Cotter pin</li> <li>2. Nut</li> <li>3. Lower arm ball joint, Knuckle arm<br/>Removal Note..... page R-12</li> <li>4. Bolt, washer, and nut (shock absorber)</li> <li>5. Anchor bolt<br/>Removal Note..... page R-12</li> <li>6. Anchor swivel</li> <li>7. Anchor arm<br/>Inspection..... page R-13</li> <li>8. Torsion bar spring<br/>Removal Note..... page R-12<br/>Inspection..... page R-13</li> <li>9. Bolts and washers</li> <li>10. Torque plate<br/>Inspection..... page R-13</li> </ol> | <ol style="list-style-type: none"> <li>11. Lower arm spindle, washer, and nut</li> <li>12. Rubber bushing<br/>Removal and installation..... page R-12</li> <li>13. Tension rod bolt</li> <li>14. Bolts, bushings, retainers, spacer, and nuts (stabilizer)</li> <li>15. Lower arm<br/>Inspection..... page R-13</li> <li>16. Bound bumper, washer, and nut</li> <li>17. Bolts and washer (ball joint)</li> <li>18. Lower arm ball joint<br/>Inspection..... page R-13</li> <li>19. Lower arm ball joint boot<br/>Removal Note..... page R-12</li> </ol> |
|--|---|

# R

## FRONT SUSPENSION (DOUBLE WISHBONE)




9BU0RX-020

### Removal note

#### Lower arm ball joint/Knuckle arm


Separate the ball joint from the knuckle arm with the **SST**.



9BU0RX-021

### Anchor bolt


Mark the anchor bolt and swivel for reference during reassembly.



9BU0RX-022

### Torsion bar spring


Mark the torsion bar spring and anchor arm and the torsion bar spring and torque plate for reference during reassembly.



9BU0RX-023

### Rubber bushing


Remove the rubber bushing from the body with the **SST**. Install the new bushing into the body with the same **SST**.




2BU0RX-008

### Lower arm ball joint boot


1. Secure the lower arm in a vise protected with brass pads.
2. Use a chisel to remove the boot.




2BU0RX-009




2BU0RX-010



2BU0RX-011



2BU0RX-012



2BU0RX-013

## Inspection

Check for the following and repair or replace parts as necessary.

1. Bending or damage of torsion bar spring.
2. Looseness between serrations of torsion bar spring and anchor arm or the torque plate.
3. Damage or poor operation of ball joint.
4. Damage of lower arm.

5. Lower arm ball joint preload.

Attach the **SST** to the ball stud, and measure the preload with a pull scale.

## Caution

**Measure the preload after first shaking the stud of the ball joint 3 or 4 times.**

## Pull scale reading:

**20—34 N (2.0—3.5 kg, 4.4—7.7 lb)**  
**(While ball stud is rotating)**

## Installation

Install as follows:

1. Liberally coat a new lower arm ball joint boot with grease.
2. Wipe away any grease that has been expelled from the lower arm ball joint boot.
3. Press a new lower arm ball joint boot with the **SST**.
4. Install the lower arm ball joint to the lower arm.
5. Install the lower arm spindle to the lower arm, and temporarily tighten the nut.
6. Install the lower arm ball joint to the knuckle arm.  
Tighten the ball joint nut to the specified torque and install a new cotter pin.

## Tightening torque:

**118—157 N·m (12—16 m·kg, 87—116 ft·lb)**

7. Install the torque plate and tighten it to the specified torque.

## Tightening torque:

**75—93 N·m (7.6—9.5 m·kg, 55—69 ft·lb)**

8. Align the marks made during removal, and connect the torsion bar spring to the torque plate.


## Caution

- a) Coat the serrations of the torsion bar with grease.
- b) Before installation, check the identification color on the end of the torsion bar spring.

**Yellow: Left bar, White: Right bar**

# R

## FRONT SUSPENSION (DOUBLE WISHBONE)




2BU0RX-014

9. Align the marks made during removal, and install the anchor arm onto the torsion bar spring.

### Caution

Coat the serrations of the torsion bar with grease.




2BU0RX-015

10. Install the anchor bolt, and tighten it until the marks made during removal are aligned.

### Note

If the anchor bolt was not marked during removal, install it as follows:

1. Lower the front suspension until the upper arm contacts the rebound stopper.
2. Install the anchor arm so that the angle **(A)** is  $33^{\circ}30'$ .
3. Install the anchor bolt and tighten it by the amount **(B)**.




0BU0RX-008

### Amount **(B)**:

B2200		B2600i
M/T	A/T	M/T and A/T
$45 \pm 1\text{mm}$ ( $1.77 \pm 0.04\text{ in}$ )	$50 \pm 1\text{mm}$ ( $1.97 \pm 0.04\text{ in}$ )	$54.5 \pm 1\text{mm}$ ( $2.15 \pm 0.04\text{ in}$ )

M/T: Manual transmission

A/T: Automatic transmission




2BU0RX-016

11. Install the tension rod bolt.


### Tightening torque:

**93—117 N·m (9.5—11.9 m·kg, 69—86 ft·lb)**



2BU0RX-017

12. Install the stabilizer bolt.  
Tighten the nuts so that **18.5mm (0.73 in)** of thread is exposed at the end of the bolt.



2BU0RX-018

13. Install the shock absorber to the lower arm, and temporarily tighten the bolt and nut.
14. Install the wheels.
15. Lower the vehicle from the safety stands.
16. Tighten the lower arm spindle nut temporarily tightened in Step 5.


**Tightening torque:**

**118—157 N·m (12—16 m·kg, 87—116 ft·lb)**

17. Tighten the shock absorber bolt and nut temporarily tightened in Step 13.

**Tightening torque:**

**55—80 N·m (5.6—8.2 m·kg, 41—59 ft·lb)**



2BU0RX-019

18. Adjust the vehicle height by turning the torsion bar spring anchor bolt.
  - (1) With the vehicle on level ground, check the front and rear tire pressures.
  - (2) Measure the distance from the center of each front wheel to the fender brim.

	mm (in)
Stretch	430 (16.9)
Short	436 (17.2)
Long	431 (17.0)

- (3) If the difference between the left and right is not within the specification, adjust the necessary anchor bolt.

**Vehicle height left/right difference:**


**10mm (0.39 in) max.**

19. Inspect front wheel alignment and adjust it as necessary.

### TORSION BAR SPRING AND LOWER ARM (4x4)

#### Removal

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.




Nm (m-kg, ft-lb)

2BU0RX-020

- |   |  |
|---|--|
| 1. Cotter pin   | 11. Lower arm spindle (rear), washer and nut                   |
| 2. Nut  | 12. Lower arm spindle (front), washer and nut                  |
| 3. Lower arm ball joint, Knuckle arm<br>Removal Note..... page R-17               | 13. Bolt, bushings, retainers, spacer and nuts<br>(stabilizer) |
| 4. Bolt, washer and nut (Shock absorber)  | 14. Lower arm<br>Inspection..... page R-18                     |
| 5. Anchor bolt and washer   | 15. Bound bumper, washer, and nut                              |
| 6. Anchor swivel  | 16. Bolts, washers and nuts                                    |
| 7. Anchor arm<br>Removal Note..... page R-17<br>Inspection..... page R-18         | 17. Lower arm ball joint<br>Inspection..... page R-18          |
| 8. Torsion bar spring<br>Removal Note..... page R-17<br>Inspection..... page R-18 | 18. Lower arm ball joint boot<br>Removal Note..... page R-17   |
| 9. Bolts and washers  | 19. Lower arm bushing<br>Removal Note..... page R-18           |
| 10. Torque plate<br>Inspection..... page R-18                                     |  |






9BU0RX-038

### Removal note

#### Lower arm ball joint/Knuckle arm


Separate the ball joint from the knuckle arm with the **SST**.



9BU0RX-039

#### Anchor arm



Mark the anchor arm and body for reference during reassembly.



9BU0RX-040

#### Torsion bar spring


Mark the torsion bar spring and anchor arm and the torsion bar spring and torque plate for reference during reassembly.




2BU0RX-021

#### Lower arm ball joint boot


1. Secure the lower arm in a vise protected with brass pads.
2. Use a chisel to remove the boot.




9BU0RX-042




9BU0RX-043



2BU0RX-022



2BU0RX-023



2BU0FX-024

**Lower arm bushing****Removal:**

Remove the bushing from the lower arm with the **SST**.

**Installation:**

Install a new bushing into the lower arm with the **SST** as illustrated.

**Note**

**Before installing the bushing, apply soapy water to the bushing surface.**

**Inspection**

Check for the following and repair or replace parts as necessary.

1. Bending or damage of the torsion bar spring.
2. Looseness between serrations of the torsion bar and the anchor arm or the torque plate.
3. Damage or poor operation of ball joint.
4. Damage of lower arm.

5. Lower arm ball joint preload.

Attach the **SST** to the ball stud, and measure the preload with a pull scale.

**Caution**

**Measure the preload after first shaking the joint stud 3 or 4 times.**

**Pull scale reading: 20—35 N (2.0—3.5 kg, 4.4—7.7 lb) (while ball stud is rotating)**


**Installation**

Install as follows:

1. Liberally coat a new lower arm ball joint boot with grease.
2. Wipe away any grease that has been expelled from the lower arm ball joint boot.
3. Press a new lower arm ball joint boot with the **SST**.
4. Install the lower arm ball joint to the lower arm.
5. Install the lower arm spindle to the lower arm, and temporarily tighten the nut.
6. Install the lower arm ball joint into the knuckle arm. Tighten the ball joint nut to the specified torque and install a new cotter pin.

**Tightening torque:**

**118—157 N·m (12.0—16.0 m·kg, 87—116 ft·lb)**




2BU0RX-025

7. Install the torque plate and tighten it to the specified torque.

**Tightening torque:**

**75—93 N·m (7.6—9.5 m·kg, 55—69 ft·lb)**




2BU0RX-026

8. Align the marks made during removal, and connect the torsion bar spring into the torque plate.

**Caution**

- a) Coat the serrations of the torsion bar with grease.
- b) Before installation, check the identification color on the end of torsion bar spring.

**Yellow: Left bar, White: Right bar**




2BU0RX-027

9. Align the marks made during removal, and install the anchor arm onto the torsion bar spring.


**Caution**

**Coat the serrations of the torsion bar with grease.**



2BU0RX-028

10. Install the anchor bolt, and tighten it until the marks made during removal are aligned.



9BU0RX-049


**Note**

**If the anchor bolt was not marked during removal, install it as follows:**


1. Lower the front suspension until the upper arm contacts the rebound stopper.
2. Install the anchor arm so that the angle (A) is 47°.
3. Install the anchor bolt and tighten it by the amount (B).

**Amount (B): 40mm (1.57 in)**


## FRONT SUSPENSION (DOUBLE WISHBONE)




2BU0RX-029



2BU0RX-030



2BU0RX-031



2BU0RX-032

11. Install the stabilizer bolt.  
Tighten the nuts so that **18.5mm (0.73 in)** of thread is exposed at the end of the bolt.
12. Install the shock absorber to the lower arm, and temporarily tighten the bolt and nut.
13. Install the wheels.
14. Lower the vehicle from the safety stands.

15. Tighten the shock absorber bolt and nut temporarily tightened in Step 12.

**Tightening torque:**

**55—80 N·m (5.6—8.2 m·kg, 41—59 ft·lb)**

16. Tighten the lower arm spindle nuts temporarily tightened in Step 5.

**Tightening torque****Front lower arm spindle nut:**

**118—157 N·m (12—16 m·kg, 87—116 ft·lb)**

**Rear lower arm spindle nut:**

**157—196 N·m (16—20 m·kg, 116—145 ft·lb)**

17. Adjust the vehicle height by turning the torsion bar spring anchor bolt.
  - (1) With the vehicle on level ground, check the front and rear tire pressures.
  - (2) Measure the distance from the center of each front wheel to the fender brim.

**Distance: 502mm (19.8 in)**

- (3) If the difference between the left and right is within the specification, adjust the necessary anchor bolt.

**Vehicle height left/right difference:**

**10mm (0.39 in) max.**

18. Inspect front wheel alignment and adjust it as necessary.


**UPPER ARM (4x2 AND 4x4)**

**Removal and Installation**

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.

**Note**


- a) During removal, note the number, amount and position of the adjustment shims so that they are reinstalled in the correct positions.
- b) After installation, check the wheel alignment and adjust it if necessary.  
(Refer to page R-7.)




N-m (m-kg, ft-lb)  
2BU0RX-033

- |                                      |                                  |
|--------------------------------------|----------------------------------|
| 1. Clip                              | 8. Adjustment shims              |
| 2. Cotter pin and nut                | 9. Upper arm assembly            |
| 3. Upper arm ball joint, Knuckle arm | 10. Plug                         |
| Removal Note..... page R-22          | 11. Threaded bushing             |
| 4. Bolts and washers                 | Removal Note..... page R-22      |
| 5. Upper arm ball joint              | Installation Note..... page R-22 |
| Removal Note..... page R-22          | 12. Upper arm shaft              |
| Inspection..... page R-23            | Installation Note..... page R-22 |
| 6. Upper arm ball joint boot         | Inspection..... page R-23        |
| Removal Note..... page R-22          | 13. Dust seal                    |
| Installation Note..... page R-23     | 14. Upper arm                    |
| 7. Bolts and washers                 | Inspection..... page R-23        |


# R FRONT SUSPENSION (DOUBLE WISHBONE)




1BU0RX-026




1BU0RX-027



1BU0RX-019



1BU0RX-020



1BU0RX-025

## Inspection

Check for the following and repair or replace parts as necessary.

1. Cracking, damage, and bending of upper arm and upper arm shaft.
2. Damage and poor operation of upper arm ball joint.

3. Upper arm ball joint preload.

Attach the **SST** to the ball stud, and measure the preload with a pull scale.

## Caution

**Measure the preload after first rocking the ball joint stud 3 or 4 times.**

**Pull scale reading: 20—34 N (2.0—3.5 kg, 4.4—7.7 lb)  
(While ball stud is rotating)**

## Removal note

### Upper arm ball joint/Knuckle arm

Using the **SST**, separate the upper arm ball joint from the knuckle arm.

## Upper arm ball joint boot


1. Secure the upper arm in a vise.
2. Use a chisel as shown to remove the upper arm ball joint boot.

## Note

**Use protective plates in the jaws of the vise to prevent damage to the part secured.**

## Upper arm ball joint boot

1. Liberally coat the new boot with grease, and use the **SST** to press it on.




1BU0RX-024

## Inspection

Verify that the upper arm shaft turns smoothly.

## Caution


**If the upper arm shaft cannot be turned smoothly, replace the upper arm and/or threaded bushings.**



1BU0RX-021

## Threaded bushing

1. Secure the upper arm shaft in a vise.
2. Alternately loosen the threaded bushings in steps.
3. Remove the threaded bushings.




1BU0RX-022

## Installation note

### Upper arm shaft/Threaded bushing

1. Apply the specified grease to the upper arm shaft and threaded bushings.



1BU0RX-027

2. Secure the upper arm shaft in a vise.
3. Install the dust seals and upper arm shaft to the upper arm.
4. Alternately tighten the threaded bushings in steps.

## Tightening torque:

**98—390 N·m (10—40 m·kg, 72—290 ft·lb)**


## Caution

**If the specified tightening torque cannot be obtained, replace the upper arm and/or threaded bushings.**



**STABILIZER AND TENSION ROD (4x2)****Removal and Inspection**

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheel.
4. Remove in the order shown in the figure.
5. Inspect the stabilizer and tension rod components and repair or replace as necessary.




N·m (m·kg, ft·lb)


2BU0RX-038

- |  |  |
|--|--|
| 1. Nuts                                      | 8. Stabilizer bar                                    |
| 2. Retainers                                 | Check for bending, cracking, deterioration or damage |
| 3. Bolt                                      |  |
| 4. Bushings, retainers and spacer            | 9. Nuts  |
| Check the bushings for wear or deterioration | 10. Bushings and retainers                           |
|  | Check bushings for wear or deterioration             |
| 5. Bolts                                     | 11. Bolt   |
| 6. Stabilizer bracket                        | 12. Tension rod                                      |
| 7. Bushing                                   | Check for bending, cracking, deterioration or damage |
| Check for wear or deterioration              |  |






9BU0RX-060



9BU0RX-061



2BU0RX-039

## Installation

Install as follows:

1. Install the tension rod.

## Tightening torque

### Bushing (front):

**93—127 N·m (9.5—13.0 m·kg, 69—94 ft·lb)**

### Lower arm:

**93—117 N·m (9.5—11.9 m·kg, 69—86 ft·lb)**

2. Install the stabilizer bushing and bracket. Tighten the bolts to the specified torque.

## Tightening torque:

**22—26 N·m (2.2—2.7 m·kg, 16—20 ft·lb)**

## Caution

- a) Install so that the bushing seam faces forward.
- b) Lower the vehicle, and then tighten once again to the specified torque with the vehicle in the unladen condition.


3. Install the stabilizer bolt.

Tighten the nuts so that **18.5mm (0.73 in)** of thread is exposed at the end of the bolt.

4. After installation, check the caster angle. (Refer to page R-7.)

**STABILIZER (4x4)****Removal and Inspection**

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheel.
4. Remove in the order shown in the figure.
5. Inspect the stabilizer components and repair or replace as necessary.




22-26 (2.2-2.7, 16-20)


N-m (m-kg, ft-lb)

2BU0RX-040

- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Nuts</li> <li>2. Retainer and bushing<br/>Check bushing for wear or deterioration</li> <li>3. Bolt</li> <li>4. Retainer and bushing<br/>Check bushing for wear or deterioration</li> </ol> | <ol style="list-style-type: none"> <li>5. Retainers, bushings, and spacer<br/>Check bushings for wear or deterioration</li> <li>6. Bolts</li> <li>7. Stabilizer bracket</li> <li>8. Bushing<br/>Check for wear or deterioration</li> <li>9. Stabilizer bar<br/>Check for cracking, bending, deterioration or damage</li> </ol> |
|--|--|



9BU0RX-064



2BU0RX-041

### Installation

1. Install the stabilizer bushing and bracket, and tighten the bolts to the specified torque.

### Tightening torque:

**22–26 N·m (2.2–2.7 m·kg, 16–20 ft·lb)**

### Caution

- a) Install so that the bushing seam faces forward.
- b) Lower the vehicle, and then tighten once again to the specified torque with the vehicle in the unladen condition.

2. Install the stabilizer bolt.  
Tighten the nuts so that **18.5mm (0.73 in)** of thread is exposed at the end of the bolt.
3. After installation, check the caster angle.  
(Refer to page R-7.)

### REAR SUSPENSION (LEAF SPRING)


#### SHOCK ABSORBER AND LEAF SPRINGS (4x2 AND 4x4)

##### Removal and Inspection

1. Loosen the wheel lug nuts.
2. Jack up the rear of the vehicle and support it with safety stands.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Inspect the shock absorber and leaf spring components and repair or replace as necessary.


##### Warning

**Do not place the safety stands under the rear axle casing. Use a jack to raise or lower the axle casing**




1. Nut, washers, retainer, and bushings  
Check bushings for wear or deterioration
2. Nut, washers, retainer, and bushings  
Check bushings for wear or deterioration
3. Shock absorber  
Check for oil leakage or poor operation
4. Nut and washers
5. Nuts and washers
6. U-bolts
7. Spring clamp
8. Stopper rubber  
Check for damage or deterioration

9. Bolts and washers
10. Spring pin
11. Nuts and washers
12. Shackle pin
13. Shackle plate
14. Leaf spring assembly  
Disassembly ..... page R-31  
Assembly ..... page R-31  
Check for weakness or damage
15. Leaf spring bushings  
Removal Note ..... page R-30  
Check for wear or deterioration



2BU0RX-043

- |   |  |
|---|--|
| <ul style="list-style-type: none"> <li>1. Bolt and nut</li> <li>2. Washers, retainer, and bushings<br/>Check bushings for wear or deterioration</li> <li>3. Nut, washers, retainer, and bushings<br/>Check the bushing for wear or deterioration</li> <li>4. Shock absorber<br/>Check for oil leakage or poor operating</li> <li>5. Nut and washers</li> <li>6. Nut and washer</li> <li>7. U-bolts</li> <li>8. Set plates</li> <li>9. Spring clamp</li> <li>10. Stopper rubber<br/>Check for wear or deterioration</li> </ul> | <ul style="list-style-type: none"> <li>11. Bolt and washer</li> <li>12. Spring pin</li> <li>13. Nut and washer</li> <li>14. Shackle pin</li> <li>15. Shackle plate</li> <li>16. Leaf spring assembly<br/>Disassembly ..... page R-31<br/>Assembly ..... page R-31<br/>Check for weakness or damage</li> <li>17. Leaf spring bushing<br/>Removal Note..... page R-30<br/>Check for wear or deterioration</li> </ul> |
|---|--|



9BU0RX-069


### Removal note

#### Leaf spring bushings

Removal:

Secure the leaf spring assembly in a vise and use a chisel to remove the bushings.

**Caution**  
Use protective pads in the vise.



2BU0RX-044

Installation:

Apply rubber grease to the bushing outer surface and press the new bushings in with a suitable round bar.

### Installation

1. Lift the leaf spring assembly into place.
2. Wipe away the grease on the shackle pin and shackle plate.
3. Install the shackle pin and shackle plate, and loosely tighten the shackle mounting nut.
4. Lift the front of the spring assembly.
5. Wipe away grease on the spring pin.
6. Install the spring pin and tighten the mounting nuts of shackle pin and spring pin to the specified torques.


### Tightening torque

**Shackle pin:**

59—78 N·m (6.0—8.0 m·kg, 43—58 ft·lb)


**Spring pin:**

78—98 N·m (8.0—10.0 m·kg, 58—72 ft·lb)



2BU0RX-045

7. Wipe away any grease that has been expelled from the shackle pin, shackle plate and spring pin.



2BU0RX-046

8. Install the U-bolts, set plates and stopper rubber. Tighten the U-bolt mounting nuts to the specified torque.

### Tightening torque


4x2: 64—78 N·m (6.5—8.0 m·kg, 47—58 ft·lb)

4x4:

120—137 N·m (12.2—14.0 m·kg, 88—101 ft·lb)

### Caution

Retighten the nuts to the specified torque after lowering the vehicle (unladen condition).




1BU0RX-015

9. Tighten the shock absorber mounting nuts to the specified torque.

(4x2 and 4x4 Upper mount)

### Tightening torque:

64—78 N·m (6.5—8.0 m·kg, 47—58 ft·lb)




1BU0RX-016

(4x2 and 4x4 Lower mount)

**Tightening torque:**

**64—78 N·m (6.5—8.0 m·kg, 47—58 ft·lb)**



2BU0RX-047


### Leaf spring assembly

#### Disassembly

1. Secure the leaf spring assembly in a vise.


#### Note

**Use protective plates in the jaws of the vise to prevent damage to the part secured.**



2BU0RX-048

2. Uncrimp the clip.
3. Remove the center bolt.




2BU0RX-049

#### Assembly

1. Secure the leaf springs in a vise.
2. Install the center bolt from the upper side.

**Tightening torque:**

**98—137 N·m (10.0—14.0 m·kg, 72—101 ft·lb)**



2BU0RX-050

3. Crimp the clip.

#### Caution

**Do not allow any gap between the clip and the springs.**