Mazda Pick-ups Automotive Repair Manual

by Mike Stubblefield and John H Haynes

Member of the Guild of Motoring Writers

Models covered:

All Mazda Pick-ups 1972 through 1993

Does not include diesel or rotary engine information



(61030-6L17)

AB


AUTOMOTIVE
AUTOS PRIES PACESSORIES MEMBERS
ACCESSORIES MEMBERS
ASSOCIATION MEMBERS

Haynes Publishing Group Sparkford Nr Yeovil

Somerset BA22 7JJ England

Haynes North America, Inc

859 Lawrence Drive Newbury Park California 91320 USA www.haynes.com



Acknowledgements

We are grateful for the help and cooperation of the Mazda Motor Company for their assistance with technical information, certain illustrations and vehicle photos. Technical writers who contributed to this project include Larry Warren, Bob Henderson and Ken Freund.

© Haynes North America, Inc. 1989, 1990, 1992, 1993 With permission from J.H. Haynes & Co. Ltd.

A book in the Haynes Automotive Repair Manual Series

Printed in Malaysia

All rights reserved. No part of this book may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage or retrieval system, without permission in writing from the copyright holder.

ISBN-10: 1-56392-084-0 ISBN-13: 978-1-56392-084-4

Library of Congress Catalog Card Number 93-79165

While every attempt is made to ensure that the information in this manual is correct, no liability can be accepted by the authors or publishers for loss, damage or injury caused by any errors in, or omissions from, the information given.

About this manual

Its purpose

The purpose of this manual is to help you get the best value from your vehicle. It can do so in several ways. It can help you decide what work must be done, even if you choose to have it done by a dealer service department or a repair shop; it provides information and procedures for routine maintenance and servicing; and it offers diagnostic and repair procedures to follow when trouble occurs.

It is hoped that you will use the manual to tackle the work yourself. For many simpler jobs, doing it yourself may be quicker than arranging an appointment to get the vehicle into a shop and making the trips to leave it and pick it up. More importantly, a lot of money can be saved by avoiding the expense the shop must pass on to you to cover its labor and overhead costs. An added benefit is the sense of satisfaction and accomplishment that you feel after having done the job yourself.

Using the manual

The manual is divided into Chapters. Each Chapter is divided into numbered Sections, which are headed in bold type between horizontal

lines. Each Section consists of consecutively numbered paragraphs.

At the beginning of each numbered section you will be referred to any illustrations which apply to the procedures in that section. The reference numbers used in illustration captions pinpoint the pertinent Section and the Step within that section. That is, illustration 3.2 means the illustration refers to Section 3 and Step (or paragraph) 2 within that Section.

Procedures, once described in the text, are not normally repeated. When it is necessary to refer to another Chapter, the reference will be given as Chapter and Section number i.e. Chapter 1/16). Cross references given without use of the word "Chapter" apply to Sections and/or paragraphs in the same Chapter. For example, "see Section 8" means in the same Chapter.

Reference to the left or right side of the vehicle is based on the assumption that one is sitting in the driver's seat, facing forward.

Even though extreme care has been taken during the preparation of this manual, neither the publisher nor the author can accept responsibility for any errors in, or omissions from, the information given.

NOTE

A Note provides information necessary to properly complete a procedure or information which will make the steps to be followed easier to understand.

CAUTION

A Caution indicates a special procedure or special steps which must be taken in the course of completing the procedure in which the Caution is found which are necessary to avoid damage to the assembly being worked on.

WARNING

A Warning indicates a special procedure or special steps which must be taken in the course of completing the procedure in which the Warning is found which are necessary to avoid injury to the person performing the procedure.

Introduction to the Mazda pick-ups

The Mazda pick-up truck is a conventional front engine-rear wheel drive design with four-wheel drive (4WD) available on later models.

The inline four-cylinder engines used in these models are equipped with a carburetor. The engine drives the rear wheels through either a four or five-speed manual or an automatic transmission via a drive-shaft and solid rear axle. On 4WD models, a transfer case is used to

drive the front wheels via a driveshaft and independent driveaxles. Front suspension is independent, featuring coil springs on earlier models and torsion bars on later models, with power assisted steering available on later models. Leaf springs are used in the rear supension.

Earlier models used drum brakes on all four wheels while later models feature disc brakes at the front and drums at the rear.

Vehicle identification numbers

Modifications are a continuing and unpublicized process in vehicle manufacturing. Since spare parts manuals and lists are compiled on a numerical basis, the individual vehicle numbers are essential to correctly identify the component required.

Vehicle Identification Number (VIN)

This very important identification number is stamped on a plate attached to the left side cowling just inside the windshield on the driver's side of the vehicle (see illustration). The VIN also appears on the Vehicle Certificate of Title and Registration. It contains information such as where and when the vehicle was manufactured, the model year and the body style.


Chassis number

The vehicle chassis number is stamped on the frame itself and is visible by looking to the rear of the right front wheel (see illustration).

Vehicle Certification Regulation Plate

The Vehicle Certification Regulation Plate (VC label) is affixed to the left (driver's) door pillar (see iliustration). The plate contains the name of the manufacturer, the month and year of manufacture, the Gross Vehicle Weight Rating (GVWR), the Gross Axle Weight Rating (GAWR) and the certification statement.


The VC label also contains a 17-character Vehicle Identification Number which is used for warranty identification of the vehicle and indicates such things as manufacturer, type of restraint system, line, series, body type, engine, model year and consecutive unit number.




Contents

Introductory pages	
About this manual	0-
Introduction to the Mazda pick-ups	0.
Vehicle identification numbers	0-
Buying parts Maintenance techniques, tools and working facilities	0-
Maintenance techniques, tools and working facilities	0-
Booster battery (jump) starting	0-1
Jacking and towing	0-1
Automotive chemicals and lubricants	0-1
Safety first! Conversion factors	0-1 0-1
Troubleshooting	0-1
Chapter 1 Tune-up and routine maintenance	1-
Chapter 2 Part A Engines	2A-
Chapter 2 Part B	
General engine overhaul procedures	2B-
Chapter 3 Cooling, heating and air conditioning systems	3-
Chapter 4 Fuel and exhaust systems	4-
Chapter 5 Engine electrical systems	5-
Chapter 6 Emissions control systems	6-
Chapter 7 Part A Manual transmission	7 A -
Chapter 7 Part B Automatic transmission	7B-
Chapter 7 Part C Transfer case	7C-I
Chapter 8 Clutch and driveline	8-
Chapter 9 Brakes	9-1
Chapter 10 Suspension and steering systems	10-1
Chapter 11 Body	11-0
Chapter 12 Chassis electrical system	12-0
Wiring diagrams	12-8
Index	IND-1


1988 Mazda Cab Plus pick-up



The Vehicle Emission Control Information (VECI) label is located on the under side of the hood



The tire pressure label can be found on the driver's side door pillar



The engine number is stamped at the front of the block

Vehicle Emission Control Information label


The Vehicle Emission Control Information (VECI) label is located on the under side of the hood (see illustration). It contains information on the emission controls with which your vehicle is equipped.

Tire pressure label

The tire pressure label is found on the driver's side door pillar and contains the recommended tire pressures (see illustration).

Engine number

The engine number for most models is stamped on a pad on the right front side of the block, near the distributor (see illustration).



Replacement parts are available from many sources, which generally fall into one of two categories – authorized dealer parts departments and independent retail auto parts stores. Our advice concerning these parts is as follows:

Retail auto parts stores: Good auto parts stores will stock frequently needed components which wear out relatively fast, such as clutch components, exhaust systems, brake parts, tune-up parts, etc. These stores often supply new or reconditioned parts on an exchange basis, which can save a considerable amount of money. Discount auto parts stores are often very good places to buy materials and parts needed for general vehicle maintenance such as oil, grease, filters, spark plugs, belts, touch-up paint, bulbs, etc. They

also usually sell tools and general accessories, have convenient hours, charge lower prices and can often be found not far from home.

Authorized dealer parts department: This is the best source for parts which are unique to the vehicle and not generally available elsewhere (such as major engine parts, transmission parts, trim pieces, etc.).

Warranty information: If the vehicle is still covered under warranty, be sure that any replacement parts purchased – regardless of the source – do not invalidate the warranty!

To be sure of obtaining the correct parts, have engine and chassis numbers available and, if possible, take the old parts along for positive identification.

Maintenance techniques, tools and working facilities

Maintenance techniques

There are a number of techniques involved in maintenance and repair that will be referred to throughout this manual. Application of these techniques will enable the home mechanic to be more efficient, better organized and capable of performing the various tasks properly, which will ensure that the repair job is thorough and complete.

Fasteners

Fasteners are nuts, bolts, studs and screws used to hold two or more parts together. There are a few things to keep in mind when working with fasteners. Almost all of them use a locking device of some type, either a lockwasher, locknut, locking tab or thread adhesive. All threaded fasteners should be clean and straight, with undamaged threads and undamaged corners on the hex head where the wrench fits. Develop the habit of replacing all damaged nuts and bolts with new ones. Special locknuts with nylon or fiber inserts can only be used

once. If they are removed, they lose their locking ability and must be replaced with new ones.

Rusted nuts and bolts should be treated with a penetrating fluid to ease removal and prevent breakage. Some mechanics use turpentine in a spout-type oil can, which works quite well. After applying the rust penetrant, let it work for a few minutes before trying to loosen the nut or bolt. Badly rusted fasteners may have to be chiseled or sawed off or removed with a special nut breaker, available at tool stores.

If a bolt or stud breaks off in an assembly, it can be drilled and removed with a special tool commonly available for this purpose. Most automotive machine shops can perform this task, as well as other repair procedures, such as the repair of threaded holes that have been stripped

Flat washers and lockwashers, when removed from an assembly, should always be replaced exactly as removed. Replace any damaged washers with new ones. Never use a lockwasher on any soft metal surface (such as aluminum), thin sheet metal or plastic.

Fastener sizes

For a number of reasons, automobile manufacturers are making wider and wider use of metric fasteners. Therefore, it is important to be able to tell the difference between standard (sometimes called U.S. or SAE) and metric hardware, since they cannot be interchanged.


All bolts, whether standard or metric, are sized according to diameter, thread pitch and length. For example, a standard $1/2-13 \times 1$ bolt is 1/2 inch in diameter, has 13 threads per inch and is 1 inch long. An M12 -1.75×25 metric bolt is 12 mm in diameter, has a thread pitch of 1.75 mm (the distance between threads) and is 25 mm long. The two bolts are nearly identical, and easily confused, but they are not interchangeable.

In addition to the differences in diameter, thread pitch and length, metric and standard bolts can also be distinguished by examining the bolt heads. To begin with, the distance across the flats on a standard bolt head is measured in inches, while the same dimension on a metric bolt is sized in millimeters (the same is true for nuts). As a result, a

standard wrench should not be used on a metric bolt and a metric wrench should not be used on a standard bolt. Also, most standard bolts have slashes radiating out from the center of the head to denote the grade or strength of the bolt, which is an indication of the amount of torque that can be applied to it. The greater the number of slashes, the greater the strength of the bolt. Grades 0 through 5 are commonly used on automobiles. Metric bolts have a property class (grade) number, rather than a slash, molded into their heads to indicate bolt strength. In this case, the higher the number, the stronger the bolt. Property class numbers 8.8, 9.8 and 10.9 are commonly used on automobiles.

Strength markings can also be used to distinguish standard hex nuts from metric hex nuts. Many standard nuts have dots stamped into one side, while metric nuts are marked with a number. The greater the number of dots, or the higher the number, the greater the strength of the nut.

Metric studs are also marked on their ends according to property class (grade). Larger studs are numbered (the same as metric bolts),



while smaller studs carry a geometric code to denote grade.

It should be noted that many fasteners, especially Grades 0 through 2, have no distinguishing marks on them. When such is the case, the only way to determine whether it is standard or metric is to measure the thread pitch or compare it to a known fastener of the same size.


Standard fasteners are often referred to as SAE, as opposed to metric. However, it should be noted that SAE technically refers to a non-metric *fine thread* fastener only. Coarse thread non-metric fasteners are referred to as USS sizes.

Since fasteners of the same size (both standard and metric) may have different strength ratings, be sure to reinstall any bolts, studs or nuts removed from your vehicle in their original locations. Also, when replacing a fastener with a new one, make sure that the new one has a strength rating equal to or greater than the original.

Tightening sequences and procedures


Most threaded fasteners should be tightened to a specific torque value (torque is the twisting force applied to a threaded component such as a nut or bolt). Overtightening the fastener can weaken it and cause it to break, while undertightening can cause it to eventually come loose. Bolts, screws and studs, depending on the material they are made of and their thread diameters, have specific torque values, many of which are noted in the Specifications at the beginning of each Chapter. Be sure to follow the torque recommendations closely. For fasteners not assigned a specific torque, a general torque value chart is presented here as a guide. These torque values are for dry (unlubricated) fasteners threaded into steel or cast iron (not aluminum). As was previously mentioned, the size and grade of a fastener determine the amount of torque that can safely be applied to it. The figures listed here are approximate

Metric thread sizes	Ft-lb	Nm/m
M-6	6 to 9	9 to 12
M-8	14 to 21	19 to 28
M-10	28 to 40	38 to 54
M-12	50 to 71	68 to 96
M-14	80 to 140	109 to 15
Pipe thread sizes		
1/8	5 to 8	7 to 10
1/4	12 to 18	17 to 24
3/8	22 to 33	30 to 44
1/2	25 to 35	34 to 47
U.S. thread sizes		
1/4 - 20	6 to 9	9 to 12
5/16 - 18	12 to 18	17 to 24
5/16 - 24	14 to 20	19 to 27
3/8 - 16	22 to 32	30 to 43
3/8 - 24	27 to 38	37 to 51
7/16 — 14	40 to 55	55 to 74
7/16 - 20	40 to 60	55 to 81
1/2 - 13	55 to 80	75 to 108



Standard (SAE and USS) bolt dimensions/grade marks

- G Grade marks (bolt strength)
- L Length (in inches)
- T Thread pitch (number of threads per inch)
- D Nominal diameter (in inches)



Metric bolt dimensions/grade marks

- P Property class (bolt strength)
- L Length (in millimeters)
- T Thread pitch (distance between threads in millimeters)
- D Diameter

for Grade 2 and Grade 3 fasteners. Higher grades can tolerate higher torque values.

Fasteners laid out in a pattern, such as cylinder head bolts, oil pan bolts, differential cover bolts, etc., must be loosened or tightened in sequence to avoid warping the component. This sequence will normally be shown in the appropriate Chapter. If a specific pattern is not given, the following procedures can be used to prevent warping.

Initially, the bolts or nuts should be assembled finger-tight only. Next, they should be tightened one full turn each, in a criss-cross or diagonal pattern. After each one has been tightened one full turn, return to the first one and tighten them all one-half turn, following the same pattern. Finally, tighten each of them one-quarter turn at a time until each fastener has been tightened to the proper torque. To loosen and remove the fasteners, the procedure would be reversed.

Component disassembly

Component disassembly should be done with care and purpose to help ensure that the parts go back together properly. Always keep track of the sequence in which parts are removed. Make note of special characteristics or marks on parts that can be installed more than one way, such as a grooved thrust washer on a shaft. It is a good idea to lay the disassembled parts out on a clean surface in the order that they were removed. It may also be helpful to make sketches or take instant photos of components before removal.

When removing fasteners from a component, keep track of their locations. Sometimes threading a bolt back in a part, or putting the washers and nut back on a stud, can prevent mix-ups later. If nuts and bolts cannot be returned to their original locations, they should be kept in a compartmented box or a series of small boxes. A cupcake or muffin tin is ideal for this purpose, since each cavity can hold the bolts and nuts from a particular area (i.e. oil pan bolts, valve cover bolts, engine mount bolts, etc.). A pan of this type is especially helpful when working on assemblies with very small parts, such as the carburetor, alternator, valve train or interior dash and trim pieces. The cavities can be marked with paint or tape to identify the contents.


Whenever wiring looms, harnesses or connectors are separated, it is a good idea to identify the two halves with numbered pieces of masking tape so they can be easily reconnected.

Gasket sealing surfaces

Throughout any vehicle, gaskets are used to seal the mating surfaces between two parts and keep lubricants, fluids, vacuum or pressure contained in an assembly.

Many times these gaskets are coated with a liquid or paste-type gasket sealing compound before assembly. Age, heat and pressure can sometimes cause the two parts to stick together so tightly that they are very difficult to separate. Often, the assembly can be loosened by striking it with a soft-face hammer near the mating surfaces. A regular hammer can be used if a block of wood is placed between the hammer and the part. Do not hammer on cast parts or parts that could be easily damaged. With any particularly stubborn part, always recheck to make sure that every fastener has been removed.

Avoid using a screwdriver or bar to pry apart an assembly, as they



Micrometer set

can easily mar the gasket sealing surfaces of the parts, which must remain smooth. If prying is absolutely necessary, use an old broom handle, but keep in mind that extra clean up will be necessary if the wood splinters.

After the parts are separated, the old gasket must be carefully scraped off and the gasket surfaces cleaned. Stubborn gasket material can be soaked with rust penetrant or treated with a special chemical to soften it so it can be easily scraped off. A scraper can be fashioned from a piece of copper tubing by flattening and sharpening one end. Copper is recommended because it is usually softer than the surfaces to be scraped, which reduces the chance of gouging the part. Some gaskets can be removed with a wire brush, but regardless of the method used, the mating surfaces must be left clean and smooth. If for some reason the gasket surface is gouged, then a gasket sealer thick enough to fill scratches will have to be used during reassembly of the components. For most applications, a non-drying (or semi-drying) gasket sealer should be used.

Hose removal tips

Warning: If the vehicle is equipped with air conditioning, do not disconnect any of the A/C hoses without first having the system depressurized by a dealer service department or an air conditioning specialist.


Hose removal precautions closely parallel gasket removal precautions. Avoid scratching or gouging the surface that the hose mates against or the connection may leak. This is especially true for radiator hoses. Because of various chemical reactions, the rubber in hoses can bond itself to the metal spigot that the hose fits over. To remove a hose, first loosen the hose clamps that secure it to the spigot. Then, with slip-joint pliers, grab the hose at the clamp and rotate it around the spigot. Work it back and forth until it is completely free, then pull it off. Silicone or other lubricants will ease removal if they can be applied between the hose and the outside of the spigot. Apply the same lubricant to the inside of the hose and the outside of the spigot to simplify installation.

As a last resort (and if the hose is to be replaced with a new one anyway), the rubber can be slit with a knife and the hose peeled from the spigot. If this must be done, be careful that the metal connection is not damaged.


If a hose clamp is broken or damaged, do not reuse it. Wire-type clamps usually weaken with age, so it is a good idea to replace them with screw-type clamps whenever a hose is removed.

Tools


A selection of good tools is a basic requirement for anyone who plans to maintain and repair his or her own vehicle. For the owner who has few tools, the initial investment might seem high, but when compared to the spiraling costs of professional auto maintenance and repair, it is a wise one.



Dial indicator set



Dial caliper




Hand-operated vacuum pump




Timing light



Compression gauge with spark plug hole adapter



Damper/steering wheel puller




General purpose puller



Hydraulic lifter removal tool



Valve spring compressor




Valve spring compressor




Ridge reamer




Piston ring groove cleaning tool



Ring removal/installation tool




Ring compressor




Cylinder hone




Brake hold-down spring tool



Brake cylinder hone



Clutch plate alignment tool



Tap and die set

To help the owner decide which tools are needed to perform the tasks detailed in this manual, the following tool lists are offered: Maintenance and minor repair, Repair/overhaul and Special.

The newcomer to practical mechanics should start off with the maintenance and minor repair tool kit, which is adequate for the simpler jobs performed on a vehicle. Then, as confidence and experience grow, the owner can tackle more difficult tasks, buying additional tools as they are needed. Eventually the basic kit will be expanded into the repair and overhaul tool set. Over a period of time, the experienced do-it-yourselfer will assemble a tool set complete enough for most repair and overhaul procedures and will add tools from the special category when it is felt that the expense is justified by the frequency of use.

Maintenance and minor repair tool kit

Fine emery cloth

Wire brush

The tools in this list should be considered the minimum required for performance of routine maintenance, servicing and minor repair work. We recommend the purchase of combination wrenches (box-end and open-end combined in one wrench). While more expensive than open end wrenches, they offer the advantages of both types of wrench.

Combination wrench set (1/4-inch to 1 inch or 6 mm to 19 mm)
Adjustable wrench, 8 inch
Spark plug wrench with rubber insert
Spark plug gap adjusting tool
Feeler gauge set
Brake bleeder wrench
Standard screwdriver (5/16-inch x 6 inch)
Phillips screwdriver (No. 2 x 6 inch)
Combination pliers — 6 inch
Hacksaw and assortment of blades
Tire pressure gauge
Grease gun
Oil can

Battery post and cable cleaning tool
Oil filter wrench
Funnel (medium size)
Safety goggles
Jackstands (2)
Drain pan

Note: If basic tune-ups are going to be part of routine maintenance, it will be necessary to purchase a good quality stroboscopic timing light and combination tachometer/dwell meter. Although they are included in the list of special tools, it is mentioned here because they are absolutely necessary for tuning most vehicles properly.

Repair and overhaul tool set

These tools are essential for anyone who plans to perform major repairs and are in addition to those in the maintenance and minor repair tool kit. Included is a comprehensive set of sockets which, though expensive, are invaluable because of their versatility, especially when various extensions and drives are available. We recommend the 1/2-inch drive over the 3/8-inch drive. Although the larger drive is bulky and more expensive, it has the capacity of accepting a very wide range of large sockets. Ideally, however, the mechanic should have a 3/8-inch drive set and a 1/2-inch drive set.

Socket set(s)
Reversible ratchet
Extension — 10 inch
Universal joint
Torque wrench (same size drive as sockets)
Ball peen hammer — 8 ounce
Soft-face hammer (plastic/rubber)
Standard screwdriver (1/4-inch x 6 inch)
Standard screwdriver (stubby — 5/16-inch)
Phillips screwdriver (No. 3 x 8 inch)
Phillips screwdriver (stubby — No. 2)

Pliers — vise grip
Pliers — lineman's
Pliers — needle nose
Pliers — snap-ring (internal and external)
Cold chisel — 1/2-inch
Scribe
Scraper (made from flattened copper tubing)
Centerpunch
Pin punches (1/16, 1/8, 3/16-inch)
Steel rule/straightedge — 12 inch
Allen wrench set (1/8 to 3/8-inch or 4 mm to 10 mm)
A selection of files
Wire brush (large)
Jackstands (second set)
Jack (scissor or hydraulic type)

Note: Another tool which is often useful is an electric drill motor with a chuck capacity of 3/8-inch and a set of good quality drill bits.

Special tools

The tools in this list include those which are not used regularly, are expensive to buy, or which need to be used in accordance with their manufacturer's instructions. Unless these tools will be used frequently, it is not very economical to purchase many of them. A consideration would be to split the cost and use between yourself and a friend or friends. In addition, most of these tools can be obtained from a tool rental shop on a temporary basis.

This list primarily contains only those tools and instruments widely available to the public, and not those special tools produced by the vehicle manufacturer for distribution to dealer service departments. Occasionally, references to the manufacturer's special tools are inluded in the text of this manual. Generally, an alternative method of doing the job without the special tool is offered. However, sometimes there is no alternative to their use. Where this is the case, and the tool cannot be purchased or borrowed, the work should be turned over to the dealer service department or an automotive repair shop.

Valve spring compressor Piston ring groove cleaning tool Piston ring compressor Piston ring installation tool Cylinder compression gauge Cylinder ridge reamer Cylinder surfacing hone Cylinder bore gauge Micrometers and/or dial calipers Hydraulic lifter removal tool Balljoint separator Universal-type puller Impact screwdriver Dial indicator set Stroboscopic timing light (inductive pick-up) Hand operated vacuum/pressure pump Tachometer/dwell meter Universal electrical multimeter Cable hoist Brake spring removal and installation tools Floor jack

Buying tools

For the do-it-yourselfer who is just starting to get involved in vehicle maintenance and repair, there are a number of options available when purchasing tools. If maintenance and minor repair is the extent of the work to be done, the purchase of individual tools is satisfactory. If,

on the other hand, extensive work is planned, it would be a good idea to purchase a modest tool set from one of the large retail chain stores. A set can usually be bought at a substantial savings over the individual tool prices, and they often come with a tool box. As additional tools are needed, add-on sets, individual tools and a larger tool box can be purchased to expand the tool selection. Building a tool set gradually allows the cost of the tools to be spread over a longer period of time and gives the mechanic the freedom to choose only those tools that will actually be used.

Tool stores will often be the only source of some of the special tools that are needed, but regardless of where tools are bought, try to avoid cheap ones, especially when buying screwdrivers and sockets, because they won't last very long. The expense involved in replacing cheap tools will eventually be greater than the initial cost of quality tools.

Care and maintenance of tools

Good tools are expensive, so it makes sense to treat them with respect. Keep them clean and in usable condition and store them properly when not in use. Always wipe off any dirt, grease or metal chips before putting them away. Never leave tools lying around in the work area. Upon completion of a job, always check closely under the hood for tools that may have been left there so they won't get lost during a test drive.

Some tools, such as screwdrivers, pliers, wrenches and sockets, can be hung on a panel mounted on the garage or workshop wall, while others should be kept in a tool box or tray. Measuring instruments, gauges, meters, etc. must be carefully stored where they cannot be damaged by weather or impact from other tools.

When tools are used with care and stored properly, they will last a very long time. Even with the best of care, though, tools will wear out if used frequently. When a tool is damaged or worn out, replace it. Subsequent jobs will be safer and more enjoyable if you do.

Working facilities

Not to be overlooked when discussing tools is the workshop. If anything more than routine maintenance is to be carried out, some sort of suitable work area is essential.

It is understood, and appreciated, that many home mechanics do not have a good workshop or garage available, and end up removing an engine or doing major repairs outside. It is recommended, however, that the overhaul or repair be completed under the cover of a roof.

A clean, flat workbench or table of comfortable working height is an absolute necessity. The workbench should be equipped with a vise that has a jaw opening of at least four inches.

As mentioned previously, some clean, dry storage space is also required for tools, as well as the lubricants, fluids, cleaning solvents, etc. which will soon become necessary.

Sometimes waste oil and fluids, drained from the engine or cooling system during normal maintenance or repairs, present a disposal problem. To avoid pouring them on the ground or into a sewage system, pour the used fluids into large containers, seal them with caps and take them to an authorized disposal site or recycling center. Plastic jugs, such as old antifreeze containers, are ideal for this purpose.

Always keep a supply of old newspapers and clean rags available. Old towels are excellent for mopping up spills. Many mechanics use rolls of paper towels for most work because they are readily available and disposable. To help keep the area under the vehicle clean, a large cardboard box can be cut open and flattened to protect the garage or shop floor.

Whenever working over a painted surface, such as when leaning over a fender to service something under the hood, always cover it with an old blanket or bedspread to protect the finish. Vinyl covered pads, made especially for this purpose, are available at auto parts stores.


Certain precautions must be observed when using a booster battery to start a vehicle.

- a) Before connecting the booster battery, make sure the ignition switch is in the Off position.
- b) Turn off the lights, heater and other electrical loads.
- c) Your eyes should be shielded. Safety goggles are a good idea.
- d) Make sure the booster battery is the same voltage as the dead one in the vehicle.
- e) The two vehicles MUST NOT TOUCH each other!
- f) Make sure the transmission is in Neutral (manual) or Park (automatic).
- g) If the booster battery is not a maintenance-free type, remove the vent caps and lay a cloth over the vent holes.

Connect the red jumper cable to the *positive* (+) terminals of each battery.

Connect one end of the black jumper cable to the *negative* (-) terminal of the booster battery. The other end of this cable should be connected to a good ground on the vehicle to be started, such as a bolt or bracket on the engine block (see illustration). Use caution to ensure that the cable will not come into contact with the fan, drivebelts or other moving parts of the engine.

Start the engine using the booster battery, then, with the engine running at idle speed, disconnect the jumper cables in the reverse order of connection.



Make the booster battery cable connections in the numerical order shown (note that the negative cable of the booster battery is NOT attached to the negative terminal of the dead battery)

Jacking and towing


Jacking


The jack supplied with the vehicle should only be used for raising the vehicle when changing a tire or placing jackstands under the frame. **Warning:** Never work under the vehicle or start the engine while this jack is being used as the only means of support.

The vehicle should be on level ground with the wheels blocked and the transmission in Park (automatic) or Reverse (manual). On 4WD


models, the transfer case must be in the 2H, 4H or 4L position (never in Neutral). If a wheel is being changed, loosen the lug nuts one-half turn and leave them in place until the wheel is raised off the ground.

Place the jack under the vehicle suspension in the indicated position (see illustrations). Turn the jack handle clockwise until the wheel is raised off the ground. Remove the lug nuts, pull off the wheel, install





Late model vehicle jacking points



Early model vehicle jacking points

the spare and thread the lug nuts back on with the bevelled sides facing in. Tighten them snugly, but wait until the vehicle is on the ground to finish tightening them.

Lower the vehicle, remove the jack and tighten the nuts (if loosened or removed) in a criss-cross pattern.

Towing

Vehicles with an automatic transmission can be towed with all four wheels on the ground, provided that speeds do not exceed 30 mph and the distance is not over 10 miles, otherwise transmission damage can result. Vehicles equipped with a manual transmission may be towed with all four wheels on the ground at moderate speeds.

Towing equipment specifically designed for this purpose should be used and should be attached to the main structural members of the vehicle, not the bumper or brackets.

Safety is a major consideration when towing and all applicable state and local laws must be obeyed. A safety chain system must be used for all towing.

While towing, the parking brake should be released and the transmission must be in Neutral. On 4WD models, the control lever must be in Neutral and the free running hubs should be in the Free position. The steering must be unlocked (ignition switch in the Off position). Remember that power steering and power brakes will not work with the engine off.

Automotive chemicals and lubricants

A number of automotive chemicals and lubricants are available for use during vehicle maintenance and repair. They include a wide variety of products ranging from cleaning solvents and degreasers to lubricants and protective sprays for rubber, plastic and vinyl.

Cleaners

Carburetor cleaner and choke cleaner is a strong solvent for gum, varnish and carbon. Most carburetor cleaners leave a dry-type lubricant film which will not harden or gum up. Because of this film it is not recommended for use on electrical components.

Brake system cleaner is used to remove grease and brake fluid from the brake system where clean surfaces are absolutely necessary. It leaves no residue and often eliminates brake squeal caused by contaminants.

Electrical cleaner removes oxidation, corrosion and carbon deposits from electrical contacts, restoring full current flow. It can also be used to clean spark plugs, carburetor jets, voltage regulators and other parts where an oil-free surface is desired.

Demoisturants remove water and moisture from electrical components such as alternators, voltage regulators, electrical connectors and fuse blocks. It is non-conductive, non-corrosive and non-flammable.

Degreasers are heavy-duty solvents used to remove grease from the outside of the engine and from chassis components. They can be sprayed or brushed on, and, depending on the type, are rinsed off either with water or solvent.

Lubricants

Motor oil is the lubricant formulated for use in engines. It normally contains a wide variety of additives to prevent corrosion and reduce foaming and wear. Motor oil comes in various weights (viscosity ratings) from 5 to 80. The recommended weight of the oil depends on the season, temperature and the demands on the engine. Light oil is used in cold climates and under light load conditions. Heavy oil is used in hot climates and where high loads are encountered. Multiviscosity oils are designed to have characteristics of both light and heavy oils and are available in a number of weights from 5W-20 to 20W-50.

Gear oil is designed to be used in differentials, manual transaxles and other areas where high-temperature lubrication is required.

Chassis and wheel bearing grease is a heavy grease used where increased loads and friction are encountered, such as for wheel bearings, ballioints, tie rod ends and universal joints.

High temperature wheel bearing grease is designed to withstand the extreme temperatures encountered by wheel bearings in disc brake equipped vehicles. It usually contains molybdenun disulfide (moly), which is a dry-type lubricant.

White grease is a heavy grease for metal to metal applications where water is a problem. White grease stays soft under both low and high temperatures (usually from -100°F to +190°F), and will not wash off or dilute in the presence of water.

Assembly lube is a special extreme pressure lubricant, usually containing moly, used to lubricate high-load parts such as main and rod bearings and cam lobes for initial start-up of a new engine. The assembly lube lubricates the parts without being squeezed out or washed away until the engine oiling system begins to function.

Silicone lubricants are used to protect rubber, plastic, vinyl and nylon

Graphite lubricants are used where oils cannot be used due to contamination problems, such as in locks. The dry graphite will lubricate metal parts while remaining uncontaminated by dirt, water, oil or acids. It is electrically conductive and will not foul electrical contacts in locks such as the ignition switch.

Moly penetrants loosen and lubricate frozen, rusted and corroded fasteners and prevent future rusting or freezing.

Heat-sink grease is a special electrically non-conductive grease that

is used for mounting HEI ignition modules where it is essential that heat be transferred away from the module.

Sealants

RTV sealant is one of the most widely used gasket compounds. Made from silicone, RTV is air curing, it seals, bonds, waterproofs, fills surface irregularities, remains flexible, doesn't shrink, is relatively easy to remove, and is used as a supplementary sealer with almost all low and medium temperature gaskets.

Anaerobic sealant is much like RTV in that it can be used either to seal gaskets or to form gaskets by itself. It remains flexible, is solvent resistant and fills surface imperfections. The difference between an anaerobic sealant and an RTV-type sealant is in the curing. RTV cures when exposed to air, while an anaerobic sealant cures only in the absence of air. This means that an anaerobic sealant cures only after the assembly of parts, sealing them together.

Thread and pipe sealant is used for sealing hydraulic and pneumatic fittings and vacuum lines. It is usually made from a teflon compound, and comes in a spray, a paint-on liquid and as a wrap-around tape.

Chemicals

Anti-seize compound prevents seizing, galling, cold welding, rust and corrosion in fasteners. High temperature anti-seize, usually made with copper and graphite lubricants, is used for exhaust system and manifold bolts.

Anaerobic locking compounds are used to keep fasteners from vibrating or working loose, and cure only after installation, in the absence of air. Medium strength locking compound is used for small nuts, bolts and screws that you expect to be removing later. High strength locking compound is for large nuts, bolts and studs which you don't intend to be removing on a regular basis.

Oil additives range from viscosity index improvers to chemical treatments that claim to reduce internal engine friction. It should be noted that most oil manufacturers caution against using additives with their oils

Gas additives perform several functions, depending on their chemical makeup. They usually contain solvents that help dissolve gum and varnish that build up on carburetor and intake parts. They also serve to break down carbon deposits that form on the inside surfaces of the combustion chambers. Some additives contain upper cylinder lubricants for valves and piston rings, and others chemicals to remove condensation from the gas tank.

Miscellaneous

Brake fluid is specially formulated hydraulic fluid that can withstand the heat and pressure encountered in brake systems. Care must be taken that this fluid does not come in contact with painted surfaces or plastics. An opened container should always be resealed to prevent contamination by water or dirt.

Weatherstrip adhesive is used to bond weatherstripping around doors, windows and trunk lids. It is sometimes used to attach trim pieces.

Undercoating is a petroleum-based tar-like substance that is designed to protect metal surfaces on the underside of the vehicle from corrosion. It also acts as a sound-deadening agent by insulating the bottom of the vehicle.

Waxes and polishes are used to help protect painted and plated surfaces from the weather. Different types of paint may require the use of different types of wax and polish. Some polishes utilize a chemical or abrasive cleaner to help remove the top layer of oxidized (dull) paint on older vehicles. In recent years many non-wax polishes that contain a wide variety of chemicals such as polymers and silicones have been introduced. These non-wax polishes are usually easier to apply and last longer than conventional waxes and polishes.

Safety first!

Regardless of how enthusiastic you may be about getting on with the job at hand, take the time to ensure that your safety is not jeopardized. A moment's lack of attention can result in an accident, as can failure to observe certain simple safety precautions. The possibility of an accident will always exist, and the following points should not be considered a comprehensive list of all dangers. Rather, they are intended to make you aware of the risks and to encourage a safety conscious approach to all work you carry out on your vehicle.

Essential DOs and DON'Ts

DON'T rely on a jack when working under the vehicle. Always use approved jackstands to support the weight of the vehicle and place them under the recommended lift or support points.

DON'T attempt to loosen extremely tight fasteners (i.e. wheel lug nuts) while the vehicle is on a jack — it may fall.

DON'T start the engine without first making sure that the transmission is in Neutral (or Park where applicable) and the parking brake is set.

DON'T remove the radiator cap from a hot cooling system — let it cool or cover it with a cloth and release the pressure gradually.

DON'T attempt to drain the engine oil until you are sure it has cooled to the point that it will not burn you.

DON'T touch any part of the engine or exhaust system until it has cooled sufficiently to avoid burns.

DON'T siphon toxic liquids such as gasoline, antifreeze and brake fluid by mouth, or allow them to remain on your skin.

DON'T inhale brake lining dust — it is potentially hazardous (see Ashestos below)

DON'T allow spilled oil or grease to remain on the floor — wipe it up

before someone slips on it. ${\bf DON'T}$ use loose fitting wrenches or other tools which may slip and

DON'T push on wrenches when loosening or tightening nuts or bolts. Always try to pull the wrench toward you. If the situation calls for pushing the wrench away, push with an open hand to avoid scraped knuckles if the wrench should slip.

DON'T attempt to lift a heavy component alone — get someone to help you.

DON'T rush or take unsafe shortcuts to finish a job.

DON'T allow children or animals in or around the vehicle while you are working on it.

DO wear eye protection when using power tools such as a drill, sander, bench grinder, etc. and when working under a vehicle.

DO keep loose clothing and long hair well out of the way of moving parts.

DO make sure that any hoist used has a safe working load rating adequate for the job.

DO get someone to check on you periodically when working alone on

a vehicle.DO carry out work in a logical sequence and make sure that everything

is correctly assembled and tightened.

DO keep chemicals and fluids tightly capped and out of the reach of children and pets.

DO remember that your vehicle's safety affects that of yourself and others. If in doubt on any point, get professional advice.

Asbestos

Certain friction, insulating, sealing, and other products — such as brake linings, brake bands, clutch linings, torque converters, gaskets, etc. — contain asbestos. Extreme care must be taken to avoid inhalation of dust from such products since it is hazardous to health. If in doubt, assume that they do contain asbestos.

Fire

Remember at all times that gasoline is highly flammable. Never smoke or have any kind of open flame around when working on a vehicle. But the risk does not end there. A spark caused by an electrical short circuit, by two metal surfaces contacting each other, or even by static electricity built up in your body under certain conditions, can ignite gasoline vapors, which in a confined space are highly explosive. Do not, under any circumstances, use gasoline for cleaning parts. Use an approved safety solvent.

Always disconnect the battery ground (–) cable at the battery before working on any part of the fuel system or electrical system. Never risk spilling fuel on a hot engine or exhaust component.

It is strongly recommended that a fire extinguisher suitable for use on fuel and electrical fires be kept handy in the garage or workshop at all times. Never try to extinguish a fuel or electrical fire with water.

Fumes

Certain fumes are highly toxic and can quickly cause unconsciousness and even death if inhaled to any extent. Gasoline vapor falls into this category, as do the vapors from some cleaning solvents. Any draining or pouring of such volatile fluids should be done in a well ventilated area.

When using cleaning fluids and solvents, read the instructions on the container carefully. Never use materials from unmarked containers.

Never run the engine in an enclosed space, such as a garage. Exhaust fumes contain carbon monoxide, which is extremely poisonous. If you need to run the engine, always do so in the open air, or at least have the rear of the vehicle outside the work area.

If you are fortunate enough to have the use of an inspection pit, never drain or pour gasoline and never run the engine while the vehicle is over the pit. The fumes, being heavier than air, will concentrate in the pit with possibly lethal results.

The battery

Never create a spark or allow a bare light bulb near the battery. The battery normally gives off a certain amount of hydrogen gas, which is highly explosive.

Always disconnect the battery ground (-) cable at the battery before working on the fuel or electrical systems.

If possible, loosen the filler caps or cover when charging the battery from an external source. Do not charge at an excessive rate or the battery may burst.

Take care when adding water and when carrying a battery. The electrolyte, even when diluted, is very corrosive and should not be allowed to contact clothing or skin.

Always wear eye protection when cleaning the battery to prevent the caustic deposits from entering your eyes.

Household current

When using an electric power tool, inspection light, etc., which operates on household current, always make sure that the tool is correctly connected to its plug and that, where necessary, it is properly grounded. Do not use such items in damp conditions and, again, do not create a spark or apply excessive heat in the vicinity of fuel or fuel vapor.

Secondary ignition system voltage

A severe electric shock can result from touching certain parts of the ignition system (such as the spark plug wires) when the engine is running or being cranked, particularly if components are damp or the insulation is defective. In the case of an electronic ignition system, the secondary system voltage is much higher and could prove fatal.

Conversion factors

Length (distance)	X	25.4	= Millimetres (mm)	Х	0.0394	= Inches (in)
eet (ft)			= Metres (m)	X	3.281	= Feet (ft)
Ailes			= Kilometres (km)	X	0.621	= Miles
Jakuma Jaanaaitul						
<i>'olume (capacity)</i> ubic inches (cu in; in³)	V	16 207	Cubin	v	0.061	C. bis is about (a. 1-3)
			= Cubic centimetres (cc; cm ³)	X	0.061	= Cubic inches (cu in; in³)
nperial pints (Imp pt)			= Litres (I)	X	1.76	= Imperial pints (Imp pt)
nperial quarts (Imp qt)	X	1.137	= Litres (I)	X	0.88	= Imperial quarts (Imp qt)
mperial quarts (Imp qt)			= US quarts (US qt)	X	0.833	= Imperial quarts (Imp qt)
JS quarts (US qt)			= Litres (I)	X	1.057	= US quarts (US qt)
mperial gallons (Imp gal)	X	4.546	= Litres (I)	X	0.22	= Imperial gallons (Imp gal)
mperial gallons (Imp gal)	X	1.201	= US gallons (US gal)	X	0.833	= Imperial gallons (Imp gal)
IS gallons (US gal)	X	3.785	= Litres (I)	X	0.264	= US gallons (US gal)
lass (weight)			American Contract			
unces (oz)	X	28.35	= Grams (g)	X	0.035	= Ounces (oz)
ounds (lb)	X	0.454	= Kilograms (kg)	X	2.205	= Pounds (lb)
orce			POSITION AND ADDRESS V			Annual report again and a resident
Ounces-force (ozf; oz)			= Newtons (N)	X	3.6	= Ounces-force (ozf; oz)
ounds-force (lbf; lb)	X		= Newtons (N)	X	0.225	= Pounds-force (lbf; lb)
lewtons (N)	Х	0.1	= Kilograms-force (kgf; kg)	×	9.81	= Newtons (N)
Pressure						
	V	0.070	K11		44000	Daniel Constant
ounds-force per square inch	X	0.070	= Kilograms-force per square	Х	14.223	= Pounds-force per square inch
psi; lbf/in²; lb/in²)	.,		centimetre (kgf/cm²; kg/cm²)		44.000	(psi; lbf/in²; lb/in²)
ounds-force per square inch psi; lbf/in²; lb/in²)	Х	0.068	= Atmospheres (atm)	Х	14.696	= Pounds-force per square inch (psi; lb/in²; lb/in²)
ounds-force per square inch	V	0.069	- Bare	Х	14.5	= Pounds-force per square inch
osi; lbf/in²; lb/in²)	^	0.003	= DdiS	^	14.5	(psi; lbf/in²; lb/in²)
ounds-force per square inch	v	6 005	Kilonopole (I.Da)	V	0.145	
	^	0.090	= Kilopascals (kPa)	Х	0.145	= Pounds-force per square inch
osi; lbf/in²; lb/in²)	.,	0.04	1411	.,		(psi; lbf/in²; lb/in²)
ilopascals (kPa)	Х	0.01	= Kilograms-force per square	X	98.1	= Kilopascals (kPa)
			centimetre (kgf/cm²; kg/cm²)			
orque (moment of force)						
ounds-force inches	X	1 152	= Kilograms-force centimetre	Х	0.868	= Pounds-force inches
bf in; lb in)	^	1.102	(kgf cm; kg cm)	^	0.000	(lbf in; lb in)
ounds-force inches	v	0 112	= Newton metres (Nm)	х	8.85	= Pounds-force inches
	^	0.113	= Newton metres (Nm)	^	0.00	
bf in; lb in)		0.000	5 1 6 6 (11 6 6) 11 6)	.,	4.0	(lbf in; lb in)
ounds-force inches	X	0.083	= Pounds-force feet (lbf ft; lb ft)	Х	12	= Pounds-force inches
bf in; lb in)		0.465				(lbf in; lb in)
ounds-force feet (lbf ft; lb ft)	Х	0.138	= Kilograms-force metres	Х	7.233	= Pounds-force feet (lbf ft; lb ft)
aunda faraa faat (lbf ft: lb ft)	V	1 256	(kgf m; kg m)	v	0.720	Davada favos fact (Ibf for Ib for
ounds-force feet (lbf ft; lb ft)			= Newton metres (Nm)	X	0.738	= Pounds-force feet (lbf ft; lb ft)
ewton metres (Nm)	× .	0.102	= Kilograms-force metres	Х	9.804	= Newton metres (Nm)
			(kgf m; kg m)			
ower						
orsepower (hp)	v .	7/57	- \A/atta (\A/)	v	0.0012	- Horsepower (ha)
orsehower (lih)	^	745.7	= Watts (W)	^	0.0013	= Horsepower (hp)
elocity (speed)						
iles per hour (miles/hr; mph)	X	1.609	= Kilometres per hour (km/hr; kph) X	0.621	= Miles per hour (miles/hr; mph)
uel consumption*						
iles per gallon, Imperial (mpg)				Х	2.825	= Miles per gallon, Imperial (mpg)
iles per gallon, US (mpg)	X (0.425	= Kilometres per litre (km/l)	X	2.352	= Miles per gallon, US (mpg)
100						
mperature						

*It is common practice to convert from miles per gallon (mpg) to litres/100 kilometres (l/100km), where mpg (Imperial) \times l/100 km = 282 and mpg (US) \times l/100 km = 235

Conversion factors

Troubleshooting

Contents		- 100 married - 100 m	W. A.
Symptom	Section	Symptom	Section
Engine and performance		Fluid leakage	47
Alternator light fails to come on when key is turned on	13	General shift mechanism problems	
Alternator light stays on		Transmission slips, shifts rough, is noisy	
Battery will not hold a charge		no drive in forward or Reverse gears .	51
Engine backfires		Transmission will not downshift with the	
Engine diesels (continues to run) after being turned off		accelerator pedal pressed to the floor	49
Engine hard to start when cold	4		
Engine hard to start when hot	5	Driveshaft	
Engine lacks power		Knock or clunk when transmission is un-	der initial
Engine 'lopes' while idling or idles erratically	8	load (just after transmission is put into	gear) 53
Engine misses at idle speed	9	Leaks at front of driveshaft	
Engine misses throughout driving speed range	14	Metallic grating sound consistent with v	ehicle speed 54
Engine rotates but will not start	2	Scraping noise	
Engine stalls	16	Vibration	55
Engine starts but stops immediately		Whining or whistling noise	
Engine surges while holding accelerator steady	19	The second secon	
Engine will not rotate when attempting to start		Rear axle and differential	
Excessive fuel consumption		Knocking sound when starting or shifting	g gears 59
Excessively high idle speed		Noise - same when in drive as when ve	
Excessive oil consumption		Noise when turning	60
Fuel odor		Oil leaks	
Hesitation or stumble during acceleration		Vibration	
Low oil pressure			
Miscellaneous engine noises	26	Transfer case (4WD models)	
Pinging or knocking engine sounds when engine		Difficult shifting	64
is under load		Gear jumping out of mesh	
Starter motor noisy or engages roughly		Noise	
Starter motor operates without turning engine	3		
Cooling system		Brakes	
Abnormal coolant loss	21	Brake pedal feels spongy when depresse	d 69
Corrosion		Brake pedal pulsates during brake applica	ation 72
External coolant leakage		Brakes drag (indicated by sluggish engine	e performance
Internal coolant leakage		or wheels being very hot after driving)	
Overcooling		Excessive brake pedal travel	
Overheating		Excessive effort required to stop vehicle	
Poor coolant circulation		Noise (high-pitched squeal)	
Tool opposite on opposite of the second seco		Pedal travels to the floor with little resist	
Clutch		Rear brakes lock up under heavy brake a	pplication 75
Clutch pedal stays on floor when disengaged	39	Rear brakes lock up under light brake ap	plication74
		Vehicle pulls to one side during braking	
Clutch slips (engine speed increases with no increase in vehicle speed)	35	Suspension and steering	
Fails to release (pedal pressed to the floor - shift lever		Excessively stiff steering	80
does not move freely in and out of Reverse)		Excessive pitching and/or rolling around	
Grabbing (chattering) as clutch is engaged		corners or during braking	
Squeal or rumble with clutch disengaged (pedal depressed)		Excessive play in steering	
Squeal or rumble with clutch engaged (pedal released)	37	Excessive tire wear (not specific to one a	area)
Manual transmission		Excessive tire wear on inside edge	
		Excessive tire wear on outside edge	
Difficulty engaging gears		Lack of power assistance	82
Noise occurs while shifting gears		Miscellaneous noises	86
Noisy in all gears		Noisy power steering pump	
Noisy in Neutral with engine running		Shimmy, shake or vibration	77
Noisy in one particular gear		Steering effort not the same in both	
Oil leaks		directions (power system)	
Slips out of gear	43	Steering wheel fails to return to straight-	
Automatia transmission		Tire tread worn in one place	
Automatic transmission	NVII S	Vehicle pulls to one side	
Engine will start in gears other than Park or Neutral	50	Wandering or general instability	79

This Section provides an easy reference guide to the more common problems that may occur during the operation of your vehicle. Various symptoms and their probable causes are grouped under headings denoting components or systems, such as Engine, Cooling system, etc. They also refer to the Chapter and/or Section that deals with the problem.

Remember that successful troubleshooting isn't a mysterious 'black art' practiced only by professional mechanics, it's simply the result of knowledge combined with an intelligent, systematic approach to a problem. Always use a process of elimination starting with the simplest solution and working through to the most complex — and never overlook the obvious. Anyone can run the gas tank dry or leave the lights on overnight, so don't assume that you're exempt from such oversights.

Finally, always establish a clear idea why a problem has occurred and take steps to ensure that it doesn't happen again. If the electrical system fails because of a poor connection, check all other connections in the system to make sure they don't fail as well. If a particular fuse continues to blow, find out why — don't just go on replacing fuses. Remember, failure of a small component can often be indicative of potential failure or incorrect functioning of a more important component or system.

Engine and performance

1 Engine will not rotate when attempting to start

- 1 Battery terminal connections loose or corroded. Check the cable terminals at the battery; tighten cable clamp and/or clean off corrosion as necessary (see Chapter 1).
- 2 Battery discharged or faulty. If the cable ends are clean and tight on the battery posts, turn the key to the On position and switch on the headlights or windshield wipers. If they won't run, the battery is discharged.
- 3 Automatic transmission not engaged in park (P) or Neutral (N).
- 4 Broken, loose or disconnected wires in the starting circuit. Inspect all wires and connectors at the battery, starter solenoid and ignition switch (on steering column).
- 5 Starter motor pinion jammed in flywheel ring gear. If manual transmission, place transmission in gear and rock the vehicle to manually turn the engine. Remove starter (Chapter 5) and inspect pinion and flywheel (Chapter 2) at earliest convenience.
- 6 Starter solenoid faulty (Chapter 5).
- 7 Starter motor faulty (Chapter 5).
- 8 Ignition switch faulty (Chapter 13).
- 9 Engine seized. Try to turn the crankshaft with a large socket and breaker bar on the pulley bolt.

2 Engine rotates but will not start

- 1 Fuel tank empty.
- 2 Battery discharged (engine rotates slowly). Check the operation of electrical components as described in previous Section.
- 3 Battery terminal connections loose or corroded. See previous Section.
- 4 Fuel not reaching carburetor or fuel injection system. Check for clogged fuel filter or lines and defective fuel pump. Also make sure the tank vent lines aren't clogged (Chapter 4).
- 5 Choke not operating properly (Chapter 1).
- 6 Faulty distributor components. Check the cap and rotor (Chapter 1).
- 7 Low cylinder compression. Check as described in Chapter 2.
- 8 Valve clearances not properly adjusted (Chapter 1).
- 9 Water in fuel. Drain tank and fill with new fuel.
- 10 Dirty or clogged carburetor jets. Carburetor out of adjustment. Check the float level (Chapters 1 and 4).
- 11 Wet or damaged ignition components (Chapters 1 and 5).
- 12 Worn, faulty or incorrectly gapped spark plugs (Chapter 1).
- 13 Broken, loose or disconnected wires in the starting circuit (see previous Section).

- 14 Loose distributor (changing ignition timing). Turn the distributor body as necessary to start the engine, then adjust the ignition timing as soon as possible (Chapter 1).
- 15 Broken, loose or disconnected wires at the ignition coil or faulty coil (Chapter 5).
- 16 Timing belt or chain failure or wear affecting valve timing (Chapter 2).

3 Starter motor operates without turning engine

- 1 Starter pinion sticking. Remove the starter (Chapter 5) and inspect.
- 2 Starter pinion or flywheel/driveplate teeth worn or broken. Remove the inspection cover on the left side of the engine and inspect.

4 Engine hard to start when cold

- 1 Battery discharged or low. Check as described in Chapter 1.
- 2 Fuel not reaching the carburetor or fuel injection system. Check the fuel filter, lines and fuel pump (Chapters 1 and 4).
- 3 Choke inoperative (Chapters 1 and 4).
- 4 Defective spark plugs (Chapter 1).

5 Engine hard to start when hot

- 1 Air filter dirty (Chapter 1).
- 2 Fuel not reaching carburetor or fuel injection system (see Section 4). Check for a vapor lock situation, brought about by clogged fuel tank vent lines
- 3 Bad engine ground connection.
- 4 Choke sticking (Chapter 1).
- 5 Defective pick-up coil in distributor (Chapter 5).
- 6 Float level too high (Chapters 1 and 4).

6 Starter motor noisy or engages roughly

- 1 Pinion or flywheel/driveplate teeth worn or broken. Remove the inspection cover on the left side of the engine and inspect.
- 2 Starter motor mounting bolts loose or missing.

7 Engine starts but stops immediately

- 1 Loose or damaged wire harness connections at distributor, coil or
- 2 Intake manifold vacuum leaks. Make sure all mounting bolts/nuts are tight and all vacuum hoses connected to the manifold are attached properly and in good condition.
- 3 Insufficient fuel flow (see Chapter 4 for the fuel pump testing procedure).

8 Engine 'lopes' while idling or idles erratically

- 1 Vacuum leaks. Check mounting bolts at the intake manifold for tightness. Make sure that all vacuum hoses are connected and in good condition. Use a stethescope or a length of fuel hose held against your ear to listen for vacuum leaks while the engine is running. A hissing sound will be heard. A soapy water solution will also detect leaks. Check the intake manifold gasket surfaces.
- 2 Leaking EGR valve or plugged PCV valve (see Chapters 1 and 6).
- 3 Air filter clogged (Chapter 1).
- 4 Fuel pump not delivering sufficient fuel (Chapter 4).
- 5 Leaking head gasket. Perform a cylinder compression check (Chapter 2).
- 6 Timing chain or belt worn or (Chapter 2).
- 7 Camshaft lobes worn (Chapter 2).
- 8 Valve clearance out of adjustment (Chapter 1). Valves burned or otherwise leaking (Chapter 2).
- 9 Ignition timing out of adjustment (Chapter 1).
- 10 Ignition system not operating properly (Chapters 1 and 5).

- 11 Thermostatic air cleaner not operating properly (Chapter 1).
- 12 Choke not operating properly (Chapters 1 and 4).
- 13 Carburetor dirty, clogged or out of adjustment. Check the float level (Chapters 1 and 4).
- 14 Idle speed out of adjustment (Chapter 1).
- 15 clogged fuel injectors or other problems in the fuel injector system (Chapter 4).

9 Engine misses at idle speed

- 1 Spark plugs faulty or not gapped properly (Chapter 1).
- 2 Faulty spark plug wires (Chapter 1).
- 3 Wet or damaged distributor components (Chapter 1).
- 4 Short circuits in ignition, coil or spark plug wires.
- 5 Sticking or faulty emissions systems (see Chapter 6).
- 6 Clogged fuel filter and/or foreign matter in fuel. Remove the fuel filter (Chapter 1) and inspect.
- 7 Vacuum leaks at intake manifold or hose connections. Check as described in Section 8.
- 8 Incorrect idle speed (Chapter 1) or idle mixture (Chapter 4).
- 9 Incorrect ignition timing (Chapter 1).
- 10 Low or uneven cylinder compression. Check as described in Chapter 2.
- 11 Choke not operating properly (Chapter 1).

10 Excessively high idle speed

- 1 Sticking throttle linkage (Chapter 4).
- 2 Choke opened excessively at idle (Chapter 4).
- 3 Idle speed incorrectly adjusted (Chapter 1).
- 4 Valve clearances incorrectly adjusted (Chapter 1).

11 Battery will not hold a charge

- 1 Alternator drivebelt defective or not adjusted properly (Chapter 1).
- 2 Battery cables loose or corroded (Chapter 1).
- 3 Alternator not charging properly (Chapter 5).
- 4 Loose, broken or faulty wires in the charging circuit (Chapter 5).
- 5 Short circuit causing a continuous drain on the battery.
- 6 Battery defective internally.
- 7 Faulty regulator (Chapter 5).

12 Alternator light stays on

- 1 Fault in alternator or charging circuit (Chapter 5).
- 2 Alternator drivebelt defective or not properly adjusted (Chapter 1).

13 Alternator light fails to come on when key is turned on

- 1 Faulty bulb (Chapter 12).
- 2 Defective alternator (Chapter 5).
- 3 Fault in the printed circuit, dash wiring or bulb holder (Chapter 12).

14 Engine misses throughout driving speed range

- 1 Fuel filter clogged and/or impurities in the fuel system. Check fuel filter (Chapter 1) or clean system (Chapter 4).
- 2 Faulty or incorrectly gapped spark plugs (Chapter 1).
- 3 Incorrect ignition timing (Chapter 1).
- 4 Cracked distributor cap, disconnected distributor wires or damaged distributor components (Chapter 1).
- 5 Defective spark plug wires (Chapter 1).
- 6 Emissions system components faulty (Chapter 6).
- 7 Low or uneven cylinder compression pressures. Check as described in Chapter 2.

- 8 Weak or faulty ignition coil (Chapter 5).
- 9 Weak or faulty ignition system (Chapter 5).
- 10 Vacuum leaks at intake manifold or vacuum hoses (see Section 8).
- 11 Dirty or clogged carburetor or fuel injectors (Chapter 4).
- 12 Leaky EGR valve (Chapter 6).
- 13 Carburetor out of adjustment (Chapter 4).
- 14 Idle speed out of adjustment (Chapter 1).

15 Hesitation or stumble during acceleration

- 1 Ignition timing incorrect (Chapter 1).
- 2 Ignition system not operating properly (Chapter 5).
- 3 Dirty or clogged carburetor or fuel injectors (Chapter 4).
- 4 Low fuel pressure. Check for proper operation of the fuel pump and for restrictions in the fuel filter and lines (Chapter 4).
- 5 Carburetor out of adjustment (Chapter 4).

16 Engine stalls

- 1 Idle speed incorrect (Chapter 1).
- 2 Fuel filter clogged and/or water and impurities in the fuel system (Chapter 1).
- 3 Choke not operating properly (Chapter 1).
- 4 Damaged or wet distributor cap and wires.
- 5 Emissions system components faulty (Chapter 6).
- 6 Faulty or incorrectly gapped spark plugs (Chapter 1). Also check the spark plug wires (Chapter 1).
- 7 Vacuum leak at the carburetor, intake manifold or vacuum hoses. Check as described in Section 8.
- 8 Valve clearances incorrect (Chapter 1).

17 Engine lacks power

- 1 Incorrect ignition timing (Chapter 1).
- 2 Excessive play in distributor shaft. At the same time check for faulty distributor cap, wires, etc. (Chapter 1).
- 3 Faulty or incorrectly gapped spark plugs (Chapter 1).
- 4 Air filter dirty (Chapter 1).
- 5 Spark timing control system not operating properly (Chapter 6).
- 6 Faulty ignition coil (Chapter 5).
- 7 Brakes binding (Chapters 1 and 10).
- 8 Automatic transmission fluid level incorrect, causing slippage (Chapter 1).
- 9 Clutch slipping (Chapter 8).
- 10 Fuel filter clogged and/or impurities in the fuel system (Chapters 1 and 4).
- 11 EGR system not functioning properly (Chapter 6).
- 12 Use of substandard fuel. Fill tank with proper octane fuel.
- 13 Low or uneven cylinder compression pressures. Check as described in Chapter 2.
- 14 Air leak at carburetor or throttle body or intake manifold (check as described in Section 8).
- 15 Dirty or clogged carburetor jets or malfunctioning choke (Chapters 1 and 4).

18 Engine backfires

- 1 EGR system not functioning properly (Chapter 6).
- 2 Ignition timing incorrect (Chapter 1).
- 3 Thermostatic air cleaner system not operating properly (Chapter 6).
- 4 Vacuum leak (refer to Section 8).
- 5 Valve clearances incorrect (Chapter 1).
- 6 Damaged valve springs or sticking valves (Chapter 2).
- 7 Intake air leak (see Section 8).
- 8 Carburetor float level out of adjustment (Chapter 4).
- 9 Problem in the fuel injection system (Chapter 4).

19 Engine surges while holding accelerator steady

- Intake air leak (see Section 8).
- Fuel pump not working properly (Chapter 4).

20 Pinging or knocking engine sounds when engine is under load

incorrect grade of fuel. Fill tank with fuel of the proper octane rating.

2 Ignition timing incorrect (Chapter 1).

- 3 Carbon build-up in combustion chambers. Remove cylinder head(s) and clean combustion chambers (Chapter 2).
- Incorrect spark plugs (Chapter 1).

Engine diesels (continues to run) after being turned off

- Idle speed too high (Chapter 1).
- Ignition timing incorrect (Chapter 1). 2
- Incorrect spark plug heat range (Chapter 1).
- Intake air leak (see Section 8).
- Carbon build-up in combustion chambers. Remove the cylinder 5 head and clean the combustion chambers (Chapter 2).
- Valves sticking (Chapter 2).
- Valve clearance incorrect (Chapter 1).
- EGR system not operating properly (Chapter 6). 8
- Fuel shut-off system not operating properly (Chapter 6).
- 10 Check for causes of overheating (Section 27).

22 Low oll pressure

- Improper grade of oil.
- Oil pump regulator valve not operating properly (Chapter 2). 2
- Oil pump worn or damaged (Chapter 2).
- Engine overheating (refer to Section 27).
- 5 Clogged oil filter (Chapter 1).
- Clogged oil strainer (Chapter 2).
- Oil pressure gauge not working properly (Chapter 2).

23 Excessive oil consumption

- Loose oil drain plug.
- Loose bolts or damaged oil pan gasket (Chapter 2).
- Loose bolts or damaged front cover gasket (Chapter 2).
- Front or rear crankshaft oil seal leaking (Chapter 2).
- Loose bolts or damaged rocker arm cover gasket (Chapter 2).
- 6 Loose oil filter (Chapter 1).
- Loose or damaged oil pressure switch (Chapter 2).
- Pistons and cylinders excessively worn (Chapter 2).
- Piston rings not installed correctly on pistons (Chapter 2).
- Worn or damaged piston rings (Chapter 2).
- 11 Intake and/or exhaust valve oil seals worn or damaged (Chapter 2).
- 12 Worn valve stems.
- 13 Worn or damaged valves/guides (Chapter 2).

24 Excessive fuel consumption

- Dirty or clogged air filter element (Chapter 1).
- Incorrect ignition timing (Chapter 1).
- 3 Incorrect idle speed (Chapter 1).
- Low tire pressure or incorrect tire size (Chapter 10).
- Fuel leakage. Check all connections, lines and components in the fuel system (Chapter 4).

- Choke not operating properly (Chapter 1).
- Dirty or clogged carburetor jets (Chapter 4).

25 Fuel odor

- Fuel leakage. Check all connections, lines and components in the fuel system (Chapter 4).
- Fuel tank overfilled. Fill only to automatic shut-off.
- Charcoal canister filter in Evaporative Emissions Control system clogged (Chapter 1).
- Vapor leaks from Evaporative Emissions Control system lines (Chapter 6).

26 Miscellaneous engine noises

- A strong dull noise that becomes more rapid as the engine accelerates indicates worn or damaged crankshaft bearings or an unevenly worn crankshaft. To pinpoint the trouble spot, remove the spark plug wire from one plug at a time and crank the engine over. If the noise stops, the cylinder with the removed plug wire indicates the problem area. Replace the bearing and/or service or replace the crankshaft (Chapter 2).
- A similar (yet slightly higher pitched) noise to the crankshaft knocking described in the previous paragraph, that becomes more rapid as the engine accelerates, indicates worn or damaged connecting rod bearings (Chapter 2). The procedure for locating the problem cylinder is the same as described in Paragraph 1.
- 3 An overlapping metallic noise that increases in intensity as the engine speed increases, yet diminishes as the engine warms up indicates abnormal piston and cylinder wear (Chapter 2). To locate the problem cylinder, use the procedure described in Paragraph 1.
- A rapid clicking noise that becomes faster as the engine accelerates indicates a worn piston pin or piston pin hole. This sound will happen each time the piston hits the highest and lowest points in the stroke (Chapter 2). The procedure for locating the problem piston is described in Paragraph 1.
- A metallic clicking noise coming from the water pump indicates worn or damaged water pump bearings or pump. Replace the water pump with a new one (Chapter 3).
- A rapid tapping sound or clicking sound that becomes faster as the engine speed increases indicates "valve tapping" or improperly adjusted valve clearances. This can be identified by holding one end of a section of hose to your ear and placing the other end at different spots along the rocker arm cover. The point where the sound is loudest indicates the problem valve. Adjust the valve clearance (Chapter 1).
- A steady metallic rattling or rapping sound coming from the area of the timing chain cover indicates a worn, damaged or out-of-adjustment timing chain. Service or replace the chain and related components (Chapter 2).

Cooling system

27 Overheating

- Insufficient coolant in system (Chapter 1).
- Drivebelt defective or not adjusted properly (Chapter 1). 2
- Radiator core blocked or radiator grille dirty and restricted (Chapter 3).
- Thermostat faulty (Chapter 3).
- Fan not functioning properly (Chapter 3).
- Radiator cap not maintaining proper pressure. Have cap pressure tested by gas station or repair shop.
- Ignition timing incorrect (Chapter 1).
- Defective water pump (Chapter 3). 8
- Improper grade of engine oil.
- inaccurate temperature gauge,

28 Overcooling

- 1 Thermostat faulty (Chapter 3).
- 2 Inaccurate temperature gauge.

29 External coolant leakage

- 1 Deteriorated or damaged hoses. Loose clamps at hose connections (Chapter 1).
- 2 Water pump seals defective. If this is the case, water will drip from the weep hole in the water pump body (Chapter 3).
- 3 Leakage from radiator core or header tank. This will require the radiator to be professionally repaired (see Chapter 3 for removal procedures).
- 4 Englne drain plugs or water jacket freeze plugs leaking (see Chapters 1 and 2).
- 5 Leak from coolant temperature switch (Chapter 3).
- 6 Leak from damaged gaskets or small cracks (Chapter 2).
- 7 Damaged head gasket. This can be verifed by checking the condition of the engine oil as noted in Section 30.

30 Internal coolant leakage

Note: Internal coolant leaks can usually be detected by examining the oil. Check the dipstick and inside the rocker arm cover for water deposits and an oil consistency like that of a milkshake.

- 1 Leaking cylinder head gasket. Have the system pressure tested or remove the cylinder head (Chapter 2) and inspect.
- 2 Cracked cylinder bore or cylinder head. Dismantle engine and inspect
- 3 Loose cylinder head bolts (tighten as described in Chapter 2).
- 4 Damaged oil cooler (Chapter 2A).

31 Abnormal coolant loss

- 1 Overfilling system (Chapter 1).
- 2 Coolant boiling away due to overheating (see causes in Section 27).
- 3 Internal or external leakage (see Sections 29 and 30).
- 4 Faulty radiator cap. Have the cap pressure tested.
- 5 Cooling system being pressurized by engine compression. This could be due to a cracked head or block or leaking head gasket(s).

32 Poor coolant circulation

- 1 Inoperative water pump. A quick test is to pinch the top radiator hose closed with your hand while the engine is idling, then release it. You should feel a surge of coolant if the pump is working properly (Chapter 3).
- 2 Restriction in cooling system. Drain, flush and refill the system (Chapter 1). If necessary, remove the radiator (Chapter 3) and have it reverse flushed or professionally cleaned.
- 3 Loose water pump drivebelt (Chapter 1).
- 4 Thermostat sticking (Chapter 3).
- 5 Insufficient coolant (Chapter 1).

33 Corrosion

- 1 Excessive impurities in the water. Soft, clean water is recommended. Distilled or rainwater is satisfactory.
- 2 Insufficient antifreeze solution (refer to Chapter 1 for the proper ratio of water to antifreeze).
- 3 Infrequent flushing and draining of system. Regular flushing of the cooling system should be carried out at the specified intervals as described in (Chapter 1).

Clutch

Note: All clutch related service information is located in Chapter 8, unless otherwise noted.

34 Falls to release (pedal pressed to the floor — shift lever does not move freely in and out of Reverse)

- 1 Clutch contaminated with oil. Remove clutch plate and inspect.
- 2 Clutch plate warped, distorted or otherwise damaged.
- 3 Diaphragm spring fatigued. Remove clutch cover/pressure plate assembly and inspect.
- 4 Leakage of fluid from clutch hydraulic system. Inspect master cylinder, operating cylinder and connecting lines.
- 5 Air in clutch hydraulic system. Bleed the system.
- 6 Insufficient pedal stroke. Check and adjust as necessary.
- 7 Piston seal in operating cylinder deformed or damaged.
- 8 Lack of grease on pilot bushing.

35 Clutch slips (engine speed increases with no increase in vehicle speed)

- Worn or oil soaked clutch plate.
- 2 Clutch plate not broken in. It may take 30 or 40 normal starts for a new clutch to seat.
- 3 Diaphragm spring weak or damaged. Remove clutch cover/pressure plate assembly and inspect.
- 4 Flywheel warped (Chapter 2).
- 5 Debris in master cylinder preventing the piston from returning to its normal position.
- 6 Clutch hydraulic line damaged.

36 Grabbing (chattering) as clutch is engaged

- 1 Oil on clutch plate. Remove and inspect. Repair any leaks.
- 2 Worn or loose engine or transmission mounts. They may move slightly when clutch is released. Inspect mounts and bolts.
- 3 Worn splines on transmission input shaft. Remove clutch components and inspect.
- Warped pressure plate or flywheel. Remove clutch components and inspect.
- 5 Diaphragm spring fatigued. Remove clutch cover/pressure plate assembly and inspect.
- 6 Clutch linings hardened or warped.
- 7 Clutch lining rivets loose.

37 Squeai or rumble with clutch engagad (pedal released)

- 1 Improper pedal adjustment. Adjust pedal free play.
- 2 Release bearing binding on transmission shaft. Remove clutch components and check bearing. Remove any burrs or nicks, clean and relubricate before reinstallation.
- 3 Pilot bushing worn or damaged.
- 4 Clutch rivets loose.
- 5 Clutch plate cracked.
- 6 Fatigued clutch plate torsion springs. Replace clutch plate.

38 Squeal or rumble with clutch disengaged (pedal depressed)

- Worn or damaged release bearing.
- 2 Worn or broken pressure plate diaphragm fingers.

39 Clutch pedal stays on floor when disengaged

1 Binding linkage or release bearing. Inspect linkage or remove clutch components as necessary.

2 Linkage springs being over extended. Adjust linkage for proper free play. Make sure proper pedal stop (bumper) is installed.

Manual transmission

Note: All manual transmission service information is located in Chapter 7, unless otherwise noted.

40 Noisy in Neutral with engine running

- 1 Input shaft bearing worn.
- 2 Damaged main drive gear bearing.
- 3 Insufficient transmission oil (Chapter 1).
- 4 Transmission oil in poor condition. Drain and fill with proper grade oil. Check old oil for water and debris (Chapter 1).
- 5 Noise can be caused by variations in engine torque. Change the idle speed and see if noise disappears.

41 Noisy in all gears

- 1 Any of the above causes, and/or:
- 2 Worn or damaged output gear bearings or shaft.

42 Noisy in one particular gear

- 1 Worn, damaged or chipped gear teeth.
- 2 Worn or damaged synchronizer.

43 Slips out of gear

- 1 Transmission loose on clutch housing.
- 2 Stiff shift lever seal.
- 3 Shift linkage binding.
- 4 Broken or loose input gear bearing retainer.
- 5 Dirt between clutch lever and engine housing.
- 6 Worn linkage.
- 7 Damaged or worn check balls, fork rod ball grooves or check springs.
- 8 Worn mainshaft or countershaft bearings.
- 9 Loose engine mounts (Chapter 2).
- 10 Excessive gear end play.
- 11 Worn synchronizers.

44 Oil leaks

- 1 Excessive amount of lubricant in transmission (see Chapter 1 for correct checking procedures). Drain lubricant as required.
- 2 Side cover loose or gasket damaged.
- 3 Rear oil seal or speedometer oil seal damaged.
- 4 To pinpoint a leak, first remove all built-up dirt and grime from the transmission. Degreasing agents and/or steam cleaning will achieve this. With the underside clean, drive the vehicle at low speeds so the air flow will not blow the leak far from its source. Raise the vehicle and determine where the leak is located.

45 Difficulty engaging gears

- 1 Clutch not releasing completely.
- 2 Loose or damaged shift linkage. Make a thorough inspection, replacing parts as necessary.
- 3 Insufficient transmission oil (Chapter 1).

- 4 Transmission oil in poor condition. Drain and fill with proper grade
- oil. Check oil for water and debris (Chapter 1).
- 5 Worn or damaged striking rod.
- 6 Sticking or jamming gears.

46 Noise occurs while shifting gears

- 1 Check for proper operation of the clutch (Chapter 8).
- 2 Faulty synchronizer assemblies. Measure baulk ring-to-gear clearance. Also, check for wear or damage to baulk rings or any parts of the synchromesh assemblies.

Automatic transmission

Note: Due to the complexity of the automatic transmission, it's difficult for the home mechanic to properly diagnose and service. For problems other than the following, the vehicle should be taken to a reputable mechanic.

47 Fluid leakage

- 1 Automatic transmission fluid is a deep red color, and fluid leaks should not be confused with engine oil which can easily be blown by air flow to the transmission.
- To pinpoint a leak, first remove all built-up dirt and grime from the transmission. Degreasing agents and/or steam cleaning will achieve this. With the underside clean, drive the vehicle at low speeds so the air flow will not blow the leak far from its source. Raise the vehicle and determine where the leak is located. Common areas of leakage are:
 - a) Fluid pan: tighten mounting bolts and/or replace pan gasket as necessary (Chapter 1).
 - b) Rear extension: tighten bolts and/or replace oil seal as necessary.
 - Filler pipe: replace the rubber oil seal where pipe enters transmission case.
 - Transmission oil lines: tighten fittings where lines enter transmission case and/or replace lines.
 - e) Vent pipe: transmission overfilled and/or water in fluid (see checking procedures. Chapter 1).
 - f) Speedometer connector: replace the O-ring where speedometer cable enters transmission case.

48 General shift mechanism problems

Chapter 7 deals with checking and adjusting the shift linkage on automatic transmissions. Common problems which may be caused by out of adjustment linkage are:

- a) Engine starting in gears other than P (park) or N (Neutral).
- b) Indicator pointing to a gear other than the one actually engaged.
- c) Vehicle moves with transmission in P (Park) position.

49 Transmission will not downshift with the accelerator pedal pressed to the floor

Chapter 7 deals with adjusting the kickdown switch to enable the transmission to downshift properly.

50 Engine will start in gears other than Park or Neutral

Chapter 7 deals with adjusting the Neutral start switch installed on automatic transmissions.

51 Transmission slips, shifts rough, is noisy or has no drive in forward or Reverse gears

- 1 There are many probable causes for the above problems, but the home mechanic should concern himself only with one possibility; fluid level.
- 2 Before taking the vehicle to a shop, check the fluid level and condition as described in Chapter 1. Add fluid, if necessary, or change the fluid and filter if needed. If problems persist, have a professional diagnose the transmission.

Driveshaft

Note: Refer to Chapter 8, unless otherwise specified, for service information

52 Leaks at front of driveshaft

Defective transmission rear seal. See Chapter 7 for replacment procedure. As this is done, check the splined yoke for burrs or roughness that could damage the new seal. Remove burrs with a fine file or whetstone.

53 Knock or clunk when transmission is under initial load (just after transmission is put into gear)

- 1 Loose or disconnected rear suspension components. Check all mounting bolts and bushings (Chapters 1 and 11).
- 2 Loose driveshaft bolts. Inspect all bolts and nuts and tighten them securely.
- 3 Worn or damaged universal joint bearings. Replace driveshaft (Chapter 8).
- 4 Worn sleeve yoke and mainshaft spline.
- 5 Defective center bearing or insulator.

54 Metallic grating sound consistent with vehicle speed

Pronounced wear in the universal joint bearings. Replace U-joints or driveshafts, as necessary.

55 Vibration

Note: Before blaming the driveshaft, make sure the tires are perfectly balanced and perform the following test.

- 1 Install a tachometer inside the vehicle to monitor engine speed as the vehicle is driven. Drive the vehicle and note the engine speed at which the vibration (roughness) is most pronounced. Now shift the transmission to a different gear and bring the engine speed to the same point.
- If the vibration occurs at the same engine speed (rpm) regardless of which gear the transmission is in, the driveshaft is NOT at fault since the driveshaft speed varies.
- 3 If the vibration decreases or is eliminated when the transmission is in a different gear at the same engine speed, refer to the following probable causes.
- 4 Bent or dented driveshaft. Inspect and replace as necessary.
- 5 Undercoating or built-up dirt, etc. on the driveshaft. Clean the shaft thoroughly.
- 6 Worn universal joint bearings. Replace the U-joints or driveshaft as necessary.
- 7 Driveshaft and/or companion flange out of balance. Check for missing weights on the shaft. Remove driveshaft and reinstall 180 of from original position, then recheck. Have the driveshaft balanced if problem persists.
- 8 Loose driveshaft mounting bolts/nuts.
- 9 Defective center bearing, if so equipped.
- 10 Worn transmission rear bushing (Chapter 7).

56 Scraping noise

Make sure the dust cover (if equipped) on the sleeve yoke isn't rubbing on the transmission extension housing.

57 Whining or whistling noise

Defective center bearing, if so equipped.

Rear axle and differential

Note: For differential servicing information, refer to Chapter 8.

58 Noise - same when in drive as when vehicle is coasting

- Road noise. No corrective action available.
- 2 Tire noise. Inspect tires and check tire pressures (Chapter 1).
- 3 Front wheel bearings loose, worn or damaged (Chapter 1).
- 4 Insufficient differential oil (Chapter 1).
- 5 Defective differential.

59 Knocking sound when starting or shifting gears

Defective or incorrectly adjusted differential.

60 Noise when turning

Defective differential.

61 Vibration

See probable causes under Driveshaft. Proceed under the guidelines listed for the driveshaft. If the problem persists, check the rear wheel bearings by raising the rear of the vehicle and spinning the wheels by hand. Listen for evidence of rough (noisy) bearings. Remove and inspect (Chapter 8).

62 Oil leaks

- 1 Pinion oil seal damaged (Chapter 8).
- 2 Axleshaft oil seals damaged (Chapter 8).
- 3 Differential cover leaking. Tighten mounting bolts or replace the gasket as required.
- 4 Loose filler or drain plug on differential (Chapter 1).
- 5 Clogged or damaged breather on differential.

Transfer case (4WD models)

63 Gear jumping out of mesh

- 1 Incorrect control lever free play.
- 2 Interference between the control lever and the console.
- 3 Play or fatigue in the transfer case mounts.
- 4 Internal wear or incorrect adjustments.

64 Difficult shifting

- 1 Lack of oil
- 2 Internal wear, damage or incorrect adjustment.

65 Noise

- 1 Lack of oil in transfer case.
- 2 Noise in 4H and 4L, but not in 2H indicates cause is in the front differential or front axle.
- 3 Noise in 2H, 4H and 4L indicates cause is in rear differential or rear axle.
- 4 Noise in 2H and 4H but not in 4L, or in 4L only, indicates internal wear or damage in transfer case.

Brakes

Note: Before assuming a brake problem exists, make sure the tires are in good condition and inflated properly, the front end alignment is correct and the vehicle is not loaded with weight in an unequal manner. All service procedures for the brakes are included in Chapter 9, unless otherwise noted.

66 Vehicle pulls to one side during braking

- 1 Defective, damaged or oil contaminated brake pad on one side. Inspect as described in Chapter 1. Refer to Chapter 9 if replacement is required.
- 2 Excessive wear of brake pad material or disc on one side. Inspect and repair as necessary.
- 3 Loose or disconnected front suspension components. Inspect and tighten all bolts securely (Chapters 1 and 10).
- 4 Defective caliper assembly. Remove caliper and inspect for stuck piston or damage.
- 5 Brake pad to rotor adjustment needed. Inspect automatic adjusting mechanism for proper operation.
- 6 Scored or out of round rotor.
- 7 Loose caliper mounting bolts.
- 8 Incorrect wheel bearing adjustment.

67 Noise (high-pitched squeal)

- 1 Front brake pads worn out. Replace pads with new ones immediately!
- 2 Glazed or contaminated pads.
- 3 Dirty or scored rotor.
- 4 Bent support plate.

68 Excessive brake pedel travel

- 1 Partial brake system failure. Inspect entire system (Chapter 1) and correct as required.
- $2\,$ Insufficient fluid in master cylinder. Check (Chapter 1) and add fluid bleed system if necessary.
- 3 Air in system. Bleed system.
- 4 Excessive lateral rotor play.
- 5 Brakes out of adjustment. Check the operation of the automatic adjusters.
- 6 Defective check valve. Replace valve and bleed system.

69 Brake pedal feels spongy when depressed

- 1 Air in brake lines. Bleed the brake system.
- 2 Deteriorated rubber brake hoses. Inspect all system hoses and lines. Replace parts as necessary.
- 3 Master cylinder mounting nuts loose. Inspect master cylinder bolts (nuts) and tighten them securely.
- 4 Master cylinder faulty.
- 5 Incorrect shoe or pad clearance.

- 6 Defective check valve. Replace valve and bleed system.
- 7 Clogged reservoir cap vent hole.
- 8 Deformed rubber brake lines.
- 9 Soft or swollen caliper seals.
- 10 Poor quality brake fluid. Bleed entire system and fill with new approved fluid.

70 Excessive effort required to stop vehicle

- 1 Power brake booster not operating properly.
- 2 Excessively worn linings or pads. Check and replace if necessary.
- 3 One or more caliper pistons seized or sticking. Inspect and rebuild as required.
- 4 Brake pads or linings contaminated with oil or grease. Inspect and replace as required.
- 5 New pads or linings installed and not yet seated. It'll take a while for the new material to seat against the rotor or drum.
- 6 Worn or damaged master cylinder or caliper assemblies. Check particularly for frozen pistons.
- 7 Also see causes listed under Section 69.

71 Pedal travels to the floor with little resistance

Little or no fluid in the master cylinder reservoir caused by leaking caliper piston(s) or loose, damaged or disconnected brake lines. Inspect entire system and repair as necessary.

72 Brake pedal pulsates during brake application

- 1 Wheel bearings damaged, worn or out of adjustment (Chapter 1).
- 2 Caliper not sliding properly due to improper installation or obstructions. Remove and inspect.
- 3 Rotor not within specifications. Remove the rotor and check for excessive lateral runout and parallelism. Have the rotors resurfaced or replace them with new ones. Also make sure that all rotors are the same thickness.
- 4 Out of round rear brake drums. Remove the drums and have them turned or replace them with new ones.

73 Brakes drag (indicated by sluggish engine performance or wheels being very hot after driving)

- 1 Output rod adjustment incorrect at the brake pedal.
- Obstructed master cylinder compensator. Disassemble master cylinder and clean.
- 3 Master cylinder piston seized in bore. Overhaul master cylinder.
- 4 Caliper assembly in need of overhaul.
- Brake pads or shoes worn out.
- 6 Piston cups in master cylinder or caliper assembly deformed. Overhaul master cylinder.
- 7 Rotor not within specifications (Section 72).
- 8 Parking brake assembly will not release.
- 9 Clogged brake lines.
- 10 Wheel bearings out of adjustment (Chapter 1).
- 11 Brake pedal height improperly adjusted.
- 12 Wheel cylinder needs overhaul.
- 13 Improper shoe to drum clearance. Adjust as necessary.

74 Rear brakes lock up under light brake application

- 1 Tire pressures too high.
- 2 Tires excessively worn (Chapter 1).
- 3 Defective proportioning valve.

75 Rear brakes lock up under heavy brake application

- Tire pressures too high.
- Tires excessively worn (Chapter 1). 2
- Front brake pads contaminated with oil, mud or water. Clean or replace the pads.
- 4 Front brake pads excessively worn.
- Defective master cylinder or caliper assembly.

Suspension and steering

Note: All service procedures for the suspension and steering systems are included in Chapter 11, unless otherwise noted.

76 Vehicle pulls to one side

- Tire pressures uneven (Chapter 1).
- Defective tire (Chapter 1).
- Excessive wear in suspension or steering components (Chapter 1).
- Front end alignment incorrect.
- Front brakes dragging. Inspect as described in Section 73.
- 6 Wheel bearings improperly adjusted (Chapter 1).
- Wheel lug nuts loose.
- Worn upper or lower link or tension rod bushings.

Shimmy, shake or vibration

- Tire or wheel out of balance or out of round. Have them balanced on the vehicle.
- Loose, worn or out of adjustment wheel bearings (Chapter 1).
- Shock absorbers and/or suspension components worn or damaged. Check for worn bushings in the upper and lower links.
- Wheel lug nuts loose.
- Excessively worn or damaged tire.
- Loosely mounted steering gear housing.
- 8 Steering gear improperly adjusted.
- Loose, worn or damaged steering components.
- 10 Damaged idler arm.
- 11 Worn balljoint.

78 Excessive pitching and/or rolling around corners or during braking

- Defective shock absorbers. Replace as a set.
- Broken or weak leaf springs and/or suspension components. 2
- Worn or damaged stabilizer bar or bushings. 3
- Worn or damaged upper or lower links or bushings.

Wandering or general instability

- Improper tire pressures.
- Worn or damaged upper and lower link or tension rod bushings. 2
- Incorrect front end alignment.
- Worn or damaged steering linkage or upper or lower link.
- Improperly adjusted steering gear.
- Out of balance wheels.
- Loose wheel lug nuts.
- Worn rear shock absorbers.
- Fatigued or damaged rear leaf springs.

80 Excessively stiff steering

- Lack of lubricant in power steering fluid reservoir, where appropriate (Chapter 1).
- Incorrect tire pressures (Chapter 1).
- Lack of lubrication at balljoints (Chapter 1).
- Front end out of alignment.
- Steering gear out of adjustment or lacking lubrication.
- Improperly adjusted wheel bearings. 6
- Worn or damaged steering gear.
- Interference of steering column with turn signal switch.
- Low tire pressures.
- Worn or damaged balljoints.
- Worn or damaged steering linkage. 11
- 12 See also Section 79.

81 Excessive play in steering

- Loose wheel bearings (Chapter 1).
- Excessive wear in upper or lower link or tension rod bushings (Chapter 1).
- Steering gear improperly adjusted.
- Incorrect front end alignment.
- Steering gear mounting bolts loose.
- Worn steering linkage.

82 Lack of power assistance

- Steering pump drivebelt faulty or not adjusted properly (Chapter 1).
- Fluid level low (Chapter 1). 2
- 3 Hoses or pipes restricting the flow. Inspect and replace parts as necessary.
- Air in power steering system. Bleed system.
- Defective power steering pump.

83 Steering wheel fails to return to straight-ahead position

- Incorrect front end alignment.
- 2 Tire pressures low.
- Steering gears improperly engaged.
- Steering column out of alignment.
- Worn or damaged balljoint.
- Worn or damaged steering linkage.
- Improperly lubricated idler arm.
- Insufficient oil in steering gear.
- Lack of fluid in power steering pump.

Steering effort not the same in both directions (power system)

- Leaks in steering gear.
- Clogged fluid passage in steering gear.

85 Noisy power steering pump

- Insufficient oil in pump.
- Clogged hoses or oil filter in pump.
- Loose pulley. 3
- Improperly adjusted drivebelt (Chapter 1).
- Defective pump.

86 Miscellaneous noises

- 1 Improper tire pressures.
- 2 Insufficiently lubricated balljoint or steering linkage.
- 3 Loose or worn steering gear, steering linkage or suspension components.
- 4 Defective shock absorber.
- 5 Defective wheel bearing.
- 6 Worn or damaged upper or lower link or tension rod bushing.
- 7 Damaged leaf spring.
- 8 Loose wheel lug nuts.
- 9 Worn or damaged rear axleshaft spline.
- 10 Worn or damaged rear shock absorber mounting bushing.
- 11 Incorrect rear axle end play.
- 12 See also causes of noises at the rear axle and driveshaft.
- 13 Worn or damaged driveaxle joints (4WD models).

87 Excessive tire wear (not specific to one area)

- 1 Incorrect tire pressures.
- 2 Tires out of balance. Have them balanced on the vehicle.
- 3 Wheels damaged. Inspect and replace as necessary.
- 4 Suspension or steering components worn (Chapter 1).

88 Excessive tire wear on outside edge

- 1 Incorrect tire pressure.
- 2 Excessive speed in turns.
- 3 Front end alignment incorrect (excessive toe-in).

89 Excessive tire wear on inside edge

- 1 Incorrect tire pressure.
- 2 Front end alignment incorrect (toe-out).
- 3 Loose or damaged steering components (Chapter 1).

90 Tire tread worn in one place

- 1 Tires out of balance. Have them balanced on the vehicle.
- 2 Damaged or buckled wheel. Inspect and replace if necessary.
- 3 Defective tire.